

WELCOME: YOU HAVE A FRIEND AT SCOTT LABS

Welcome to the 2020 edition of the Scott Labs' Winemaking Handbook! This publication, now in its 25th year, has a new name but the same purpose - to bring the wine industry the best fermentation and enological products while delivering the best product application support and winemaking know-how.

I recently came back to Scott Labs (for the 3rd time!) after having been away for several years. Since my return I have been amazed by the people who serve the needs of our fermentation and enology customers. Our team is large, geographically diverse, knowledgeable, friendly, and fiercely dedicated to getting things right. We are available to answer your questions,

help you troubleshoot a problem, track down an order, or just lend a sympathetic ear.

I'm proud to be part of this team and wanted you to meet us if you haven't done so already. You have a friend at Scott Labs. Your success is our success and we love being part of your community.







Alexha Faraud Cvnthia Coleman



Annamarie Howard









Corinne Frostick



Julia Crosby Vazquez



Maggie McBride



Mollie Forest



Terry Dewane



Margaret Karrer



Nichola Hall, PhD



Rebekka deKramer




Todd Whiteford



Marisa Segovia Nieblas







Jason Butler









Michael Jones



SUPPLIERS

LALLEMAND (ALLEMAND



www.lallemandwine.com

Lallemand has been producing yeast since the 1920s when it started supplying fresh bakers yeast in Quebec, Canada. In 1974, over 50 years later, Lallemand found a new partner with Scott Laboratories who was looking to produce dry wine yeast from their culture collection. Two strains were produced that first year — the first ever active dry wine yeast brought to North America!

The Lallemand/Scott Laboratories relationship, now in its 46th year, has brought North American winemakers nearly one hundred Lallemand products including yeast, yeast-based products, bacteria and enzymes.

These products have changed the way North America makes wine and have changed winemakers' understanding of winemaking.

Lallemand is the leader in knowledge, education, applications and product development for winemakers worldwide. With 150 research scientists, 11 research labs, over 70 publications, eight patents, and collaboration with enological institutions on five continents, Lallemand is committed to the ongoing success of the global wine industry. Their solutions to winemaking problems are both cutting edge and practical.



www.ioc.eu.com

The origins of the Institut Oenologique de Champagne (IOC) headquartered in Epernay, France can to be traced back to the founding of the Entrepôt Général de la Champagne in 1890. Since 2010, Scott Laboratories has supplied their products to North America.

In the early days, the IOC was known for post-fermentation products. Today they offer not only fining agents and stabilizers, but yeast and other wine processing products for still and sparkling wines.

ANCHOR



www. anchoroenology.com

Anchor Yeast began in 1923 when Daniel Mills and Sons started the first yeast factory in Cape Town, South Africa. Yeast is now produced in an ISO 9001:2008 certified plant near Durban. They produce wine yeast, baker's yeast, distilling yeast and whiskey yeast and are sold throughout the world.


The wine yeast strains from Anchor Oenology can be divided into natural isolates and hybrid strains which combine the best characteristics from both parents. Anchor Oenology is the leading New World wine yeast

THE OAK LAB & öaklab.

www.theoaklab.com The Oak Lab is a portfolio of oak infusion products that was launched in 2019 and is the newest division of Scott Laboratories. The Oak Lab's mission is to deliver oak infusion products that are unique and exceedingly high-quality.

The Oak Lab's flagship Thermic line of products are produced using a revolutionry process. The Thermic products are consistent in their flavor and aroma profiles and reliably scale up from bench trials to production volumes with remarkable fidelity.

OENOBRANDS --DSM #AMERICA CONSION



Oenobrands comes to the Scott Laboratories portfolio with a distinguished pedigree. Supported by its world renowned parent companies, DSM Food Specialties and Anchor Oenology, Oenobrands provides wine-

makers with innovative and scientifically sound solutions. This results in revolutionary products from brands such as DSM, Rapidase and Claristar.

ERBSLÖH SERBILGH

www.erbsloeh.com

is one of the most trusted names in the industry. Based in Geisenheim, portfolio premium bentonites and granulated carbons.

Scott Laboratories is proud to add Erbslöh to our list of suppliers. Erbslöh Germany, this family owned company brings the Scott Laboratories

BIOSEUTICA Moisseuffera



www.bioseutica.com

Bioseutica produces our lysozyme. The Bioseutica Group's experience tica researchers discovered that lysozyme had winemaking uses. Bioseuwith egg-derived proteins extends back to the 1940s and they are now tica's lysozyme and Lysovin have since become standard tools in modern the world's largest producer of these products. In the early 1990s Bioseuwinemaking.

AIRD INNOVATIONS IN CHEMISTRY MAIRD

www.airdchemistry.com

AiRD® Innovations in Chemistry specializes in environmentally conyards with the goal of providing sustainable, non-hazardous alternatives scious cleaning products for the wine industry. Founded over two decades ago in New South Wales, Australia, AiRD grew up near the vine-

to caustic for cleaning stainless steel and other surfaces.

TABLE OF CONTENTS

MALOLACTIC FERMENTATION 55
Selecting Bacteria for Success
Co-Inoculation
Co-Inoculation Bacteria Cultures
Sequential Inoculation
Effervescent Direct Addition Bacteria
Selecting Oak & Tannins for Success
Oak Chips Product Descriptions
Oak Infusion (Thermic) Product Descriptions
ENZYMES79Selecting Enzymes for Success.79Choosing Enzymes.80Enzyme Product Descriptions.81Enzymes for American and Hybrid Grape Varieties.82How to Make A 10% Enzyme Solution.86Timing of Additions: SO2, Enzymes & Tannins.86FAQS.86

TABLE OF CONTENTS (CONTINUED)

11	MICROBIAL CONTROL	87
	Microbial Control Action	.87
	Selecting Microbial Control Agents for Success	.87
	Choosing Microbial Control Agents	.88
	Lysozyme, Chitosan, and Chitin-Glucan	.89
	Lysovin or Bactiless?	.89
	Bactiless	.90
	No Brett Inside	.90
	Sulfur Dioxide	.91
	Tartaric Acid	.91
	FAQS	.92
F	FINING & STABILITY	93
1	In the world in the control of the c	- 0
1	Selecting Fining & Stability Agents for Success	
1		.93
	Selecting Fining & Stability Agents for Success	.93 .93
-	Selecting Fining & Stability Agents for Success Factors Impacting Efficacy of Fining Agents	.93 .93 .94
	Selecting Fining & Stability Agents for Success Factors Impacting Efficacy of Fining Agents	.93 .93 .94 .95
•	Selecting Fining & Stability Agents for Success	.93 .93 .94 .95
1	Selecting Fining & Stability Agents for Success Factors Impacting Efficacy of Fining Agents	.93 .93 .94 .95
1	Selecting Fining & Stability Agents for Success Factors Impacting Efficacy of Fining Agents	.93 .93 .94 .95 .95
1	Selecting Fining & Stability Agents for Success Factors Impacting Efficacy of Fining Agents Choosing Fining & Stability Agents Fining Agents Product Descriptions Activated Carbon Bentonite. Casein and/or PVPP.	.93 .94 .95 .95 .95
1	Selecting Fining & Stability Agents for Success Factors Impacting Efficacy of Fining Agents Choosing Fining & Stability Agents Fining Agents Product Descriptions Activated Carbon Bentonite. Casein and/or PVPP.	.93 .94 .95 .95 .95
1	Selecting Fining & Stability Agents for Success Factors Impacting Efficacy of Fining Agents Choosing Fining & Stability Agents. Fining Agents Product Descriptions Activated Carbon Bentonite. Casein and/or PVPP. Gelatins Inactivated Yeast & Bentonite Blends	.93 .93 .94 .95 .95 .95 .98 100
1	Selecting Fining & Stability Agents for Success Factors Impacting Efficacy of Fining Agents Choosing Fining & Stability Agents. Fining Agents Product Descriptions Activated Carbon Bentonite. Casein and/or PVPP. Gelatins Inactivated Yeast & Bentonite Blends Inert Clarifying Agents	.93 .94 .95 .95 .95 .98 100 101

CLEANING
Benefits of Cleaning Products
Water Savings With Aird Cleaning Products
Choosing Cleaning Products for Success
Cleaning Product Descriptions
FRUIT WINES & MEAD 107
Choosing Products for Fruit Wines & Mead
Selecting Products for Success In Fruit Wines & Mead108
GENERAL TOOLS109
GENERAL TOOLS
Calculations & Conversions
Calculations & Conversions
Calculations & Conversions.109Bench Trial Protocol & Procedure.110Finishing Kit for Bench Trials.110

Vendor Notice

The information in this booklet is, to the best of our knowledge, true and accurate. The data and information, however, are not to be considered as a guarantee, expressed or implied, or as a condition of sale of our products. Furthermore, it is understood by both buyer and vendor that wine is a natural product. Circumstances such as fruit qualities and cellar conditions are infinitely variable. It is the responsibility of the buyer to adapt the use of our products to such circumstances. There is no substitute for good winemaking practices or ongoing vigilance.

Please Note:

Trade of wine between the United States, Canada and other nations and/or trade blocs (such as the European Community) may involve restrictions. In particular these may involve proscription or limitation on the allowable levels of certain ingredients in fermentation aids, fining agents or stabilization products. To the best of our knowledge, all products described in this handbook when used as directed herein are legal for use in wine made in, and sold, in the United States. Conditions of trade with other nations and trade blocs are subject to ongoing change beyond the control of Scott Laboratories, Inc. It is the responsibility of users of our products to be informed of current restrictions of other countries or trade blocs to which they wish export and to use only products and product levels which conform to those restrictions.

NEW PRODUCTS FROM SCOTT LABORATORIES

LALLEMAND

YEAST



Taste the power of New Zealand!



MSB (Marlborough Sauvignon blanc) is a newly isolated yeast strain from the Marlborough Valley in New Zealand. This strain enhances fruity, tropical and citrus notes.



YEAST

Find MSB on page 27.

LALLEMAND




Dare to mark your territory

Unleash the full potential of your Sauvignon blanc



Sauvy is a wine yeast perfect for Sauvignon blanc and other aromatically intense white wines. Sauvy was selected for its exceptional ability to reveal volatile thiols, most notably 4MMP, leading to overexpression of gooseberry, grassy, and passion fruit aromas.



Find Sauvy on page 30.



INACTIVATED YEAST


GLUTASTAR™

GET SUPREME HIGH POWER

THE KING OF NATURAL ANTIOXIDANTS

Glutastar is a yeast derivative nutrient that protects and stabilizes wine aroma and color due to its unique content of antioxidant peptides and high concentration

of GSH (reduced glutathione). Glutastar's high antioxidant and scavenging of free radicals leads to increased wine shelf life. Glutastar also increases the perception of freshness and mouthfeel thanks to the contribution from yeast-derived polysaccharides.



Find Glutastar on page 51.



NON-SACCHAROMYCES
YEAST

LAKTIA™ Give back freshness to your wines



Laktia is a natural alternative for acidification. Laktia is a pure culture of *Lachancea thermotolerans* used to produce high levels of lactic acid during fermentation. Laktia gives winemakers new possibilities to naturally acidify wine during fermentation.



Find Laktia on page 35.



YEAST

EXOTICS NOVELLO

ICONIC, FRESH AND FRUITY WINES

Exotics Novello is a new all-purpose yeast strain that enhances aromatic expression in white and red wines. This strain is an inter-species hybrid between Saccharomyces cerevisiae and Saccharomyces cariocanus.



Find Exotics Novello on page 23.



MALOLACTIC BACTERIA

SOLO SELECT

SECURITY AND STRUCTURE

Anchor Solo Select is a malolactic bacteria selected for its ability to perform MLF under a wide range of conditions. This robust culture can enhance complexity and structure as well as dark fruit and spicy characteristics.



Find Solo Select on page 59.

BENTONITE

€ ERBSLÖH

GranuBent PORE-TEC

GranuBent PORE-TEC is a new-to-us sodium-based bentonite for the removal of heat unstable proteins. Like all Erbslöh bentonites, GranuBent PORE-TEC is highly purified. Its production using PORE-TEC technology makes it virtually dust free and easy-to-use. GranuBent PORE-TEC joins our other specialty bentonites—BlancoBent UF, compatible with cross-flow filtration, and FermoBent PORTE-TEC, used during fermentation—from the Erbslöh family of products. *Find GranuBent on page 97.*




FERMENTATION OAK CHIPS



BALANCE & STRUCTURE

Minimize herbaceousness while amplifying fruit aromatics with feelwood! BALANCE & STRUCTURE fermentation oak chips. These oak chips are a mix of untoasted, light, and medium toasted French oak.

Find out more on page 75.



FERMENTATION OAK CHIPS



SWEET & FRESH

Enhance fruit, add mid-palate sweetness, while increasing length and finish with feelwood! SWEET & FRESH fermentation oak chips. These oak chips are untoasted 100% French oak.



Find out more on page 75.



VINEYARD PRODUCTS

looking for less chemical inputs in the vineyard, and high expectations of grape quality all while maintaining crop yields. Innovative vineyard strategies are needed to help growers meet these and future challenges.

Modern winegrowers face many challenges including Lallemand has developed several innovative products for increasing climatic uncertainty, demands from consumers use in the vineyard. The LalVigne® products, derived from inactivated yeast, offer winegrowers novel tools to promote sustainable viticulture while maintaining and protecting grape quality and yields. LalVigne is the outcome of Lallemand's deep knowledge of microbial technology and rigorous research with respected viticultural institutions.

LALVIGNE® IS A VINEYARD TOOL TO IMPROVE WINE QUALITY

- ♦ Advances phenolic maturity
- ◆ Increases uniformity in ripening
- ◆ Reduces herbaceous and green flavors (pyrazines)
- ◆ Protects volatile aromas and enhances mouthfeel

SELECTING LALVIGNE FOR SUCCESS

Each vineyard will differ in its potential to provide quality grapes and yield depending on many factors. In order to successfully choose and apply the best LalVigne product it's important to understand the vineyard location, the stage of growth of the vines, the vintage conditions, and the grape variety.

VINEYARD LOCATION

In cooler climates phenolic maturity can be difficult to reach. Due to the onset of rain and early frosts the harvest date may be determined by external factors and not by grape maturity. In warm climates optimal sugar levels are often reached before phenolic maturity. Application of LalVigne minimizes the sugar/maturity gap and allows winemakers the opportunity to make picking decisions based on flavor.

VINE GROWTH PHASE

LalVigne is applied at the beginning of veraison. Maximum benefit of a LalVigne treatment is when the first spray is applied at 5% veraison and the second application is 10 - 12 days later. If the window of veraison is missed, there is still some benefit in applying LalVigne (see chart on Page 8).

VINTAGE CONDITIONS

Drought, rainfall, temperature and light variations are dominant conditions affecting the vintage. These variations impact vine growth rates, vigor, yield and fruit composition. Berry size, tannins, flavor, color, aroma and Brix are all uniquely affected by each years vintage conditions.

GRAPE VARIETY

LalVigne can reduce green and herbaceous flavor when applied to grape varieties high in pyrazines (Cabernet Sauvignon, Cabernet Franc, and Merlot). When using LalVigne on white grape varieties there is an increase in compounds that help stabilize volatile aromas. With highly aromatic varities such as Sauvignon blanc, Muscat, and Riesling LalVigne can increase varietal aromas.

LALVIGNE® AROMA + LALVIGNE LA **LalVigne

Yeast-based foliar spray for enhancing varietal expression White grape varieties

#17501	3 kg LalVigne Aroma*	\$110.00
#17500	3 kg LalVigne LA*	\$110.00

Use of LalVigne® Aroma will improve both grape and wine quality. In grapes an increase in berry skin thickness gives added protection against rot. Increases in glutathione prevent degradation of aromatic compounds making them more stable for ageing. In aromatic grape varieties there is an increase of the 3MH aromatic precursors which can convert to 3MHA, increasing the thiol aromatic compounds in varieties such as Sauvignon blanc. Mouthfeel components are enhanced and green and vegetal flavors are diminished. Minimal impact on berry weight, Brix, pH or total acidity.

Recommended Dosage

1 treatment = 2 applications = \$88.00/acre

1 application = 2.7 lb/acre/1.2 kgs/acre

LALVIGNE® MATURE + LALVIGNE LM **LalVigne*

Yeast-based foliar spray for phenolic maturity and uniform ripening Red grape varieties

#17511	1 kg LalVigne Mature*	\$94.00
#17510	1 kg LalVigne LM*	\$94.00

Use of LalVigne® Mature advances phenolic maturity and evens the ripening process. Increases in berry skin thickness give added protection against rot. Thicker skins also allow for better extractability of anthocyanins (color) as well as improved structure. LalVigne Mature reduces herbaceous and green characters with a positive impact on mouthfeel. Minimal impact on berry weight, Brix, pH or total acidity.

Recommended Dosage

1 treatment = 2 applications = \$76/acre

1 application =	0.9 lb/acre/405 g per acre
1 application -	0.7 10/acre/+03 g per acre

Application Recommendation


LalVigne® is applied with a standard vineyard sprayer on the leaves at the beginning of veraison. Maximum benefit of a LalVigne treatment is when the first application is applied at 5% veraison with a second application 10 - 12 days later. If 5% veraison is missed there is still some benefit in applying LalVigne. See chart below for guidance on applying LalVigne at different stages of veraison.

%Veraison at First Application:

Timing of Second Application

5% (ideal)	12-14 days after first application
5-30%	10-12 days after first application (+/- 2 days)
30-50%	7 days after the first application
50-70%	7 days after the first application if 100% veraison is not reached
70%	Not reccommended

HOW DOES LALVIGNE WORK?



LalVigne is an inactivated yeast product that is sprayed as a foliar spray on the grapevines twice during early veraison. The plant receptors in the leaves recognize the yeast as a possible pathogen, which activates the plant's secondary metabolism. The production of secondary metabolites includes anthocyanins, tannins and other phenolic compounds, resulting in uniform ripening and better quality of grapes and the resulting wine.

*LalVigne Aroma® and LalVigne Mature® are registered in the following states: AL, AK, AZ, CT, DE, FL, GA, HI, IL, IN, IA, KS, KY, LA, MD, MA, MI, MO, MT, NE, NV, NH, NJ, NY, NC, OR, RI, TN, UT, VT, VA, WA, WY

LalVigne LA and LalVigne LM are registered in the following states: CA, CO, ME, MN, MS, NM, OH, PA, SC, TX, WI The following states have no registered use: ID, ND, OK, SD, WV

YEAST

Since our founding in 1933 as the Berkeley Yeast Laboratory, yeast has been at the heart of our portfolio. Our first commercial yeasts were provided on slants and came from the yeast collection housed at the University of California, Berkeley during prohibition. Growing yeast from slants poses microbial challenges for winemakers so we started providing yeast in an active dried form. For many years we produced and dried our strains at a large brewery, but in 1974 we partnered with Lallemand who began to produce our wine strains in addition to their baking strains. This partnership launched Lallemand

into wine yeast production. Lallemand continues to isolate and bring new wine yeast strains to winemakers worldwide and they remain the most respected wine yeast producer in the world.

Today's wine yeast strains are well characterized and improvements have been made in their strength, purity and reliability. A near century of wine yeast cultivation makes Scott Laboratories and our yeast partners uniquely positioned to assist winemakers with yeast to meet the demands of today's winemaking.

SELECTING YEAST FOR SUCCESS

Harvested grape lots can differ from vintage to vintage and from block to block even within the same vineyard. There is no such thing as "standard" fruit chemistry and you can improve your yeast selection success by knowing the fermentable sugar, yeast assimilable nitrogen (YAN), and physical condition for every lot of fruit. Knowing the pH, titratable acidity (TA), malic acid and potassium concentration for each lot is also helpful for your entire winemaking plan.

We suggest selecting yeast based first on its technical compatibility with grape and winery conditions and secondly on its sensory contribution and compatibility with the desired wine style. For assistance see yeast strain selection charts on pages 11-16. As a reminder:

FERMENTABLE SUGAR Yeast strains vary in their ability to tolerate ethanol levels. The initial sugar content will help determine the final ethanol content. Initial sugar content may be determined by gravity (usually reported as °Brix) or by direct measurments of sugar.

Yeast strains vary in their need for yeast assimilable nitrogen (YAN). Our strains

YAN

are classified as low, medium or high nitrogen-demanding strains. The amount of nitrogen a yeast will need is dependent upon its individual needs, the initial sugar level and the temperature of the fermentation.

TEMPERATURE

Yeast strains vary in their temperature tolerance. Do not stress the yeast by fermenting at the upper or lower end of the recommended range. Temperature management is a key factor of yeast health, fermentation rate and security. Temperature should be measured directly under the cap in red must/wine and good cap management is required to ensure homogenous temperatures. When working with high sugar fermentations, lower temperatures are recommended.

FRUIT CONDITION

Yeast strain choice can be optimized for unsound or spoiled fruit. Yeast strains that have a short lag phase, are low volatile acidity (VA) producers, and are positive/ neutral for competitive factor, will be quick to outcompete microbial spoilers, won't contribute to VA, and won't be sensitive to microbial attack. If the fruit was treated with high SO, to combat spoilage, consider using a no to low H₂S-producing strain.

WHY SHOULD YOU ADD 25 g/hL* OF YEAST?

Lower
potential for
osmotic shock

Shorter lag phase

Fast onset of fermentation

Shorter fermentation length

Lower final VA

Lower final residual sugar Healthier cell population

HOW TO MAKE GOOD YEAST BETTER

QTL PROCESS: BREEDING YEAST THAT DO NOT PRODUCE SULFIDES OR SULFUR DIOXIDE

Selective breeding is used to improve the traits of enological strains of Saccharomyces cerevisiae. At the genetic level, traits may be controlled by a single/small group of genes or by a large group of genes.

Yeast traits that are controlled by a single or small group of genes have been the traditional target of selective breeding. When two yeast strains, each with different traits controlled by one or a few genes, are bred together, daughter yeast are easily screened to find the correct combination of traits.

Some yeast traits are genetically complex and traditional selective breeding and screening methods are an ineffective tool to target these traits. For example, if we breed two strains of wine yeast, one that produces low levels of H₂S and another that produces low levels of SO₂, it is very difficult to identify

the daugher yeast that is both a low H₂S and low SO₂ producer. This is because these traits are controlled and influenced by a large group of genes.

Quantitative Trait Loci (QTL) is a new technique that allows us to pinpoint the location of all genes involved in complex yeast traits. Now when we selectively breed yeast we can quickly screen daughter strains for the desired trait. Combining QTL mapping with selective breeding has allowed Lallemand to produce a line of no to very low H,S, SO,, and acetaldehyde producing strains. This is a non-GMO technique and all QTL process strains are naturally bred. Look for the QTL logo in the yeast descriptions.





YSEO PROCESS: YEAST PREPARATION IMPROVES PERFORMANCE AND SENSORY QUALITY

Did you know that the way in which a yeast is produced can have a major impact on wine quality?

In the early 2000s, Lallemand began developing a new yeast preparation technique. The Yeast SEcurity and SEnsory Optimization process (YSEO) optimizes nutrient additions during cell growth and the results are impressive.

The chart shows that yeast produced using the YSEO process produce less volatile acidity (VA) in a variety of wine types. In each fermentation the same veast strain was used in identical conditions. The only difference was that one was fermented with yeast produced with the YSEO process and the other with the YSEO can make a good yeast even better. traditional yeast production process.

Other trials have shown that the YSEO process can enhance strain performance in other ways including reduced lag phase, faster fermentation times, decreased H₂S production, better adaption to stressful conditions and reduced malolactic fermentation antagonism.

YSEO IS A UNIQUE AND INNOVATIVE PROCESS FOR YEAST DEVELOPED BY LALLEMAND.

The benefits of the YSEO process are:

Better adaption to stressful Reduced lag phase Optimized fermentation Reduced potential for VA conditions

Production of Volatile Acidity in Yeast Produced with and without the YSEO Process

	Yeast without YSEO (g/L acetic acid)	Yeast with YSEO (g/L acetic acid)
Italy (Montepulciano)	0.29	0.18
INRA (Sauvignon)	0.51	0.42
INRA (Sauvignon)	0.31	0.13
WSU (Riesling)	0.44	0.31
WSU (Syrah)	0.23	0.21
WSU (Cabernet Sauvignon)	0.58	0.38

Adapted from the article, Evaluation of the YSEO Process to Prepare Dried Winemaking Yeast by Sibylle Krieger¹, Anne Ortiz-Julien¹, Francoise Raginel¹, Ann Dumont¹, Forbes Wardrop¹, Charles G. Edwards²

² Department of Food Science and Human Nutrition, Washington State University, Pullman, WA, U.S.A.



^{*} If sugar is greater than 25 °Brix you should increase your inoculation rate to at least 30g/hL (2.5 lb/1000 gal). Increasing dosage of yeast may help prevent a sluggish or stuck fermentation.

¹ Lallemand, 1620, rue Prefontaine, Montreal, QC Canada

YEAST STRAINS FOR WHITE & ROSÉ WINE

YEA	TC	<u> </u>	1 L	(A)	$T\Gamma$	O	7	75	(<u>1 V'</u>	11	T	J 0	7 7	\mathbf{C}	1C'	<u>ነ V</u>	<u>'V 1</u>	$T\overline{I}$	L_
O Yeast Strain Type ◆ Highly Recommended O Recommended M Mouthfeel EVC Enhanced Varietal Character Mod Moderate Ntrl Neutral Snstv Sensitive Avg Average	43/43 RESTART	58W3	718	Alchemy I	Alchemy II	Assmanshausen (AMH)	BA11	BM 4x4	BRG	CEG (Epernay II)	Cross Evolution	CVW5	CY3079	DV10	EC1118	Elixir	Exotics Mosaic	Exotics Novello	Fermivin Champion	ICV D21
Page#	17	17	17	18	18	19	19	20	20	20	21	21	22	22	22	22	23	23	24	24
S. cerevisiae cerevisiae		0	0				0		0	0			0							0
S. cerevisiae bayanus	0											0		0	0				0	
Yeast hybrid/other						0					0					0	0	0		
Yeast blend				0	0			0												
Alcohol Tolerance ¹	17%	14%	14%	15.5%	15.5%	15%	16%	16%	15%	13.5%	15%	15%	15%	17%	18%	15%	15.5%	15.5%	18%	16%
Relative Nitrogen ²	Low	Med	Low	Med	Med	Med	High	High	High	Med	Low	Low	High	Low	Low	Med	Med	Med	Med	Med
Temp. Range (°F) ³	55-95	54-77	59-85	56-61	56-61	68-86	59-77	64-82	64-88	59-77	58-68	57-82	59-77	50-95	50-86	57-77	64-83	62-82	59-86	61-86
Fermentation Speed	Fast	Mod	Mod	Fast	Fast	Slow	Mod	Mod	Fast	Slow	Mod	Fast	Mod	Fast	Fast	Slow	Mod	Mod	Mod	Mod
Competitive Factor	Yes	Ntrl	Snstv	Yes	Yes	Snstv	Snstv	Yes	Ntrl	Snstv	Yes	Yes	Snstv	Yes	Yes	Snstv	Yes	Yes	Ntrl	Yes
Sensory Effect	Ntrl	EVC Esters M	Esters	EVC Esters	EVC Esters	EVC	Esters M	EVC M	EVC	Esters	EVC M	Esters	EVC M	Ntrl	Ntrl	EVC Esters	EVC M	EVC M	Ntrl	EVC M
MLF Compatibility	Good	Avg	Very Good	Good	Good	Very Good	Below Avg	Below Avg	Avg	Not Known	Avg	Avg	Good	Good	Avg	Avg	Very Good	Good	Good	Avg
Albariño					٥			0			٨	٨					٨	٠		
Chardonnay				٨				٨	٥		٨	٨	٨	٨		٨	•			٨
Chenin blanc				٨	٨							٨					•			
Gewürztraminer		•		<u>.</u>		٥	٨				٨			٨						
Muscat				<u>.</u>			٥		<u>.</u>	٨	٨	٨		٥				٨		
Pinot blanc							٠				٨		٨	٨						
Pinot gris		٨	٨	٨								٨		٨		٥				
Riesling		٨	٨	٥		٨	٠				٨									
Sauvignon blanc				٥	٨		٠	٥			٨					٨				
Viognier		٨		٥			٨									۵	٨			
Rosé			•				•			•	•	•				٨				٥
Rhône Whites		•		٨	٨		٨	δ		<u>.</u>	•					٨	•			
Aromatic Whites		•		٨			٨			<u>.</u>	٨	٨				٨		٨		
Late Harvest	•			<u>.</u>	<u>:</u>	<u>.</u>			:	<u></u>				٥	٥		:			
Sparkling Base				<u></u>			٥		<u> </u>	<u></u>		•		•	٨		:			<u>.</u>
Restart Stuck	•													٨	٥				•	

^{1.} The alcohol tolerance column indicates performance possibilities in good circumstances and conditions. Alcohol tolerance may vary as circumstances and to the other strains on this chart. See article on page 45. conditions vary.

YEAST STRAINS FOR WHITE & ROSÉ WINE

<i>,</i>	U.	т т,	<u> </u>	TTA		T /	$\mathcal{I}_{\mathbf{I}}$		ν т.	ΙΙ.	ш		<u>- T</u>		\mathcal{L}	<u> </u>	<u>у</u> т.	T A T	
ICV D47	ICV D254	ICV GRE	ICV OKAY	ICV Opale 2.0	IOC Be Fruits	IOC Be Thiols	K1 (V1116)	M83	MSB	NT 116	QA23	R2	Rhône 4600	R-HST	Sauvy	Sensy	VIN 13	VIN 2000	W15
24	25	25	25	26	26	26	27	27	27	28	28	29	29	30	30	30	31	32	32
0	0	0					0	0	-	- - - - - - - - - - - - - - - - - - -			0	0	0				0
									0		0	0							
			0	0	0	0				0						0	0	0	
15%	16%	15%	16%	14%	14%	15%	18%	15%	14.5%	16%	16%	16%	15%	15%	14%	15%	17%	15.5%	16%
Low	Med	Med	Low	Low	Low	Med	Med	Med	Med	Med	Low	High	Low	Med	Med	Low	Low	Low	High
60-82	54-82	59-82	54-86	59-86	54-75	59-77	50-95	63-82	57-68	54-61	59-90	50-86	56-72	50-86	57-68	54-64	54-61	55-61	50-81
Mod	Mod	Mod	Mod	Mod	Mod	Fast	Fast	Mod	Mod	Fast	Fast	Mod	Mod	Mod	Mod	Mod	Fast	Mod	Mod
Yes	Ntrl	Yes	Yes	Yes	Yes	Yes	Yes	Ntrl	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
EVC M	EVC M	EVC M	Esters	EVC Esters	EVC Esters	EVC	Esters	EVC	EVC M	EVC E	EVC	Esters	Esters	EVC M	EVC	EVC M	EVC Esters	EVC Esters	EVC M
Good	Very Good	Very Good	Very Good	Good	Good	Good	Poor	Avg	Not Known	Good	Very Good	Good	Good	Avg	Not Known	Very Good	Good	Good	Very Good
٥					٨						٨						٨	٨	
٨	٨			٨	<u>:</u>						٨		٨				٨	٨	
	<u>.</u>	٨					٨		٨	٨							٨	٨	
٥						٥					٨	٨		٨					٨
											٥						۵		
		<u></u>									٨					٨			
	<u>.</u>	<u>.</u>	<u>i</u>		<u> </u>							٥	٥	<u>.</u>					٨
		٨	<u>.</u>		<u>.</u>	٥					٥	٨	<u>.</u>	٨					٨
	<u>.</u>		<u>.</u>	٨		ه		<u>:</u>	٨	٨	ه	ه	٥	ه	٨	٨	ه	•	
٥	<u>.</u>	<u>.</u>	•					:		-	٥	٥	•	•				•	
•	٥	•	•	٠	•	•	<u>:</u>	•		<u>.</u>			•	٥		•	•	٥	•
•	•	٨		•				: 	-	-			•	٨			٨		٨
ļ	<u>.</u>	<u></u>	<u></u>			<u></u>	<u></u>				•	•		•	•		•		•
<u></u>		<u></u>	:				٨			•	<u> </u>	<u>.</u>							
ļ	<u>.</u>		<u>.</u>		<u>.</u>	<u>.</u>	<u>.</u>	<u>:</u>	<u>.</u>	: :			<u></u>				<u>.</u>	:	<u>.</u>
			8				٥				8				1		δ		
	24	24 25	24 25 25 O O O 15% 16% 15% Low Med Med 60-82 54-82 59-82 Mod Mod Mod Yes Ntrl Yes EVC M EVC M EVC M Good Good Good ♦ ♦ ♦ ♦ ♦ ♦	24 25 25 25 O O O O 15% 16% 15% 16% Low Med Med Low 60-82 54-82 59-82 54-86 Mod Mod Mod Mod Yes Ntrl Yes Yes EVC M EVC M EVC M Esters Good Cood Cood Cood △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △ △	24 25 25 25 26 O O O O O O 15% 16% 15% 16% 14% Low Med Med Low Low 60-82 54-82 59-82 54-86 59-86 Mod Mod Mod Mod Mod Yes Ntrl Yes Yes Yes EVC M EVC M Esters EVC geod Good Sood Yes Yes Yes Yes Wery Good Good Good Good Good Sood A A A A A A A A A A A A A A A A A A A	24 25 25 26 26 ○ ○ ○ ○ ○ ○ 15% 16% 15% 16% 14% 14% Low Med Med Low Low Low Low 60-82 54-82 59-82 54-86 59-86 54-75 Mod Mod Mod Mod Mod Mod Yes Ntrl Yes Yes Yes Yes EVC M EVC M Esters EVC C Esters EVC C Esters EVC C Esters Good Good Good Good Good Good ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ ♦ <td>24 25 25 25 26 26 26 ○</td> <td>24 25 25 25 26 26 26 27 O O O O O O O O 15% 16% 15% 16% 14% 14% 15% 18% Low Med Med Low Low Low Med Med 60-82 54-82 59-82 54-86 59-86 54-75 59-77 50-95 Mod Mod Mod Mod Mod Fast Fast Yes Ntrl Yes Yes Yes Yes Yes EVC M EVC M Esters EVC Esters EVC Esters Good Good Good Good Good Good Food A A A A A A A A A A A A A A A A A A A A A</td> <td> The color of the</td> <td>24 25 25 25 26 26 26 26 27 27 27 O <</td> <td>24 25 25 25 26 26 26 27 27 27 28 O <</td> <td> 24</td>	24 25 25 25 26 26 26 ○	24 25 25 25 26 26 26 27 O O O O O O O O 15% 16% 15% 16% 14% 14% 15% 18% Low Med Med Low Low Low Med Med 60-82 54-82 59-82 54-86 59-86 54-75 59-77 50-95 Mod Mod Mod Mod Mod Fast Fast Yes Ntrl Yes Yes Yes Yes Yes EVC M EVC M Esters EVC Esters EVC Esters Good Good Good Good Good Good Food A A A A A A A A A A A A A A A A A A A A A	The color of the	24 25 25 25 26 26 26 26 27 27 27 O <	24 25 25 25 26 26 26 27 27 27 28 O <	24	24	24	24	24	24	24	24

^{3.} The temperature column indicates general performance possibilities. It is not a substitute for sound winemaking. Yeast may be stressed or die if temperatures are sustained at extremes of their tolerance. Keep in mind that a yeast's ability to ferment within the given range also depends on alcohol and other antagonistic conditions.

Important Notes

This chart is only useful as a quick reference guide. For more information on selected yeast strains, please refer to the yeast section of this handbook.

Red Wine Yeast Strains *continue on next page* →

	ΥI	ΞA	SТ	S	ТБ	? A	IN	S	FC	R	RF	ZD	W	ΊŅ	JE			
O Yeast Strain Type ♦ Highly Recommended ◇ Recommended M Mouthfeel EVC Enhanced Varietal Character Mod Moderate Ntrl Neutral Snstv Sensitive Avg Average	43	43 RESTART	3001	718	Alchemy III	Alchemy IV	Assmanshausen (AMH)	BDX	BM 4X4	BRG	BRL97	CLOS	CSM	CVRP	Exotics Mosaic	Exotics Novello	Fermivin Champion	Fermivin MT48
Page#	17	17	18	17	18	19	19	19	20	20	20	21	21	21	23	23	24	24
S. cerevisiae cerevisiae			0	0				0		0	0	0	0	0				0
S. cerevisiae bayanus	0	0				<u>.</u>				<u>.</u>							0	<u>.</u>
Yeast hybrid/other							0								0	0		
Yeast blend					0	0			0									
Alcohol Tolerance ¹	17%	17%	15%	14%	15.5%	15.5%	15%	16%	16%	15%	16%	17%	14%	16%	15.5%	15.5%	18%	15%
Relative Nitrogen ²	Low	Low	Med	Low	Med	Med	Med	Med	High	High	Med	Med	Med	Med	Med	Med	Med	Low
Temp. Range (°F) ³	55-95	55-95	54-90	59-85	61-82	61-82	68-86	64-86	64-82	64-88	62-85	57-90	59-90	64-86	64-83	62-82	59-86	68-86
Fermentation Speed	Fast	Fast	Mod	Mod	Fast	Fast	Slow	Mod	Mod	Fast	Mod	Fast	Mod	Mod	Mod	Mod	Mod	Mod
Competitive Factor	Yes	Yes	Yes	Snstv	Yes	Yes	Snstv	Snstv	Yes	Ntrl	Yes	Yes	Yes	Yes	Yes	Yes	Ntrl	Ntrl
Sensory Effect	Ntrl	Ntrl	EVC	Esters	EVC	EVC	EVC	EVC M	EVC M	EVC M	EVC	EVC M	EVC	EVC M	EVC M	EVC M	Ntrl	М
MLF Compatibility	Good	Good	Avg	Very Good	Good	Good	Very Good	Avg	Below Avg	Avg	Avg	Very Good	Avg	Very Good	Very Good	Good	Good	Good
Barbera								٥	٥		٠	٨						
Cabernet Franc						٥					٥		٠	٥				
Cabernet Sauvignon					٨			٥	٠		٥		٨	٥				
Grenache				٠	٠				٠		٥	٨			٠			٨
Malbec					٠						٠	٨						
Merlot								٨	٥		٠		٠	٠	٠			٨
Petite Sirah							٠		٨			٠		٠				
Pinot noir			٠		٥	٥	٨			٥	٠							
Petit Verdot					٠		:	٨			٠	٥	٥	<u>+</u>	٠		·	٨
Sangiovese	•					٨			٠									٨
Syrah	•					٨		٨	٥		٥	٨			٨			
Tempranillo					٨					<u>.</u>		٨		٨	٨			٨
Zinfandel	٨				٨	·	٨	٨	٨	<u> </u>	٨	٨		<u> </u>				
Fruit Forward Reds				٨		٨									٨	٨		•
Structured Reds					٨			٨	٨			٨						
•••••	+					-						.	<u>.</u>	1			.	.

^{1.} The alcohol tolerance column indicates performance possibilities in good circumstances and conditions. Alcohol tolerance may vary as circumstances and conditions vary.

2. Relative nitrogen needs refer to how much nitrogen one strain requires relative to the other strains on this chart. See article on page 45.

YEAST STRAINS FOR RED WINE

		ΔA	Ω T	_ <u>U</u>	T L	Δ	TTJ	<u>U</u> .	<u> </u>	M	$\overline{1/1}$	ענ		<u> </u>	<u> </u>			
O Yeast Strain Type ◆ Highly Recommended O Recommended M Mouthfeel EVC Enhanced Varietal Character Mod Moderate Ntrl Neutral Snstv Sensitive Avg Average	ICV D21	ICV D80	ICV D254	ICV GRE	ICV OKAY	lonys _{wF}	MT	NT 116	NT 202	Persy	RC212	Rhône 2226	RP15	Syrah	173	Tango Malbec	VRB	W15
Page#	24	25	25	25	25	26	27	28	28	28	29	29	30	31	31	31	32	32
S. cerevisiae cerevisiae	0	0	0	0		0	0				0	0	0	0		0	0	0
S. cerevisiae bayanus	<u>.</u>														0			
Yeast hybrid/other	<u>.</u>				0			0	0	0								
Yeast blend																		
Alcohol Tolerance ¹	16%	16%	16%	15%	16%	16%	15%	16%	16%	16%	16%	18%	17%	16%	16%	16%	17%	16%
Relative Nitrogen ²	Med	High	Med	Med	Low	High	Med	Med	Med	Low	Med	Med	Med	Med	Low	Med	Med	High
Temp. Range (°F) ³	61-86	59-82	54-82	59-82	54-86	77-82	59-90	76-83	60-82	59-82	60-86	59-82	68-86	59-90	65-90	59-82	59-82	50-81
Fermentation Speed	Mod	Mod	Mod	Mod	Mod	Mod	Mod	Fast	Fast	Mod	Mod	Fast	Mod	Mod	Mod	Mod	Mod	Mod
Competitive Factor	Yes	Yes	Ntrl	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Ntrl	Yes	Yes	Yes	Yes	Ntrl	Ntrl	Yes
Sensory Effect	EVC M	EVC M	EVC M	EVC M	Esters	М	EVC M	EVC	EVC Esters	EVC M	EVC	EVC M	EVC	EVC	Esters M	EVC	EVC M	EVC M
MLF Compatibility	Avg	Avg	Very Good	Very Good	Very Good	Good	Avg	Good	Very Good	Very Good	Good	Below Avg	Avg	Avg	Below Avg	Good	Good	Very Good
Barbera	٥	٥	٥	٥								٠					٨	
Cabernet Franc	٥	٥	٥	٠			٥		٥		٥	٥	٥		٥			
Cabernet Sauvignon	٨	٨	٨	٨		٥	٨	٨	٠		٠	٥	٨					
Grenache	٥		٥	٨							٨	٥		٥			٥	
Malbec			٠			٠			٠				٨			٨		
Merlot	٨	٨	٥	٠		٠	٨		٨			٠	٠	٨	٨	٥		
Petite Sirah		٨			٠	٠				٨		٠	٠	٠		٥	٨	
Pinot noir				٥					٠	٠	٨							٨
Petit Verdot	٥		٨			٥	٨	٠					٨	٥				
Sangiovese	٥		٨	٥		٥						٠		٥	٥		٨	
Syrah	٨	٨	٨	٨	٨	٥				٨			٨	٨		٨		٨
Tempranillo	٥	٥	٥	٥		•	٥			٨			•		٥	٨	٨	•
Zinfandel	٨	٨	٠	<u>.</u>					٥			٨	٨		٨		٨	
Fruit Forward Reds				٨			<u> </u>							1	٨		٨	•
Structured Reds	•	٨		<u></u>	<u></u>	<u>.</u>	•	<u> </u>	•			٨	•	٨				
Restart Stuck							<u> </u>	<u> </u>	٥	<u>.</u>		٥						•

^{3.} The temperature column indicates general performance possibilities. It is not a substitute for sound winemaking. Yeast may be stressed or die if temperatures are sustained at extremes of their tolerance. Keep in mind that a yeast's ability to ferment within the given range also depends on alcohol and other antagonistic conditions.

This chart is only useful as a quick reference guide. For more information on selected yeast strains, please refer to the yeast section of this handbook.

Restart Stuck

YEAST STRAINS FOR AMERICAN & HYBRID WHITE CULTIVARS

TEAST STRAIL	NOL	\mathcal{I}		M	$\mathbf{I} \mathbf{V} \mathbf{X}$, ,,,,,,,	1117	COL	$I \perp I \setminus VI$	IIO
O Yeast Strain Type ♦ Highly Recommended O Recommended M Mouthfeel EVC Enhanced Varietal Character Mod Moderate Ntrl Neutral Snstv Sensitive Avg Average	58W3	718	Alchemy I	CVW5	CY3079	Elixir	Exotics Mosaic	ICV Opale 2.0	QA23	Sauvy	VIN 13	VIN 2000
Page#	17	17	18	21	22	22	23	26	28	30	31	32
S. cerevisiae cerevisiae	0	0			0					0		
S. cerevisiae bayanus				0					0			
Yeast hybrid/other						0	0	0			0	0
Yeast blend			0									
Alcohol Tolerance ¹	14%	14%	15.5%	15%	15%	15%	15.5%	14%	16%	14%	17%	15.5%
Relative Nitrogen ²	Med	Low	Med	Low	High	Med	Med	Low	Low	Med	Low	Low
Temp. Range (°F) ³	54-77	59-85	56-61	57-82	59-77	57-77	64-83	59-86	59-90	57-68	54-61	55-61
Fermentation Speed	Mod	Mod	Fast	Fast	Mod	Slow	Mod	Mod	Fast	Mod	Fast	Mod
Competitive Factor	Ntrl	Snstv	Yes	Yes	Snstv	Snstv	Yes	Yes	Yes	Yes	Yes	Yes
Sensory Effect	EVC Esters M	Esters	EVC Esters	Esters	EVC M	EVC Esters	EVC M	EVC Esters	EVC	EVC	EVC Esters	EVC Esters
MLF Compatibility	Average	Very Good	Good	Average	Good	Average	Very Good	Good	Very Good	Not Known	Good	Good
Reduces malic acid content		٨					٠	٨				
Aromella	٥		٥			٥			•		٥	
Blanc du Bois				٠		٥			٨	٠	٨	٨
Chardonel			٠	٨	٠			٨	٠		٨	٨
Frontenac blanc			•			٥			•		٥	٥
Frontenac gris	٥	١		٥			٥	٨	•	•		
ltasca		٨		٥					•		٠	٥
La Crescent	•	٨	٠			٥	٨		٥	٥	٨	
Muscadine	٥			٥					٥		٨	
Rosé		٨		٥		٥	٨	•			٨	٨
Seyval blanc			٥			٨			•	٨		٥
Traminette	•		٨			٥	٠		٥	٠	٨	
Vidal blanc			٥	٥		٥		٥				٨
Vignoles	•		٠			•		٥	•		•	

^{1.} The alcohol tolerance column indicates performance possibilities in good circumstances and conditions. Alcohol tolerance may vary as circumstances and to the other strains on this chart. See article on page 45. conditions vary.

HYBRID AND NON-VINIFERA WINES

Most native American grape cultivars tend to have strong fruit flavors and aromas as compared to European cultivars. This is especially true of rotundifolia (Muscadine) and labrusca varieties. The combination of strong fruit and high acid is often balanced by creating wines with residual sugar.

French-American hybrid varieties are crosses between Vitis

vinifera and one or more American varieties. As a result of the breeding it is possible to create cultivars that have aromas and flavors that are more or less reminiscent of their European ancestors. In addition to viticultural practices, wine style can be influenced by the yeast strain. Yeast can enhance flavors and aromas, mouthfeel and varietal expression. If the yeast

YEAST STRAINS FOR AMERICAN & HYBRID RED CULTIVARS

O Yeast Strain Type ♦ Highly Recommended ◇ Recommended M Mouthfeel EVC Enhanced Varietal Character Mod Moderate Ntrl Neutral Snstv Sensitive Avg Average	3001	718	Alchemy III	Alchemy IV	BM 4X4	BRL 97	2010	CSM	ICV D254	Exotics Mosaic	Persy	NT 202	RC212
Page#	18	17	18	19	20	20	21	21	25	23	28	28	29
S. cerevisiae cerevisiae	0	0				0	0	0	0				0
S. cerevisiae bayanus													
Yeast hybrid/other										0	0	0	
Yeast blend			0	0	0								
Alcohol Tolerance ¹	15%	14%	15.5%	15.5%	16%	16%	17%	14%	15.5%	16%	16%	16%	16%
Relative Nitrogen ²	Med	Low	Med	Med	High	Med	Med	Med	Med	Med	Med	Low	Med
Temp. Range (°F) ³	54-90	59-85	61-82	61-82	64-82	62-85	57-90	59-90	64-83	54-82	60-82	59-82	60-86
Fermentation Speed	Mod	Mod	Fast	Fast	Mod	Mod	Fast	Mod	Mod	Mod	Fast	Mod	Mod
Competitive Factor	Yes	Snstv	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Ntrl	Yes	Yes	Ntrl
Sensory Effect	EVC	Esters	EVC	EVC	EVC M	EVC	EVC M	EVC	EVC M	EVC M	EVC Esters	EVC M	EVC
MLF Compatibility	Average	Very Good	Good	Good	Below Average	Average	Very Good	Average	Very Good	Very Good	Very Good	Very Good	Good
Diminishes vegetal characters		٠		٨	•			٠			٨		
Promotes color stability					٠	٠							
Reduces malic acid content		٠								٠			
Black Spanish					٠		٨						
Chambourcin	•			٨	٨	٥	٨	٨	•		٨	٠	•
Crimson Pearl			٥	٠					•				•
Frontenac		٨		٨	٨			٨		٠	٠	٠	•
Maréchal Foch	•		•			•				•	•	٥	•
Marquette	•		•		٨		٨	٠	•	٠	٠		٥
Noiret			•	٥		٨	٨			٥	٠	٠	•
Norton	٥		•	٥		•	٨		•	•		٠	•••••••••••••••••••••••••••••••••••••••
Petite Pearl		٨	٥	٨			٥		•			٥	•
St. Croix			•		:	**************************************	٥	٥				٠	

^{3.} The temperature column indicates general performance possibilities. It is not a substitute for sound winemaking. Yeast may be stressed or die if temperatures are sustained at extremes of their tolerance. Keep in mind that a yeast's ability to ferment within the given range also depends on alcohol and other antagonistic conditions.

This chart is only useful as a quick reference guide. For more information on selected yeast strains, please refer to the yeast section of this handbook.

HYBRID AND NON-VINIFERA WINES (CONTINUED)

can convert flavorless thiol precursors into aromatic elements or produce enzymes that cleave glycosidic bonds and release aromatic terpenes into the wine, then varietal characteristics are enhanced. Yeast can also produce high levels of polysaccharides which can increase mouthfeel, balance harshness and acidity (within reason) and add to the colloidal stability of the wine.

In the last few years, new strains of yeast have shown promise with hybrids and native American varieties. These strains are listed in the chart above.

16

^{2.} Relative nitrogen needs refer to how much nitrogen one strain requires relative

YEAST STRAIN DESCRIPTIONS

43 CALLEMAND YSEO

Fructophilic yeast for high sugar or traditional restart

Zinfandel, Sangiovese, Syrah, Late Harvest

#15134	500 g	\$46.00
#15140	10 kg	\$560.00

Uvaferm 43™ is a Saccharomyces cerevisiae bayanus strain that gives high-quality sensory results in high Brix red fermentations and helps maintain color, red fruit and cherry characteristics.

Isolated by Lallemand in collaboration with the research center of Inter-Rhône in France.

Alcohol Tolerance: 17%		Temp. Range: 55-95°F
	43 RESTART @	EMAND YSEO

Preacclimated fructophilic yeast for restarting stuck fermentations Restart Stuck Fermentations, Late Harvest

#15223	500 g	\$55.00
#15240	10 kg	\$672.00

Uvaferm 43 RESTARTTM is the result of an innovative preacclimation process developed by Lallemand using Uvaferm 43, a strain isolated by Lallemand in collaboration with Inter-Rhône in France.

- 43 RESTART's resistance to stressful conditions of stuck fermentations has been naturally enhanced. Acclimation includes addition of micronutrients, sterols and polyunsaturated fatty acids to strengthen 43 RESTART cell membranes. Yeast cells are more robust, acclimate quicker and have a lower mortality rate after inoculation.
- 43 RESTART is sensory neutral and malolactic bacteria compatible.

For best results use the 43 RESTART protocol for stuck wines. See page 38 for protocol which includes Reskue™ and Fermaid O™ and best practices.

Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 17%	LOW	55-95°F

58W3 (ALLEMAND YSEO) Spicy and fruity aromatic white wines

Pinot gris, Gewürztraminer, Riesling, Viognier, Rhône Whites, **Aromatic Whites**

	500 g	\$49.00
#15/21	10 kg	\$592.00

Vitilevure 58W3™ contributes an overall well-balanced mouthfeel with spicy, floral and fruity aromas.

Allows for the release of bound terpenes in aromatic varieties due to the strain's beta-glucosidase activity. This enhances classic varietal characters.

Due to 58W3's fermentation kinetics, especially in high sugar juices, a balanced nutrient strategy and good fermentation practices should be followed.

This strain was isolated during a five-year study by the INRA (National Agricultural Research Institute) in Alsace, France.

Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 14%	MEDIUM	54-77°F
	71D (AHEMAN)	

Softens high malic acid grapes

Pinot gris, Riesling, Grenache, Rosé, Fruit Forward Reds

#15059	500 g	\$32.00
#15078	101	\$415.00

Lalvin 71BTM is known for fermenting fruity rosé wines and semi-sweet whites. It sythesizes relatively stable esters and higher alcohols resulting in long-lived aromas. Respects rosé

Softens high acid musts by partially metabolizing malic acid.

Sensitive to competitive factors and may have difficulty competing with wild microflora. Careful rehydration with Go-Ferm Protect Evolution™ and early inoculation will help 71B dominate in competitive conditions.

This strain was isolated and selected by the INRA (National Agricultural Research Institute) in Narbonne, France.

••••	:	: ······
Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 14%	LOW	59-85°F



#15682 \$49.00 500 g

Vitilevure 3001™ is recommended for use with cold soak protocols to produce intense Pinot noir wines with aging potential. Wines made with 3001 are noted for fruit and varietal characters that are both elegant and complex.

This strain was isolated, studied and selected from the prestigious Côte de Nuits terroir in Burgundy during a threeyear research project by Laboratory Burgundia Oenologie in Beaune, France. The goal of this selection program was to find a dominant yeast strain from a traditional cold soak that would enhance the varietal character, intensity, and balance of Pinot noir.

Tolerant of standard SO₂ additions and low temperatures for a steady and reliable alcoholic fermentation following cold soak.

Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 15%	MEDIUM	54-90°F
	• • • • • • • • • • • • • • • • • • • •	• • • • •

ALCHEMY I

Blend of yeast strains for fruity and floral esters

Sauvignon blanc, Chardonnay, Chenin blanc, Riesling, Pinot gris, Rhône Whites, Aromatic Whites

\$105.00

Alchemy I is a blend of Saccharomyces cerevisiae wine yeast strains developed in collaboration with the Australian Wine Research Institute (AWRI) in South Australia.

The ratio of the yeast in the blend has been formulated to provide an optimal aromatic profile. Alchemy I enhances fruity and floral esters and volatile thiols (boxwood, passion fruit, grapefruit and guava aromas).

Alchemy I is a strong aroma producer with fast fermentation kinetics and low foam production.

Barrel fermentation is not recommended and temperature control is advised.

		.
Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 15.5%	MEDIUM	56-61°F



Blend of yeast strains for expressing volatile thiols

Albariño, Sauvignon blanc, Chenin blanc, Rhône Whites


15177 \$105.00

Alchemy II is a blend of Saccharomyces cerevisiae wine yeast strains developed in collaboration with the AWRI in South Australia for optimal aromatic profile.

Alchemy II enhances volatile thiols such as boxwood, passion fruit, grapefruit, kiwifruit and guava aromas. It is highly recommended for cool tank fermentations of Sauvignon blanc (New Zealand, South African or Chilean style).

Under difficult conditions (pH<3.2, turbidity under 80 NTU, low YAN, temperatures below 15°C(59°F), Alchemy II can be stressed and will produce VA.

Alchemy II is a low SO₂ producer with fast fermentation kinetics. Temperature management is crucial.



Blend of yeast strains for complex structured reds

Cabernet Sauvignon, Malbec, Zinfandel, Tempranillo, Grenache, Petit Verdot, Structured Reds

> #15230 \$105.00 1 kg

Alchemy III is a blend of Saccharomyces cerevisiae wine yeast strains developed in collaboration with the AWRI in South Australia.

Alchemy III is a very high producer of 2-phenylethanol (rose), 2-phenylethyl acetate (floral and fruity), ß-ionone (raspberry) and acetate esters (fruity and candy).

It produces complex wines with good structure and body and is suitable for all red varietals.

Alchemy III is a strong fermenter, producing minimal SO₂ and high levels of glycerol (8-11 g/L).

······································		: ·········
Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 15.5%	MEDIUM	61-82°F
• • • • • • • • • • • • • • • • • • • •		<u>:</u>

20

ALCHEMY IV

Blend of yeast strains for intensely fruity reds

Pinot noir, Syrah, Cabernet Franc, Sangiovese, Fruit Forward Reds

1 kg \$105.00

Alchemy IV is a blend of Saccharomyces cerevisiae wine yeast strains developed in collaboration with the AWRI in South Australia.

Formulated for the production of intense red fruit characters such as cherry, red currant, raspberry and pomegranate. The high production of ethyl esters, especially ethyl hexanoate (fruity) contributes to the longevity of the fruit aromas.

Alchemicy IV can diminish herbaceous, vegetal, and unripe flavors and elevate terpenes while producing smooth, round wines with heightened aroma intensity.

Alchemy IV is a strong fermenter, produces minimal SO₂, and high levels of glycerol (8-11 g/L).

Alcohol Tolerance: 15.5%		Temp. Range: 61–82°F	
ASSMANSHAUSEN (AMH)			

Allows for the expression of indigenous microflora

Pinot noir, Zinfandel, Riesling, Petite Sirah, Gewürztraminer

#15632	500 g	\$49.00
#15622	10 kg	\$592.00

Enoferm AMH™ has a long lag phase with a slow to medium fermentation rate. A well-managed nutrient program during rehydration and fermentation is essential.

Enhances spicy (clove, nutmeg) and fruit flavors and aromas while adding overall complexity.

Fermentation potential is enhanced with AMH if the culture is allowed to develop in about 10% of the total must volume for eight hours prior to final inoculation.

AMH is a Saccharomyces kudriavzevii strain originating from the Geisenheim Research Institute in Germany.

Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 15%	MEDIUM	68-86°F
• • • • • • • • • • • • • • • • • • • •	• • • • • • • • • • • • • • • • • • • •	• • • • • • • • • • • • • • • • • • • •

BA11 (ALLEMAND YSEO)

Strong fermenter for white wine mouthfeel

Riesling, Viognier, Sauvignon blanc, Pinot blanc, Gewürztraminer, Rosé, Muscat, Rhône Whites, Aromatic Whites

Lalvin BA11™ promotes clean aromatic characteristics and intensifies mouthfeel and persistent flavors in white or sparkling

BA11 can enhance fresh aromas of tropical fruit, cream, vanilla and spice in relatively neutral white grape varieties.

This S. cerevisiae cerevisiae strain was selected in 1997 near the Estação Vitivinicola de Barraida in Portugal.

Alcohol Tolerance: 16%	O	Temp. Range: 59-77°F	
RDX (ALLEMAND YSEO			
Stoady fo	rmenter for Bordeaux vo	· 7mm	

Merlot, Cabernet Sauvignon, Zinfandel, Petit Verdot, Structured Reds

#15634	500 g	\$49.00
#15635	10 kg	\$592.00

Uvaferm BDXTM is a reliable fermenter for high quality red wines and allows for the expression of varietal character.

This strain does not generate a lot of heat during fermentation. Optimizes color and structure with soft tannin extraction and increased mouthfeel.

Selected from the Institut Pasteur strain collection in Paris,

Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 16%	MEDIUM	64-86°F



Mouthfeel and color stability for extended fermentations

Sangiovese, Cabernet Sauvignon, Grenache, Zinfandel, Chardonnay, Structured Reds


#15176	500 g	\$55.00
#15200	10 kg	\$655.00

Lalvin BM 4X4™ is a blend of Lalvin BM45™ (see scottlab.com for more information) and another yeast known for fermentation reliability. The BM4X4 blend was formulated to provide the aromatic complexity of BM45 while providing greater reliability under difficult fermentation conditions.

In Italian red varietals sensory descriptors include jam, floral and cherry liqueurs, sweet spice, licorice, cedar and earthy elements.

Produces high levels of polyphenol-reactive polysaccharides, resulting in wines with increased mouthfeel and improved color stability in reds. In whites, BM 4X4 releases high levels of esters responsible for fruit aromas.

Poor malolactic fermentation compatibility.



Levuline BRG™ is the reference strain for Burgundian winemakers. Increases minerality in whites such as Chardonnay and spice characters in reds like Pinot noir.

BRG is a fast fermenter. Ability to produce significant amounts of polysaccharides during fermentation leading to enhanced mouthfeel and body.

This strain was isolated in Burgundy at the IUVV (Institut Universitaire de la Vigne et du Vin) laboratory in Dijon, France.

Tolerance: 15% HIGH 64-88°F	Alcohol	Nitrogen Needs:	•
	Tolerance: 15%	HIGH	64-88°F





Enhanced color stability and structure in color sensitive varietals

Pinot noir, Zinfandel, Barbera, Merlot, Malbec, Petit Verdot

#15102	500 g	\$46.00
#15205	10 lra	¢560.00

Lalvin BRL97™ respects varietal characteristics and helps retain color in grapes sensitive to color loss.

Fast starter and a moderate speed fermenter. Demonstrates good malolactic fermentation compatibility and high alco-

This strain was isolated at the University of Torino in Italy from a Nebbiolo fermentation.

To enhance complexity, BRL97 fermented wine may be blended with wines fermented with RC212[™] or W15[™].

Alcohol Tolerance: 16%	Nitrogen Need MEDIUM	s: Temp. Range: 62-85°F
	•••••	• • • • • • •
	CEG (EPERNAY I	(I) LALLEMAND
Sweet ar	nd semi-sweet wine p	production
	White, Rosé	
#15081	500 g	\$25.00

Uvaferm® CEG was isolated by the Geisenheim Research Institute in Germany.

Notable for its ability to deliver slow, steady and clean fermentations. Optimal fermentation temperatures range from 15-25°C(59-77°F).

CEG fermentations often slow or stop under stressed conditions leaving residual sugar. This makes CEG advantageous for use in semi-dry white or rosé wines.

Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 13.5%	MEDIUM	59-77°F

Ultra-premium reds

Syrah, Grenache, Tempranillo, Zinfandel, Petite Sirah, Barbera, Petit Verdot, Structured Reds, Malbec

#15201	500 g	\$46.00
#15204	10 kg	\$560.00

Lalvin CLOS $^{\text{TM}}$ was selected for its ability to enhance aromatic complexity, structure and mouthfeel.

Notable for its high alcohol tolerance (up to 17% v/v) and good implantation in difficult conditions. Good compatibility with malolactic bacteria.

Spain from the Priorat region.

Alcohol Tolerance: 17%	Nitrogen Needs: MEDIUM	Temp. Range: 57-90°F
•••••	•••••	•••••

CROSS EVOLUTION (ALLEMAND)

Natural yeast hybrid to enhance aromatics and mouthfee

Chardonnay, Gewürztraminer, Pinot blanc, Riesling, Sauvignon blanc, Rosé, Rhône Whites, Muscat, Albariño, Aromatic Whites

#15640	500 g	\$49.00
#15641	101.	\$592.00

Cross Evolution™ is a strong fermenter and ideal for aromatic white and rosé wines that have a high alcohol potential. This strain complements an increased mouthfeel style resulting in aromatic wines that are balanced.

Increases fresh fruit and floral aromas in whites and rosés.

This hybrid yeast is from a unique breeding program at the Institute for Wine Biotechnology at the University of Stellenbosch in South Africa.

Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 15%	LOW	58-68°F



Minimizes herbaceous characters in under-ripe fruit

Cabernet Sauvignon, Cabernet Franc, Merlot, Petit Verdot

#15638	500 g	549 . 00
#15639	10 kg	Ø502.00

Wines fermented with Enoferm CSMTM have shown intense aromas of berries, spice and licorice.

CSM has been known to reduce vegetal aromas and add complexity with a balanced, round mouthfeel.

CSM is malolactic friendly and was selected by the Institut Français de la Vigne et du Vin (IFV, formerly ITV) in Bor-This strain was isolated by the University of Rovira i Virgili in deaux in cooperation with Conseil Interprofessionnel du Vin de Bordeaux (CIVB-Bordeaux).

Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 14%	MEDIUM	59–90°F
CVRP CALLEMAND		

High polysaccharide producer for roundness in reds

Cabernet Franc, Cabernet Sauvignon, Merlot, Petite Sirah, Tempranillo

#15207	500 g	\$46.00
#15208	10 120	\$560.00

Ideal for big reds, CVRP™ is one of the highest polysaccharide producers in the Lallemand yeast collection.

CVRP enhances mouthfeel, roundness, soft tannins and elevated varietal character. Good compatibility with malolactic bacteria.

Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 16%	MEDIUM	64-90°F
CVW5 (ALEMAN)		

Production of stable esters in whites

Chardonnay, Chenin blanc, Pinot gris, Rosé, Sparkling Base, Albariño, Muscat, Aromatic Whites, Fruit Wine

#15237		\$46.00
#15210	10 kg	\$560.00

CVW5™ is a high producer of fruity aromas (esters) and low producer of volatile acidity and SO₂.

CVW5 has the lowest nitrogen demand of the Lallemand yeast strains. Strong fermenter even under difficult conditions, including low turbidity.

This S. cerevisiae bayanus strain was selected from the Lallemand yeast collection and is a daughter strain of Lalvin EC1118™ (see pg 22).

• • • • • • • • • • • • • • • • • • • •	• • • • • • • • • • • • • • • • • • • •	• • • • • • • • • • • • • • • • • • • •
Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 15%	LOW	57-82°F



Classic strain for barrel-fermented whites

Chardonnay, Pinot blanc

#15061	: 500 g	\$46.00
#15082	101	\$560.00

Lalvin CY3079 (Bourgoblanc)™ is highly recommended for Lalvin EC1118™ is the original, steady, low-foamer yeast strain. barrel-fermented and sur lie aged Chardonnay.

Autolyzes quickly at the end of fermentation resulting in wines with roundness. Enhances aromas of fresh butter, almond, honey, flowers and pineapple.

CY3079 is a steady, average fermenter even at cooler temperatures (15°C/59°F). This strain demonstrates good alcohol tolerance and low production of volatile acidity and H₂S when nutrient requirements are met.

This strain was isolated for its ability to complement typical white Burgundy whites by the Bureau Interprofessional des Vins de Bourgogne (BIVB) in France.

Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 15%	HIGH	59–77°F
· · · • • • ·	DV10 CALLEMAND	• • • • •

Strong fermenter for crisp, clean wines

Chardonnay, Sparkling Base, Gewürztraminer, Pinot gris, Late Harvest, Pinot blanc, Restart Stuck Fermentations

#15062	500 g	\$46.00
#15106	10 kg	\$560.00

Lalvin DV10™ is well known for clean fermentations that respect varietal character while avoiding bitter sensory contributions associated with other, more one-dimensional, 'workhorse' strains such as Prise de Mousse.

Strong fermentation kinetics. Recognized for low foaming, low VA production and very low H₂S and SO₂ production. Saccharomyces cerevisiae bayanus strain from Epernay, France.

·········		•
Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 17%	LOW	50-95°F

EC1118 (PRISE DE MOUSSE) Original sparkling wine strain Sparkling Base Wines #15053 500 g \$29.00

\$413.00

This Saccharomyces cerevisiae bayanus strain was selected by the IOC in Epernay, France and is the reference strain for sparkling base wine. It is an excellent choice for secondary fer-


10 kg

#15076

mentations of sparkling wine.

.

Ferments well at low temperatures and flocculates with compact lees. Under low nutrient conditions EC1118 can produce high amounts of SO₂ (up to 50 ppm) and, as a result, may inhibit malolactic fermentation.



Vitilevure ElixirTM expresses terpenes, thiols, and floral and fruity aromas (from fatty-acid esters), adding complexity to aromatic varieties.

Good implantation in clarified juice. Strain requires good nutrition and proper temperature control. It is a low SO₂, H₂S and volatile acidity producer.

Elixir is a hybrid yeast cross resulting from the yeast hybridization program at the Institute for Wine Biotechnology at the University of Stellenbosch in South Africa.

Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 15%	MEDIUM	57-77°F

•••••





Freshness and mouthfeel for mature and concentrated reds and whites

#15143	500 g	\$46.00
#15163	10 kg	\$560.00

FERMIVIN CHAMPION

Fructophilic yeast for restarting stuck ferments

Restart Stuck Fermentations

10 kg

Fermivin® Champion has an excellent capacity to metabolize

fructose, making it a good choice for restarting stuck fermenta-

Fermivin Champion can be added as a preventative measure

towards the end of high (initial) Brix fermentations with no

Fermivin Champion helps preserve the varietal character of

the must/juice when restarting a stuck fermentation. Does not

This Saccharomyces cerevisiae bayanus strain was selected in

Nitrogen Needs:

MEDIUM

Fruity and spicy reds

Merlot, Sangiovese, Grenache, Tempranillo, Petit Verdot,

Fruit Forward Reds

Fermivin® MT48 enhances aromatic notes of cherry, raspber-

ry, blackberry, plum and spices in Bordeaux varieties. Produces excellent results in Sangiovese, Grenache and Tempranillo.

Fermivin MT48 has a short to medium lag phase, rapid and

steady kinetics and low volatile acidity production. Produces

Fermivin MT48 was selected in Bordeaux by the IFV (formerly

Nitrogen Needs:

LOW

ITV) France in collaboration with CIVB-Bordeaux.

FERMIVIN MT48

tions when the glucose-to-fructose ratio isn't favorable.

pre-acclimatization if the ethanol is <10% (v/v).

\$30.00

\$420.00

Temp. Range:

59-86°F

\$46.00

Temp. Range:

68-86°F

#17143

#17145

produce secondary aromas.

#17106

high glycerol.

Alcohol

Tolerance: 15%

Alcohol

Tolerance: 18%

Alsace by INRA of Narbonne, France.

stable color, intense fore-mouth volume, mid-palate tannin structure and fresh aftertaste. Contributes both higher acidity perception and positive polyphenol-reactive polysaccharides leading to a more stable aromatic profile in the mouth.

Lalvin ICV D21TM was selected for fermenting red wines with

Strain can be used with ripe white grapes that are barrel fermented to develop fresh fruit aromas, volume and perceived acidity.

Noted for its good fermentation performance and low sulfide production. In highly clarified juices, maintain fermentation temperatures above 16°C(61°F) and supplement with proper nutrition.

ICV D21 was isolated from one of the best Languedoc terroirs during a special regional program run by the Institut Coopératif du Vin's (ICV) Natural Micro-Flora Observatory and Conservatory in France.

Alcohol Tolerance: 16%	0	Temp. Range: 61-82°F
	••••••	• • • •
	ICV D47	YSEO
Complex whit	es with citrus and floral	expression
Cl	I	

#13042	300 g	φτοισσ
#15643	10 kg	\$560.00

duces wines known for accentuated fruit and volume.

ICV D47 is known for the production of full-bodied, barrelfermented Chardonnay and other white varietals. Excellent

		•
Alcohol	Relative Nitrogen:	Temp. Range:
Tolerance: 15%	LOW	60-82°F

24

EXOTICS MOSAIC

All-purpose hybrid yeast for fruity wines with mouthfeel

Chardonnay, Viognier, Chenin blanc, Syrah, Merlot, Tempranillo, Grenache

#15213	250 g	\$40.00
#15220	5 kg	\$696.00

Produces white wines with guava, passion fruit, tropical and stone fruit aromas and flavors as well as good mouthfeel. In red wines Exotics Mosaic has shown aromas of cherry, floral, cocoa and strawberries. Reds are described as full-bodied, well-balanced, complex and intense.

Steady fermenter but sensitive to cold temperatures. Can produce elevated levels of glycerol (9-13 g/L) which potentially leads to lower alcohol. Low volatile acidity and SO₂ production. Strain can partially degrade malic acid and is known to facilitate and enhance malolactic fermentation.

Exotics Mosaic is a hybrid of Saccharomyces cerevisiae and S. paradoxus developed at the Institute for Wine Biotechnology at the University of Stellenbosch in South Africa.

Storage: $5-15^{\circ}C(41-59^{\circ}F)$

Alcohol Nitrogen Needs: Temp. Range: 64-83°F Tolerance: 15.5% MEDIUM NEW **EXOTICS NOVELLO** All purpose hybrid yeast for aromatic expression and mouthfeel Sauvignon blanc, Viognier, Aromatic Whites, Merlot, Syrah, Fruity Reds #15271 \$40.00

Developed by Anchor Oenology in collaboration with the Australian Wine Research Institute (AWRI), Exotics Novello is a Saccharomyces hybrid having the sensory characteristics of S. cariocanus and the fermentation security of S. cerevisiae.

Exotics Novello has some pectinase activity. Known for being a thiol revealer and an ester producer in both white and red wines. Reveals fresh fruit and floral esters while decreasing astringency and bitterness in whites. Increases red and black fruits and spice while diminishing green and vegetal characters in reds. Wines produced with Exotics Novello are known for improved mouthfeel and softness.

It produces low levels of VA and H₂S.


Storage: 5-15°C(41-59°F)

		•
Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 15.5%	MEDIUM	62-82°F
		1

STAFF PICK

"The yeast strain that I most often recommend is Exotics Mosaic. I fell in love with it while using it on hybrid grapes 10 years ago. It has the magical ability to both add body and reduce acidity which helps soften the mouthfeel in high-acid varietals. This strain is cold-sensitive which is a benefit when someone is looking to arrest fermentation to balance the wine with some residual sugar. I love that it can be used successfully in both reds and whites. I find that Exotics Mosaic enhances varietal character without being over-the-top and mimics the aromatic complexity that is desired from spontaneous ferments without the inherent risk of spontaneous ferments. I'm really excited to start working with more yeast strains coming out of the Exotics line from Anchor." -Katie Cook, Sales Representative based in Upstate New York

Exotics Novello Impact on Esters & Thiols in Sauvignon blanc




EXOTICS NOVELLO: A NEW HYBRID YEAST FOR NEW WORLD RED AND WHITE WINEMAKING

Hybrid yeast can occur in nature when organisms are present in the same ecological niche. By definition, a hybrid is an organism that contains genomic DNA from two or more hereditarily distinct parents.

Exotics Novello is an interspecies hybrid of Saccharomyces cerevisiae and Saccharomyces cariocanus developed by Anchor Oenology in collaboration with the Australian Wine Research Institute. S. cariocanus is closely related to S. cerevisiae and produces an interesting array of aromas and flavors. However, S. cariocanus is not a strong fermenter. Exotics Novello combines the novel sensory profile of S. cariocanus with the strong fermentation kinetics of *S. cerevisiae*.

This new strain produces wines that are fruit forward and focused and has the ability to reveal thiols and synthesize esters (see chart above). Exotics Novello can also produce red wines that have elevated red and black fruits and spicy nuances. This specific hybrid can produce polysaccharides that impart a softness to the wine, as well as displaying pectinase activity that can assist with clarification.



Chardonnay, Rosé, Rhône Whites

#15642	500 g	\$46.00
#15643	10 kg	\$560.00

Lalvin ICV D47™ is a high polysaccharide producer and pro-

for blending with wines made with Lalvin ICV D21™.

Short lag phase followed by a regular fermentation. Will tolerate a fermentation temperature range of 15-28°C(59-82°F), however a temperature range of 15-20°C(59-68°F) is preferential. This isolate is from Suze-la-Rousse in the Côtes du Rhône in France.

•••••	: ·······	
Alcohol	Relative Nitrogen:	Temp. Range:
Tolerance: 15%	LOW	60-82°F

ICV D80 (ALLEMAND Enhances tannin structure in reds


Cabernet Sauvignon, Merlot, Syrah, Zinfandel, Petite Sirah, Structured Reds

#15125	500 g	\$46.00
#15133	10 kg	ØE (0.00

Lalvin ICV D80™ is a rapid starter with a moderate fermentation rate. Produces wines with high fore-mouth volume, big mid-palate mouthfeel and intense fine-grain tannins in reds.

Complements big tannin volume, ripe fruit, and licorice style reds. Selected for its ability to bring out varietal aromas by reinforcing the rich concentrated flavors found in varieties such as Zinfandel and Svrah. Excellent for blending with wines fermented with LALVIN ICV D254TM.

This strain was isolated by the Institut Coopératif du Vin (ICV) in 1992 from the Côte Rôtie area of the Rhône Valley in France.



ICV D254 (ALLEMAND YSE) Mouthfeel and balance in reds and whites

Verdot, Malbec, Rhône Whites

Cabernet Sauvignon, Syrah, Zinfandel, Sangiovese, Chardonnay, Petit

	•	•
#15094	500 g	\$46.00
#15021	10 kg	\$560.00

In red wines, Lalvin ICV D254™ develops ripe fruit, jam and Lalvin ICV OKAY™ is recommended for fresh and aromatic cedar aromas together with mild spiciness.

On the palate it contributes high fore-mouth volume, big midpalate mouthfeel and intense fruit concentration.

When used for white wines (particularly Chardonnay), sensory descriptors include butterscotch, hazelnut and almond aromas. This strain was isolated by the Institut Coopératif du Vin (ICV) from a Rhône Valley Syrah fermentation.

Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 16%	MEDIUM	54-82°F



Fruit forward reds with minimal skin contact

Cabernet Franc, Grenache, Cabernet Sauvignon, Merlot, Syrah, Chenin blanc, Riesling, Rosé, Rhône Whites, Fruit Forward Reds

#15101	500 g	\$46. 00
#15142	10 kg	\$560.00

In reds, Lalvin ICV GRETM complements up-front fruit for easy-to-drink Rhône-style wines. With short skin contact (three to five days), ICV GRE reduces vegetal and undesirable sulfur components in varieties like Merlot, Cabernet Sauvignon, Grenache and Syrah.

In fruit-focused whites, such as Chenin blanc, Riesling and Rhône whites, ICV GRE fermentations result in stable, fresh fruit characteristics such as melon and apricot while improving fore-mouth impact.

ICV GRE is a rapid starter, with good alcohol tolerance and low volatile acidity production.

Alcohol	Nitrogen Needs:	Temp. Range:	
Tolerance: 15%	MEDIUM	59–82°F	

Strong fermenter for sulfur management and fruity esters Petit Sirah, Rosé, Syrah, Viognier

ICV OKAY (ALLEMAND YSEO)

		•
#15221	500 g	\$30.00
#15222	10 kg	\$441.00

red, white or rosé wines with fruit intensity.

Very short lag phase with steady fermentation kinetics. Low foam production.

ICV OKAY has very good synergy with malolactic bacteria.

This S. cerevisiae hybrid was selected in collaboration with the INRA, SupAgro Montpellier, the ICV and Lallemand for very low to no SO₂, H₂S, and acetaldehyde production.

		• • • • • • • • • • • • • • • • • • • •
Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 16%	LOW	54-86°F



Lalvin ICV Opale 2.0™ enhances varietal character and aromatics in high-maturity/high Brix grapes that might otherwise produce neutral wines. Complements intense and complex fruit aromas in premium white and rosé wines.

ICV Opale 2.0 has excellent fermentation qualities with a short lag phase. Very low to no SO₂, H₂S, and acetaldehyde production

Alcohol Tolerance: 14%	Nitrogen Needs: LOW	Temp. Range 59-86°F
Low H.5 and So: producer	IOC BE FRUITS on and fruity esters for v	DC whites and rosés
Sulful Muliageme	Albariño, Rosé	villes and roses
#15241	500 g	\$46.00

IOC Be Fruits[™] produces fruity esters (strawberry, pineapple, citrus notes) in white and rosé wines without masking varietal aromas. Fruit expression is emphasized due to the yeast's very low to no sulfite and acetaldehyde production.

Optimal conditions for fruity ester production are achieved when must/juice is clarified (80 NTU \pm 20) and fermentation temperatures are between 12-15°C(54-59°F).


Be Fruits[™] has a short lag phase and low volatile acidity production. This hybrid yeast strain was selected by INRA for very low to no SO₂ or H₂S production.



IOC Be Thiols™ reveals fruity thiols (citrus and exotic fruits) in white and rosé wines. It enhances 3MH potential (grapefruit, passion fruit) without excessive green flavors. The purity of the fruity expression is heightened by this strain's inability to produce negative sulfur compounds that can mask aromas.

Optimal conditions for expressing fruity thiols occur when must/juice is clarified (80 NTU ± 20), pH >3.2, and fermentation temperatures are between 15–20°C(59–68°F).

Be Thiols is a fast fermenter with a short lag phase. This hybrid yeast strain was selected by INRA for very low to no SO2 or H₂S production.



#15233 \$55.00

IONYS_{WF}TM is a selected wine yeast that naturally increases the acidity of wines feremented from low acid musts.

IONYS_{WE} is recommended for fermenting reds from warmer climates with high pH and high potential alcohol. The acidification 'power' of IONYS_{WE} may result in a titratable acidity increase of 0.4-1.4 g/L (tartaric acid) and a pH decrease of between 0.04-0.2. With proper nutrition and temperature control, wines made with IONYS_{WE} are characterized as having fresh fruit and mineral characters and fine-grain tannins.


Low producer of volatile acidity, SO₂ and H₂S, with an alcohol tolerance of up to 16% (v/v). Maintaining a temperature range of 25–28°C(77–82°F) optimizes glycerol production (up to 15 g/L) and may decrease alcohol production by 0.4-0.8% (v/v).

Moderate fermentation speed with a long, but steady stationary phase. IONYS_{WE} has very high nitrogen requirements and a balanced nutrient protocol is essential.

Storage: $4^{\circ}C(39^{\circ}F)$.

Note: IONYS_{WE} is an innovative yeast selection and is protected by an International Patent pending; No WO2015/11411. Propagation of IONYS_{WE} is an infringement of this Patent.

Acidifying Effects of lonyswe



26

K1 (V1116) (ALLEMAND

Strong fermenter for ester production and challenging conditions

Restart Stuck Fermentations, Sauvignon blanc, Chenin blanc, Sparkling Base

#15063	500 g	\$28.00
#15077	10 kg	\$270.00

Lalvin K1 (V1116)™ is one of the highest ester producing strains in our portfolio. When fermented at low temperatures (16°C/61°F) with proper nutrition, it is a strong floral ester producer, especially in neutral or high-yielding varieties.

K1 (V1116) performs well in difficult conditions such as extreme temperatures, high alcohol (18% v/v) and low turbidity and is useful in restarting stuck fermentations, especially when relative fructose levels remain high.

Alcohol Tolerance: 18%	Nitrogen N LOW		Temp. Range: 50-95°F
	•••••••	• • • • •	• • • • •
	M83	LALLEMAND	
	Provence style	rosés	
	Rosé		
#15674	500 g	:	\$49.00

Vitilevure M83™ increases color stability in rosé as a result of its polysaccharide production. Produces round and balanced rosés with enhanced fresh fruit aromas.

M83 is particularly well adapted for rosé winemaking in warmer regions. It has good implantation, strong fermentation kinetics, and low volatile acidity and SO₂ production.

This strain was selected by the Laboratoire Aubanelle in the Bandol appellation of Provence.

Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 15%	MEDIUM	63-82°F

NEW < MSB (ALLEMAND YSEO)

Enhances Sauvignon blanc varietal characters

Sauvignon blanc, Colombard


#15267 \$46.00

Lalvin MSB^{TM} is a yeast strain isolated from the Marlborough Valley in New Zealand by the Lallemand R&D team.

This strain enhances fruity, tropical and citrus notes, while maintaining a balanced mouthfeel. Maintains the natural acidity of grapes due to negligible malic acid uptake.

To optimize thiols, use in conjunction with our yeast nutrient, Stimula Sauvignon Blanc™ (see pg 47 for more information).

Effect of Stimula Sauvignon Blanc™ on Thiol Production in a Wine Fermented with Lalvin MSB™



High maturity, long-aging Bordeaux varieties

Merlot, Cabernet Sauvignon, Petit Verdot, Structured Reds

#15650	500 g	\$49.00
#15651	10 kg	\$592.00


Vitilevure MTTM is recommended for grapes with high maturity and long aging potential.

Known for producing aromas of strawberry and caramel, especially in Merlot. MT fermented wines have good color intensity and tannin structure.

Has steady fermentation kinetics. This strain benefits from a balanced nutrient strategy. When good fermentation practices are followed MT produces minimal volatile acidity and H₂S.

MT was selected in Saint Emilion, France, by the IFV (formerly ITV) Bordeaux in collaboration with the INRA Montpellier.

• • • • • • • • • • • • • • • • • • • •	• • • • • • • • • • • • • • • • • • • •	•
Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 15%	MEDIUM	59-90°F
	•	•



All-purpose strain for new world style whites and reds

Syrah, Cabernet Sauvignon, Merlot, Petite Sirah, Pinot gris, Aromatic Whites

#15185	1 kg	\$94.00
#15226	10 kg	\$672.00

NT 116 is equally suited for both white and red winemaking. Its ability to reveal volatile thiols and produce esters makes it suitable for aromatic white wine production. Wines are crisp and fresh with citrus and zesty aromas. Also suitable for fullbodied, high maturity red wines destined for oak aging.

Temperature control is advised when using this low foaming but vigorous strain.

This hybrid strain of S. cerevisiae is a product of the yeast hybridization program of Infruitec-Nietvoorbij, the wine and vine institute of the Agricultural Research Council in Stellenbosch, South Africa.

Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 16%	MEDIUM	54-83°F
• • • • • • • • • • • • • • • • • • • •		

NT 202 Structured and complex reds

Cabernet Sauvignon, Pinot noir, Merlot, Malbec, Structured Reds

#15191	1 kg	\$94.00
#15227	10 kg	\$672.00

NT 202 is an aromatic red wine yeast that promotes blackcurrant, blackberry and plum-like flavors.

This strain has a stimulatory effect on malolactic fermentation and good fructose utilization. Fermentation temperature should be monitored to control the speed. Not suitable for cold soaking.

This low foaming, hybrid strain of *S. cerevisiae* is a product of the yeast hybridization program of Infruitec-Nietvoorbij, the wine and vine institute of the Agricultural Research Council in Stellenbosch, South Africa.

	Nitrogen Needs:	
Tolerance: 16%	MEDIUM	64-82°F







Sulfur management and mouthfeel in red wines

Rhône reds, Pinot noir, Tempranillo or other varietals susceptible to hydrogen sulfide production

#15261	500 g	\$46.00
#15262	10 kg	\$560.00

Red wines fermented with Lalvin $Persy^{TM}$ have a balanced mouthfeel with fruit forward persistent aromas and flavors optimizing varietal expression.

Using good fermentation practices, Persy produces very low to no H₂S, SO₂, or volatile acidity and is compatible with malolactic bacteria.

This hybrid yeast strain was developed for use in red wines produced from varietals naturally susceptible to H₂S. It was developed in collaboration with INRA, SupAgro Montpellier and Lallemand.



Strong fermenter for varietal expression in highly clarified musts

Chardonnay, Sauvignon blanc, Gewürztraminer, Pinot blanc, Albariño, Muscat, Aromatic Whites

#15652	500 g	\$49.00
#15653	10 kg	\$592.00

Lalvin QA23[™] is an excellent thiol converter making it a complementary yeast for developing varietal Sauvignon blanc passion fruit character.

Large amounts of the enzyme beta-glucosidase are produced during growth which allows for the release of bound terpenes in aromatic varieties.

QA23 has low nutrient and oxygen requirements and will ferment juice with low turbidity at low temperatures to dryness.

This strain was selected in Portugal by the University of Trásos-Montes and Alto Douro (UTAD) in cooperation with the Viticultural Commission of the Vinho Verde region.

Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 16%	LOW	59-90°F
the state of the s	777	•

Expression of varietal aromas at cold temperatures

Riesling, Sauvignon blanc, Gewürztraminer, Late Harvest, Aromatic Whites

#15071 500 g \$46.00

Lalvin $R2^{TM}$ can enhance varietal characters due to the enzymatic release of aroma precursors producing intense, direct fruit-style whites with heightened fruity and floral aromas.

Has excellent cold temperature properties and has been known to ferment in conditions as low as $5^{\circ}C(41^{\circ}F)$. Tends to produce VA without proper nutrition.

This *Saccharomyces cerevisiae bayanus* strain was isolated in the Sauternes region of Bordeaux, France, by Brian Croser of South Australia.

Alcohol Tolerance: 16%	Nitrogen Needs: HIGH	Temp. Range 50-86°F
	12 (BOURGOROU	GE) (ALLEMAND
	tructure and color for	•
Pir	not noir, Grenache, Ro	sé
#15057	500 g	\$46.00
#15097	10 kg	\$560.00

Lalvin RC212 (Bourgorouge) $^{\text{TM}}$ is known for its ability to generate ripe berry, bright fruit and spicy characteristics and to consistently produce Pinot noir with good tannin structure.

RC212 requires thoughtful nutrient additions to avoid potential sulfide production.

Wines fermented with RC212 can be blended with wines fermented with Enoferm AMH $^{\text{TM}}$, Lalvin W15 $^{\text{TM}}$ or Lalvin BRL97 $^{\text{TM}}$ to achieve more complexity.

This *S. cerevisiae cerevisiae* strain was selected from fermentations in Burgundy, France, by the BIVB.

	Nitrogen Needs:	Temp. Range:
Tolerance: 16%		60-86°F




Complexity and balance in high alcohol reds

Merlot, Zinfandel, Sangiovese, Barbera, Cabernet Franc, Petite Sirah, Structured Reds

#15644	500 g	\$46.00
#15645	10 kg	\$560.00

Lalvin Rhône 2226™ contributes to wine quality by enhancing varietal aroma expression, tannin structure and high color intensity in high-alcohol reds. Produces aromas of black cherry, berry and cherry cola in red wines.

This strain was isolated from a vineyard in the Côtes du Rhône in France.



Lalvin Rhône 4600^{TM} produces wines with complex aromatic notes. Noted for elevating fresh fruit aromas (apple, pear, strawberry) this strain is ideal for rosé and Rhône-style whites. Can produce fatty-acid ethyl esters (apricot and tropical fruit flavors) when fermented in high-sugar, low nutrient musts at cool temperatures $13.5^{\circ}\text{C}(56^{\circ}\text{F})$.

Higher roundness with diminished bitterness makes this strain a good choice for Rhône white varietals and Chardonnay.

Rhône 4600 has a short lag phase. May produce low levels of SO₂ and H₂S under conditions of stress. Malolactic friendly.

Isolated from a Viognier fermentation in the Côtes du Rhône region in France in collaboration with Inter-Rhône technical department.

Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 15%	LOW	56-72°F



Strong fermenter for Riesling and other aromatic whites

Riesling, Gewürztraminer, Sauvignon blanc, Viognier, Rhône Whites, Aromatic Whites

#15130 500 g \$46.00

Lalvin R-HST $^{\rm TM}$ retains fresh varietal character while contributing structure and mouthfeel. It can produce crisp, premium white wines with citrus and floral notes.

Tolerates fermentation temperatures as low as 10°C(50°F), however, allow the temperature to increase toward the end for a clean finish.

Short lag phase and generation time, even at cold temperatures. R-HST dominates and persist over spoilage yeast such as *Kloeckera apiculata*.

This strain was selected from Riesling trials conducted in the Heiligenstein region of Austria.



Complex, balanced and concentrated reds

Syrah, Zinfandel, Merlot, Cabernet Sauvignon, Cabernet Franc, Petite Sirah, Malbec, Petit Verdot, Structured Reds

#15665	500 g	\$49.00
#15666	10 kg	\$592.00

Enoferm RP15™ is recommended for medium to full bodied reds to produce a rich, lush, balanced mouthfeel. Wines are characterized by red fruit and mineral notes.

Contributes a rich mid-palate structure and enhances varietal fruit characters and helps to stabilize color.

Rehydrating the yeast in Go-Ferm Protect Evolution $^{\text{TM}}$ (see pg 45) tends to improve the aromatic profile of this yeast.

This strain was isolated from spontaneous Rockpile Syrah fermentations in California.

,		.
Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 17%	MEDIUM	68-86°F

NEW



For mega expression of grassy thiols Sauvignon blanc, Chenin blanc


#15258	500 g	\$50.00
#15272	10 kg	\$604.00

Sauvy™ was selected for its exceptional ability to uptake and reveal volatile thiols, especially 4MMP (passion fruit/black currant/gooseberry). Even in grapes where there are low levels of the thiol precursors the resulting wine expresses the 4MMP/green thiol character.

Sauvy also elevates Sauvignon blanc's traditional tropical fruit and citrus aromas and flavors especially when used in conjunction with the yeast nutrient, Stimula Sauvignon blanc $^{\text{TM}}$.

Sauvy produces very low to no H₂S, SO₂ and volatile acidity.

Impact of Sauvy™ on Volatile Thiols in 2019 Napa Valley Sauvignon blanc



Alcohol Nitrogen Needs: Temp. Range: Tolerance: 14% MEDIUM 57-68°F



Sulfur management and aromatic finesse for whites and rosés $% \left(1\right) =\left(1\right) \left(1\right)$

Rosé, Sauvignon blanc, Pinot blanc

#15225

Lalvin SensyTM respects varietal aromas and promotes aro-

\$46.00

30

matic esters while balancing mouthfeel and freshness in aromatic white wines.

Sensy has a short lag phase, is malolactic bacteria friendly and

produces very low to no SO₂ or H₂S even under low temperature and NTU white winemaking conditions. Avoid adding >50 ppm SO₂ at the crusher.

This hybrid strain of *S. cerevisiae* was selected in collaboration with the INRA, SupAgro Montpellier, the ICV and Lallemand as part of an innovative porfolio of yeast to control the production of negative sulfur compounds.

Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 15%	LOW	54-64°F

32

SYRAH CALLEMAND YSEG

Spicy, fruity and floral reds

Syrah, Merlot, Mourvedre, Petite Sirah, Petit Verdot, Structured Reds

#15657	: 500 g	\$49.00
#15658	10 kg	Ø502.00

Enoferm SyrahTM offers good mouthfeel and stable color extraction. Tends to produce high levels of β -damascenone, which promotes violet and red fruit aromas.

Typical aromas include violets, raspberries, strawberries and black pepper which enhance and respect the varietal character. This strain has a tendency to produce H_2S under low YAN conditions hence rehydration with Go-Ferm Protect EvolutionTM and thoughtful nutrition management is essential.

This strain that was isolated from the Côtes du Rhône region of France.

Alcohol Tolerance: 16%	Nitrogen Needs: MEDIUM	Temp. Range: 59–90°F
	•••••	• • • • •
	T73 LALLEMAND	
Strong fermenter fo	or varietal complexity in	high-alcohol reds
Merlot, Zinfandel, Sc	ıngiovese, Tempranillo, I	Fruit Forward Reds
#15091	500 g	\$46.00

Lalvin T73™ is recognized for its ability to enhance natural aromas and flavors in red wines produced in hot climates. Its well balanced production of esters and higher alcohols help hot climates wines "open up".

Mouthfeel is enhanced through the production of glycerol.

T73 shows good resistance to anti-fungal vineyard treatments, has extremely low nitrogen demand, and dominates against indegenous microflora.

This yeast strain was isolated by La Universidad de Valencia of Spain in collaboration with Lallemand.

•••••••••••••••••••••••••••••••••••••••		········
Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 16%	LOW	65-90°F
······:		:

Malbec, Syrah, Tempranillo, Merlot, Petite Sirah


#15252 500 g \$46.00

Lalvin Tango MalbecTM respects varietal character and promotes intense color. Tango Malbec produces full bodied red wines with aromatic complexity including flavors of violet, black cherry, blackberry, raspberry, dark plum and anise.

Its interactions with polyphenolic compounds creates wines with good structure, balance and the natural sweetness associated with Malbec.

It is a low H₂S and SO₂ producer and malolactic friendly.

Tango Malbec was isolated by the National Institute of Agricultural Technology in La Consulta, Uco Valley, Mendoza, Argentina.



VIN 13 is a very good thiol releaser (guava, passion fruit and grapefruit) and outstanding ester producer. In tank-fermented Chardonnay VIN 13 promotes pineapple and banana flavors, while on Riesling, Gewürztraminer and Viognier it accentuates floral notes.

10 kg

\$672.00

#15228

Aromatic as well as cold tolerant it is favored for its ease of use, making it a good choice for restarting stuck white fermentations, especially when fructose levels remain high.

Temperature control is advised. Do not over inoculate.

This hybrid yeast strain is a product of the yeast hybridization program at the Institute for Wine Biotechnology, University of Stellenbosch in South Africa.

Alcohol		Temp. Range:		
Tolerance: 17%	LOW	54-61°F		

VIN 2000 © Full bodied, Aromatic Whites


Chenin blanc, Chardonnay, Sauvignon blanc, Viognier, Albariño

#15195 1 kg \$94.0

VIN 2000 is recommended for the production of rich and ripe style Chenin blanc (fresh pineapple and citrus aromas), oaked Chardonnay (citrus aromas) and Sauvignon blanc (passion fruit, guava and tropical aromas).

Moderate speed fermenter with very low SO₂ production and low foaming. VIN 2000 is suitable for barrel fermentation.

This hybrid yeast strain is a product of the yeast hybridization program at the Institute for Wine Biotechnology, University of Stellenbosch in South Africa.



Tempranillo, Barbera, Sangiovese, Zinfandel, Petite Sirah,

Fruit Forward Reds .

#15173 500 g \$46.00


Uvaferm VRBTM helps express varietal characteristics and ester production in wines such as Tempranillo, Barbera, and Sangiovese. These wines are described as having flavors of ripe fruit, jam, hazelnut and dried plums.

VRB can soften tannins and add flavor complexity with good mid-palate volume. Wines tend to have good color intensity and stability with good polyphenolic structure.

VRB softens high acid musts by partially metabolizing malic acid.
VRB was selected by Centro de Investigaciones Agrarias

(CIDA) in Logroño, Spain.

	,	
Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 17%	MEDIUM	59-82°F



Ferments cleanly at low temperatures

Gewürztraminer, Riesling, Pinot gris, Pinot noir, Syrah, Rosé, Aromatic Whites, Rhône Whites

#15118	500 g	\$46.00
#15119	10 kg	\$560.00

In white wines, Lalvin W15[™] helps retain bright fruit characters while optimizing mouthfeel and balance. Performs well in Pinot noir and cooler climate Syrah.

Produces glycerol and succinic acid, especially when fermented between $15-20^{\circ}C(59-68^{\circ}F)$, adding complexity to the mid-palate.

Low heat generation during fermentation helps winemakers minimize the potential for temperature spikes and possible H₂S problems.

Isolated in 1991 at the Swiss Federal Research Station in Wädenswil, Switzerland.

		• • • • • • • • • • • • • • • • • • • •
Alcohol	Nitrogen Needs:	Temp. Range:
Tolerance: 16%	HIGH	50-81°F

NON-SACCHAROMYCES YEAST

"Non-Saccharomyces" is the colloquial term for yeast strains associated with vineyards or wineries that are not from the Saccharomyces genus. Due to their unpredictable nature and their ability to produce ethyl acetate and other undesirable characters, non-Saccharomyes have a bad reputation. However, specific organism within this group have been shown to contribute positively during the pre-fermentative and early fermentation stages. We have gained a better appreciation for these yeasts and use them as bioprotectants, to enhance the aromatic potential of grapes, and to naturally increase wine acidity.

Non-Saccharomyces are not strong fermenters and they require different handling than regular wine yeast. It is important to follow the specific handling recommendations and inoculate with a Saccharomyces species to complete the alcoholic fermentation.

SELECTING NON-SACCHAROMYCES YEAST FOR SUCCESS

	322201110 11011 3/1001/11 1010 1010 1010 101				
Non- Saccharomyces	Organism	Main activity	Winemaking application	When to add Saccharomyces	Suggested Compatible <i>Saccharomyces</i> strains
BIODIVA	Torulaspora delbrueckii	Produces polysaccharides and aroma compounds (esters). Consumes some sugar to alleviate osmotic (high sugar) stress on <i>Saccharomyces</i> .	To enhance mouthfeel, fruity esters and complexity of white, rosé and red wines. Suitable for late harvest, icewine and high starting sugar.	After 2-3°Brix drop	43, BDX, ICV D254, Persy, QA23 and VRB
FLAVIA	Metschnikowia pulcherrima	Enzyme production cleaves aroma precursors to reveal terpenes and thiols.	Optimize the tropical, citrus and floral notes of certain white and rosés.	24 hours after Flavia	Cross Evolution, Elixir, ICV D47, ICV GRE, QA23, Rhône 4600
GAIA	Metschnikowia fructicola	Out-competes native microflora that may produce volatile acidty. Useful when SO_2 isn't effective or desired.	Can be added to white or rosé grapes or juices for protection during transportation. Can be added to red grapes to protect during transportation or cold soak.	Upon juice receipt or end of cold soak	Any strain
LAKTIA	Lachancea thermotolerans	Converts glucose to lactic acid. Acts as a natural acidifier.	Acidification of low acid musts adding freshness and complexity.	24-72 hours after Laktia	Any strain



\$111.00

#15697

BiodivaTM is a pure culture of *Torulaspora delbrueckii* that can enhance the aroma profile and complexity of wines (see figure at right). This non-*Saccharomyces* yeast is an ester producer and can also produce components that lead to a fuller mouth-feel. Biodiva is osmotolerant making it a good choice for high sugar fermentations, late harvest and icewine production as it will consume some sugar alleviating some of the stress on *Sac*-

$\label{lem:charomyces} \emph{charomyces}. \ This \ can \ result in lower final volatile \ acidity \ levels.$ Recommended Dosage

Usage

Prior to inoculation, ensure that: free SO_2 <15ppm, turbidity >80 NTU, and inoculation temperature >16°C(61°F)*. Rehydrate Biodiva in ten times its weight of chlorine free, 30°C(86°F) water and stir gently. After 15 minutes stir gently again. Slowly combine some of the must with the rehydrated yeast to drop the temperature 10°C(18°F) and hold for 15 minutes. This step may need repeating until you are within

 $10^{\circ}\text{C}(18^{\circ}\text{F})$ of the must temperature, however the process should not exceed 45 minutes.


After 1.5-3°Brix drop a compatible *S. cerevisiae* strain should be inoculated following the recommended *Saccharomyces* rehydration protocol (see pg 36).

*If the must is <16°C(61°F) you may observe a long lag phase.

Storage

Store for 24 months at 11°C (52°F). Once opened use immediately.

Impact of Biodiva on Sensory Perception of a Merlot by 27 Tasters



Impact: Rounder, fruitier, more complex wines due to over-production of polyols and esters

Add *Saccharomyces*: After 2-3°Brix drop

FLAVIA Metschnikowia pulcherrima


For revelation of terpenes and thiols in aromatic whites and rosés

15244 500g \$109.00

FlaviaTM is a pure culture of *Metschnikowia pulcherrima* used for its ability to liberate bound thiols and terpenes in grapes. Bound thiols and terpenes are odorless and flavorless but are odor-active when released contributing to tropical, citrus and floral aromas.

Bound terpenes are attached to two sugar molecules and require two different actions to release them. Flavia has the ability to remove one sugar due to its α -arabinofuranosidase activity and *S. cerevisiae* can remove the other sugar due to its β -glucosidase activity. Flavia also has the ability to release bound thiols. Wines made using Flavia have enhanced floral aromas (see figure below).

This strain was selected in conjunction with the Universitad de Santiago de Chili (USACH).



Recommended Dosage

		,-
250ppm	25g/hL	2 lb/1000 gal

Usage

Prior to inoculation ensure the free SO_2 <10ppm. Rehydrate Flavia in ten times its weight of chlorine free, 30°C(86°F) water and stir gently. After 15 minutes stir gently again. Slowly combine some of the must with the rehydrated yeast to drop the temperature $10^{\circ}\mathrm{C}(18^{\circ}\mathrm{F})$ and hold for 15 minutes. This step may need repeating until you are within $10^{\circ}\mathrm{C}(18^{\circ}\mathrm{F})$ of the juice temperature, however, the process should not exceed 45 minutes. If the initial YAN is <100ppm we recommend using Go-Ferm Protect Evolution during the Flavia rehydration. After 24 hours a compatible *S. cerevisiae* strain should be inoculated, even if there has been no change in °Brix.

Storage

Store for 24 months at 11° C(52°F). Once opened use immediately.

Impact: Heightened terpenes and thiols due to enzymatic activity

Add *Saccharomyces*: After 24 hours

GAIA (ALLEMAND

Metschnikowia fructicola

For managing spoilage risks when transporting grapes or juice, or cold soaking reds

15686 500g \$109.00

GaiaTM is non-fermentative but implants and multiplies quickly, controlling the production of ethyl acetate and acetic acid from *Kloeckera apiculata* (see figure below), acetic acid bacteria, and other native microflora. Gaia can protect your grapes during a pre-fermentation cold soak for up to five days if the temperature is $<10^{\circ}$ C (50° F). Although Gaia was selected for its use as a bioprotectant, it can also help to preserve fruit characteristics and aroma.

Recommended Dosage

250ppm 25g/hL 2 lb/1000 gal

Usage


Prior to inoculation ensure the total SO_2 is <50ppm. Rehydrate Gaia in ten times its weight of chlorine free, $30^{\circ}C(86^{\circ}F)$ water and stir gently. After 15 minutes stir gently again. Slowly combine some of the must with the rehydrated yeast to drop the temperature $10^{\circ}C$ ($18^{\circ}F$) and hold for 15 minutes. This step may need repeating until you are within $10^{\circ}C(18^{\circ}F)$ of the must temperature, however, the process should not exceed 45 minutes.

Upon juice receipt or once cold soak has been completed, a compatible *S. cerevisiae* strain should be added following the recommended *Saccharomyces* rehydration protocol (see pg 36).

Storage

Store for 24 months at 11°C(52°F). Once opened use immediately.

Effect of Gaïa™ on Acetic Acid Production in Must Inoculated with *Kloeckera apiculata*



Impact: Crowds out volatile acid-producing native microflora

Add Saccharomyces: When desired (after juice settling, end of cold soak)

34

STAFF PICK

Why would you even consider cold soak in 2020 without Gaia? Preservation of fruit and aromatic expression with less risk of volatile acidity during maceration, it is the perfect use of a non-Saccharomyces to prevent spoilage. A snub to Kloekera apiculata! —Shirley Molinari, Technical Support - Lallemand Oenology, based in Sonoma County, CA

Lachancea thermotolerans

Naturally acidifies grapes lacking acidity


15253 \$109.00

Laktia $^{\text{TM}}$ is a pure culture of Lachancea thermotolerans isolated from the Rioja region of Spain. It is added at the beginning of fermentation where it produces lactic acid from sugar, bringing a freshness and aromatic complexity to wines. Laktia gives winemakers an interesting blending opportunity for wines lacking in acidity (Figure 1). Laktia is recommended for red musts but has been used successfully used in whites.

Although Laktia produces some alcohol, it does not have the ability to complete the alcoholic fermentation. It must be followed up after 24-72 hours with S. cerevisiae.

It is important to note that lactic acid >3g/L can inhibit malolactic bacteria.

Impact of Laktia on Acidity in a 2017 Tempranillo



Recommended Dosage

250ppm 25g/hL 2 lb/1000 gal

Usage

Prior to inoculation ensure the free SO₂ is <15ppm, temperature >17°C(63°F) and YAN >150ppm. Rehydrate Laktia in ten times its weight of chlorine free, 30°C(86°F) water and stir gently. After 15 minutes stir gently again. Slowly combine some of the must with the rehydrated yeast to drop the temperature 10°C(18°F) and hold for 15 minutes. This step may need repeating until you are within 10°C(18°F) of the must temperature, however the process should not exceed 45 minutes.

After 24 hours a compatible S. cerevisiae strain should be inoculated following the recommended Saccharomyces rehydration protocol (see pg 36) and using Go-Ferm Protect Evolution™. Due to consumption of nitrogen by Laktia, YAN should be measured and supplemented as necessary when Saccharomyces is inoculated.

Storage

Store for 24 months at 4°C(39°F). Once opened use immediately.

Impact: Adds freshness due to lactic acid production

Add Saccharomyces: After 24-72 hours

HOW TO

SACCHAROMYCES YEAST REHYDRATION

Proper yeast rehydration is one of the most important steps to ensure a strong and healthy fermentation. Normal inoculation rate for wine active dried yeast is 2 lb/1000 gal (25 g/hL). When added properly, this inoculation rate results in an initial yeast cell concentration of 3-4 million viable cells per mL of must/juice. Under favorable conditions, the initial yeast cell population will increase up to 100-150 million viable cells per mL of must/juice before growth stops and alcoholic fermentation begins. This biomass increase is critical for healthy fermentations. Higher inoculation rates are recommended on grapes that are higher maturity (higher sugar). When using a yeast rehydration nutreint such as Go-Ferm™ or Go-Ferm Protect Evolution™, maintain a ratio of 1 part yeast to 1.25 parts rehydration nutrient. Careful rehydration, atemperation, inoculation and homogenization are all important to help prevent sluggish or stuck fermentations.

Note: This protocol is not appropriate for non-Saccharomyces yeast. Please see individual product descriptions for rehydration quidelines (pgs 33-35).

- 1. Suspend 2.5 lb/1000 gal (30 g/hL) of Go-Ferm or Go-Ferm 3. Slowly (over a period of 5 minutes) combine an equal amount Protect Evolution in 20 times its weight of clean, chlorine free, 43°C(110°F) water. (For example: 2.5 lb rehydration nutrient x 20 = $50 \div 8.33$ lb/gal water = 6 gal water.) The water temperature is important for mixing of the rehydration nutrient. Due to the unique nature of Go-Ferm and Go-Ferm Protect Evolution, they will not go into solution completely. This is due to the fatty acid and sterol content. Please see page 45-46 for information on yeast rehydration nutrients. Important: If not using a yeast rehydration nutrient, water temperature should begin at 40°C(104°F) and the volume of water should be 10 times the weight of the yeast amount. This lower temperature is important so you do not to harm the yeast.
- 2. Once the temperature of the yeast rehydration nutrient solution has dropped to 40°C(104°F), add 2 lb/1000 gal (25 g/hL)* of active dried yeast. Stir gently to break up any clumps. Let suspension stand for 20 minutes, then stir gently again. Live yeast populations decline when allowed to stand for more than 30 minutes. Note: Foaming is not an indicator of yeast viability.

Step 2

- of the must/juice to be fermented with the yeast suspension. This will help the yeast adjust to the high sugar conditions and the cooler temperature of the must/juice. This step is essential as it will help to avoid cold shock caused by a rapid temperature drop exceeding 10°C(18°F). This atemperation step may need repeating for very low temperature must/juice. Each atemperation step should last about 15-20 minutes. For every 10°C(18°F) temperature difference between the must/juice and the yeast slurry, an atemperation step must be performed. For example, for a must/juice temperature of 20°C(68°F) and yeast slurry temperature of 40°C(104°F), two atemperation steps are required.
- 4. For direct inoculation of yeast post rehydration, ensure you mix the yeast slurry into the full volume of the must/juice.
- 5. For large tanks with long filling times add the yeast slurry to the bottom of the fermentation vessel just as you begin filling with must/juice. This is especially important when inoculating with strains that are sensitive to the competitive factor (refer to pages 11-14 for individual yeast strain information). This allows the yeast a head start over indigenous organisms.

Note: Copies of "Easy Steps for Optimal Yeast Rehydration" may be downloaded in Spanish, French and English from our website (scottlab.com).

Step 3

Atemperate.

*The yeast dosage can vary depending on the initial Brix, manufacturer's recommendations and the sanitary state of the grapes or winery. Visit scottlab.com for a video animation of this protocol.


Step 1 Add Go-Ferm or Go-Ferm Protect Evolution to warm water.





Wait 20 minutes





Repeat if necessary.

TROUBLESHOOTING GUIDE FOR SLUGGISH ALCOHOLIC FERMENTATIONS

Many factors influence the success of a fermentation including yeast strain selection, yeast cell number, yeast handling and inoculation practices, availability of nutrition and oxygen, and temperature management. If a fermentation becomes sluggish or you suspect it might be stuck, it is wise to get a complete picture of the wine before jumping into a full restart. Sometimes a simple adjustment or a mixing can be enough to get a fermentation back on track (refer below).

If a restart is necessary, having all the details will help you determine the best approach.

Recognizing that a fermentation is sluggish or stuck is the first step in rectifying a challenging situation. A fermentation can be viewed as stuck if the sugar has not dropped for >48 hours. A warning sign that a sluggish fermentation may become stuck is when the fermentation approaches ~1 °Brix and fermentation slows to <0.25 °Brix per day (and the temperature is reasonable).

There are a two protocols in our handbook (and more online). that can walk you through the necessary steps to restart a sluggish or stuck fermentation.

THE YEAST MIGHT **NEED ADDITIONAL NUTRIENTS**

For a fermentation to be happy and If your juice is clear (<50 NTU), there may not be enough solids to keep the healthy it is essential that the yeast have yeast in suspension during the early enough nutrients. Even when starting phases of fermentation. Increasing the with high nutrient levels (>300ppm YAN) turbidity is advised. This can be achieved additional nutrients are almost always through an addition of Reskue[™] (pg 49), needed at 1/3 of the way through the in addition to stirring. A side benefit of fermentation. If you're at the tail end of Go-Ferm™ and Go-Ferm Protect Evoluthe fermentation with just a small amount $tion^{TM}$ (pg 45-46) is that they also help to of sugar left, an addition of Reskue™ (pg increase the turbidity of the juice. 49) and a mixing can be beneficial.

THE YEAST MAY NOT HAVE BEEN PROPERLY ACCLIMATIZED

Rehydrated yeast must have time to acclimatize to the changes in sugar concentration and temperature of juice/ must during inoculation. Improper acclimatization can delay the start of fermentation after inoculation. Our "Saccharomyces Yeast Rehydration" protocol (pg 36) contains proper timing and steps for acclimatization.

THE JUICE/WINE

MIGHT BE TOO CLEAR

THERE MAY NOT BE ENOUGH YEAST

If you didn't inoculate at the appropriate rate it is possible that you don't have a sufficient population of yeast. In this case a re-inoculation might be necessary.

THE YEAST POPULATION IS NOT HEALTHY

You may have an adequate population, but the cells may not be healthy.

Choosing the correct protocol is essential for a successful outcome. If a fermentation sticks and the sugar level is >3 °Brix with an alcohol <11.5% (v/v) it is relatively easy to restart as long as there are no other compounding factors. However, fermentations are more difficult to restart when the alcohol is higher and the sugar is lower.

Our preferred method to restart sluggish and stuck fermentations is the "Recommended Method to Restart a Stuck Fermentation using Uvaferm 43 RESTARTTM" listed on the next page. This protocol was developed in conjunction with Inter-Rhône and is specifically for use with the 43 RESTART yeast strain. Other yeast strains (even ones within our portfolio, including Uvaferm 43TM) should not be attempted with this one-step acclimatization protocol. If a different strain like Uvaferm 43, Fermivin® Champion, Lalvin K1 (V1116)™ or VIN 13 is preferred for the restart, then the multi-step build-up protocol "Traditional Method to Restart a Stuck Fermentation" on page 39-40 can be used.

> starting sugar, you should always select a strain that will be able to handle the

THE WINE MIGHT

When wine yeast become stressed, they can produce certain compounds that impede fermentation. Reskue™ (pg 49) can be extremely beneficial in this situation. If possible, Reskue should be added and racked after 48 hours. If you are unable to rack, adding Reskue and leaving it in the wine can still help.

NEED A DETOXIFICATION

THE TEMPERATURE OF THE WINE IS PROBLEMATIC

Each yeast strain has an optimal temperature range for fermentation. Anything outside of this range can cause stress for the yeast. If your temperature is too low, try warming the wine slowly. If the temperature is too high, or if it spiked at any point, it's possible that the yeast are no longer viable and a re-inoculation will be necessary. To increase success rates at the end of fermentation, try adjusting the temperature of the wine to $20-22^{\circ}C(68-72^{\circ}F)$.

THE ALCOHOL MAY BE TOO HIGH FOR YOUR SELECTED YEAST STRAIN

Certain yeast strains can tolerate more alcohol than others. If you have exceeded the tolerance level of your selected strain, you may need to re-inoculate with a strain that has a higher tolerance. Based on your potential alcohol level.

THERE MIGHT BE OTHER MICROBIAL POPULATIONS YOU NEED TO ADDRESS

Check your malic acid and volatile acidity (VA). If malic acid has dropped, and you have not used malic acid-degrading yeast or bacteria, you may have a lactic acid bacteria (LAB) infection. A strong LAB population can produce VA and inhibit yeast that are already weak at the end of alcoholic fermentation. VA >0.6g/L can be challenging for yeast, especially in high alcohol situations, and anything greater than 0.8g/L can be inhibitory. LAB can be mitigated with LysovinTM (pg 89) if malolactic fermentation (MLF) isn't complete but is desired, or Bactiless™ (pg 90) if MLF is complete or a MLF is not desired. In any condition, uncontrolled LAB should be controlled before attempting to restart a stuck ferementation.

HOW TO

RECOMMENDED METHOD TO RESTART A STUCK FERMENTATION USING UVAFERM 43 RESTART™

FOR 1000 GALS OF STUCK WINE

PREPARE THE STUCK WINE

- 1. Address any potential spoilage organism concerns with SO₂, 8. Add 2kgs (4.4 lbs) of Go-Ferm Protect Evolution in 10 gallons Bactiless™ or Lysovin additions.
- 2. Suspend 1.5kg (3.3lb) Reskue™ in 10 times its weight of warm water 30-37°C(86-98°F). Wait 20 minutes then add to stuck wine. Mix thoroughly to incorporate.
- 3. Allow the Reskue to settle for 48 hours then rack off the
- 4. Adjust the temperature of the Reskue-treated wine to 20-25°C(68-77°F).

PREPARE THE "PIED-DE-CUVE" (STARTER)

- 5. Prepare the following:
- ♦ 40 gallons water
- ♦ 50 gallons racked Reskue-treated wine
- ♦ 0.3kg (2/3 lb) Fermaid O[™]
- 6. Adjust to 5°Brix.
- 7. Mix well.


YEAST REHYDRATION

- of water at 43° C (110° F).
- 9. Cool solution to 40°C (104°F) and add 1.5kgs (3.3 lbs) of Uvaferm 43 RESTART.
- 10. Wait 20 minutes and slowly acclimate the yeast before adding to the "Pied-de-cuve."
- 11. Maintain temperature of 20–25°C (68–77°F).

INCORPORATION OF THE "PIED-DE-CUVE"

- 12. Allow "Pied-de-cuve" to drop to 0°Brix.
- 13. Transfer immediately to the full volume of Reskue treated wine.
- 14. Add 1.5kg (3.3lbs) of Fermaid O to tank. Mix to homogenize. Monitor sugar depletion throughout the restart process.

The steps in this protocol can be adapted for volumes of wine other than 1000 gallons.



STAFF PICK

Our recently introduced Reskue/43Restart protocol has been a game changer for stuck and sluggish ferments. I've seen it solve many problems for winemakers—while saving time and people power!—Mollie Forest, Sales Representative, based in Washington State

HOW TO TRADITIONAL METHOD TO RESTART A STUCK FERMENTATION IN WINES >3°BRIX AND <11.5% ALCOHOL

When restarting a sluggish or stuck fermentation, it is essential to address yeast biomass buildup together with the low nutrient levels. A yeast rehydration nutrient such as Go-Ferm Protect Evolution™ is essential, as it is rich in micronutrients and survival factors.

When stuck wines have high residual sugar levels, the addition of a complex nutrient to the stuck wine is also recommended. Unwanted bacteria like Lactobacillus spp. and Oenococcus oeni are often present in stuck fermentations. Adding Lysovin (pg 89) to the stuck wine prior to restarting the fermentation may help control unwanted bacteria and provide an improved environment for the restart to occur.

Adding ReskueTM (pg 49) to the stuck wine prior to restarting the fermentation may also help reduce accumulated toxins and improve chances for a successful restart.

FOR WINES STUCK AT >3°BRIX AND <11.5% (V/V) ALCOHOL

STEPS 1-8

Build-up for Stuck Wine

- to restarting.
- 2. After 48 hours, rack off the Reskue.
- 3. Add a complex yeast nutrient (Fermaid K[™] or Fermaid O[™]) directly to the tank of stuck wine at a rate of 0.5-1.0 lb/1000 gal (6–12 g/hL). Many winemakers also add Lysovin at this time to reduce potential bacteria problems (see page 89).
- 4. In another clean container mix equal volumes of stuck wine and water. Generally this would total 1% of the total wine volume. (Example: For 1000 gal of stuck wine, use 10 gal water + 10 gal wine.) This container will be the "Mother Restart Tank".
- 5. Calculate the amount of Go-Ferm Protect Evolution at the recommended rate. Dissolve this yeast rehydration nutrient in 20 times its weight of clean, chlorine free, 43°C(110°F) water. (Example: 5 lb Go-Ferm Protect Evolution x 20 = 100 lb, divided by 8.33 lb/gal water = 12 gal water needed.) Mix the solution.
- 6. Select a yeast strain that is both alcohol tolerant and a vigorous fermenter such as Uvaferm 43™, Lalvin K1 (V1116)™, Fermivin® Champion or VIN 13. Calculate the amount of yeast required for the total volume of stuck wine at 3-5 lb/1000 gal (36-60 g/hL). When the rehydration nutrient/water solution temperature has cooled to 40°C(104°F), slowly (over 5 min-

utes) add yeast. Stir gently to mix and avoid clumping. Let this yeast suspension stand for 20 minutes.

- 1. Add 40 a/hL (3.3 lb/1000 gal) of Reskue 48 hours prior 7. Check the temperature of the yeast suspension. There should not be more than 10°C(18°F) difference between the yeast suspension and the diluted wine in the Mother Restart Tank. If there is too great a temperature difference, acclimatization may be required. Cold temperatures may shock the yeast cells.
 - When the yeast suspension is properly rehydrated and proper consideration has been given to temperature differences, add the yeast to the Mother Restart Tank and wait 20-30 minutes.

Inoculation of Stuck Wine

- 9. Add 10% of stuck wine to the Mother Restart Tank and wait 20-30 minutes. (Example: For 1000 gal stuck wine, add 100 gal wine.)
- 10. Add 20% of stuck wine to the Mother Restart Tank and wait 20-30 minutes. (Example: For 1000 gal stuck wine, add 200 gal wine.)
- 11a. Repeat step 10.
- 11b. Repeat step 10.
- 11c. Repeat step 10.
- 12. Add any remaining wine to the Mother Restart Tank.


FOR WINES STUCK AT 1-2°BRIX AND <11.5% (V/V) ALCOHOL

Follow this restart protocol, except in Step 3 reduce the complex yeast nutrient addition to 0.5 lb/1000 gal (6 g/hL).

FOR WINES STUCK AT <1°BRIX AND <11.5% (V/V) ALCOHOL

Follow this restart protocol, except in Step 3 eliminate the addition of a complex yeast nutrient.

TRADITIONAL METHOD TO RESTART A STUCK FERMENTATION IN WINES >3°BRIX AND <11.5% ALCOHOL





NUTRIENTS

at their peak while converting juice into wine. If yeast needs are not met, however, they become stressed and their performance

Yeast are living organisms. When treated well, they survive is hindered. To optimize yeast performance and to encourage most winemaking conditions. If yeast physical and nutritional a successful fermentation the yeast's nutritional needs must needs are understood and met, they can be expected to perform be met. Yeast require a balance of vitamins, minerals, survival factors and nitrogen.

SUPPLEMENTING NUTRIENTS FOR SUCCESS

Yeast require nitrogen in a form they can assimilate. Yeast assimilable nitrogen (YAN) consists of most amino acids, ammonia, and some types of peptides. Grapes vary in their YAN content. When determing the YAN content of must/juice, both assimilable amino acids (Proline is not assimilable) and ammonia need to be measured to determine total YAN.

Yeast also need vitamins, minerals and survival factors. Vitamins and minerals are co-factors for growth and aroma metabolism. Interestingly, the higher the YAN content the more vitamins and minerals a yeast requires. Yeast cannot survive without them. Yeast survival factors (sterols and unsaturated fatty acids) are needed for healthy plasma membranes. When yeast have sufficient survival factors, sugar uptake can continue throughout fermentation and the toxic effects of ethanol can be minimized. By providing sterols and unsaturated fatty acids during yeast rehydration, the cells will be off to a great start!

HOW MUCH YAN IS REOUIRED?

The amount of YAN yeast require depends on the following: individual yeast strain requirements, initial sugar content, fermentation temperature, oxygenation, turbidity, pre-fermentation practices and fruit quality.

YAN will vary between vintages, vineyards and varietals so it's necessary to analyize each lot of fruit. Analysis should be conducted as close to yeast inoculation as possible.

See more informaton on nitrogen supplementation and the importance of organic nitrogen on pgs 44.

YEAST STRAIN CHOICE

Different yeast strains have different requirements and are classified as low, medium or high.

- Low nitrogen-requiring yeast need 7.5 ppm YAN per 1°Brix.
- Medium nitrogen-requiring yeast need 9 ppm YAN
- High nitrogen-requiring yeast need 12.5 ppm YAN per 1°Brix.

INITIAL SUGAR CONTENT	TEMPERATURE	OXYGEN
The higher the initial sugar content, the more YAN required.	An increase in temperature stimulates fermentation rate and yeast growth, thereby requiring increased levels of nitrogen.	When adding more oxygen to the must/juice, nitrogen is captured faster, and more is needed.
TURBIDITY	PRE-FERMENTATION PRACTICES	FRUIT QUALITY
When juice is over-clarified (<50 NTU), many nutritional factors for yeast are removed, making it necessary to supplement with complete and balanced nutrients.	Vitamins and minerals are generally consumed (even in healthy fruit) by native microflora. This means that prior to inoculation these essential factors may be deficient.	The presence of rot will impact grape juice/must chemistry. Studies have shown that grapes impacted by <i>Botrytis cinerea</i> and other molds are deficient in YAN.

CHOOSING YEAST NUTRIENTS & YEAST DERIVATIVE NUTRIENTS

dVO 48	Fermaid K + Fermaid K (Kosher)	Fermaid O		ect E									
48	1	Fer	Go-Ferm	Go-Ferm Protect Evolution	Nutrient Vit End	Reskue	Stimula Chardonnay	Stimula Sauvignon blanc	Glutastar	Noblesse	Opti-MUM Red	Opti-RED	Opti-WHITE
1	48	49	46	45	50	49	46	47	51	52	52	53	53
50/50	25/25	10/40-60	-	-	-	-	10/40-60	10/40-60	-	-	-	-	-
60/60	30/30	12/48-72	-	-	-	-	12/48-72	12/48-72	-	-	-	-	-
80/80	40/40	16/64-96	-	-	-	-	16/64-96	16/64-96	-	-	-	-	-
			٥	٨									
				٥				٨					
		٥					٠						
		1	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	✓	J	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	✓												
		1	✓	✓			√	✓					
	✓												
					٥	٨							
									٨	٥			٥
									٥	٥			٥
										٥	٨	٥	
										٥	٨	٥	٥
											٥	٥	
										٥	٥	٥	
		٥					٥	٥	٥	٥	٥	٥	٥
												٥	٥
	٥	٥	٥	٥			۵	٥		٥			
										٥		٥	
		1	√	J	√					✓	✓	✓	√
✓		1	√	√	✓	✓	✓	✓	J	J	✓	✓	1
	50/50 60/60 80/80	50/50 25/25 60/60 30/30 80/80 40/40 	50/50 25/25 10/40-60 60/60 30/30 12/48-72 80/80 40/40 16/64-96	50/50 25/25 10/40-60	50/50 25/25 10/40-60 - - 60/60 30/30 12/48-72 - - 80/80 40/40 16/64-96 - - 0 0 0 0 0 1 0 0 0 0 0 1 0	50/50 25/25 10/40-60 - - - - 60/60 30/30 12/48-72 - - - - 80/80 40/40 16/64-96 - - - - <td>50/50 25/25 10/40-60 -</td> <td>50/50 25/25 10/40-60 - - - - 10/40-60 60/60 30/30 12/48-72 - - - - 12/48-72 80/80 40/40 16/64-96 - - - - 16/64-96 <t< td=""><td>50/50 25/25 10/40-60 - - - - 10/40-60 10</td><td>50/50 25/25 10/40-60 - - - - 10/40-60 10/40-60 - - - 10/40-60 10/40-60 - - - 12/48-72 12/48-72 - - - 12/48-72 12/48-72 - - - - 12/48-72 12/48-72 -</td><td> 50/50 25/25 10/40-60 10/40-60 10/40-60 10/40-60 10/40-6</td><td> S0 S0 25 Z5 10 40-60 10 40-60 10 40-60 </td><td> Solono S</td></t<></td>	50/50 25/25 10/40-60 -	50/50 25/25 10/40-60 - - - - 10/40-60 60/60 30/30 12/48-72 - - - - 12/48-72 80/80 40/40 16/64-96 - - - - 16/64-96 <t< td=""><td>50/50 25/25 10/40-60 - - - - 10/40-60 10</td><td>50/50 25/25 10/40-60 - - - - 10/40-60 10/40-60 - - - 10/40-60 10/40-60 - - - 12/48-72 12/48-72 - - - 12/48-72 12/48-72 - - - - 12/48-72 12/48-72 -</td><td> 50/50 25/25 10/40-60 10/40-60 10/40-60 10/40-60 10/40-6</td><td> S0 S0 25 Z5 10 40-60 10 40-60 10 40-60 </td><td> Solono S</td></t<>	50/50 25/25 10/40-60 - - - - 10/40-60 10	50/50 25/25 10/40-60 - - - - 10/40-60 10/40-60 - - - 10/40-60 10/40-60 - - - 12/48-72 12/48-72 - - - 12/48-72 12/48-72 - - - - 12/48-72 12/48-72 -	50/50 25/25 10/40-60 10/40-60 10/40-60 10/40-60 10/40-6	S0 S0 25 Z5 10 40-60 10 40-60 10 40-60	Solono S

^{*}See page 43 for more information on YAN equivalent vs measurable YAN

FERMAID O IS MORE EFFICIENT THAN AMMONIA (DAP)

THE IMPORTANCE OF AN ORGANIC SOURCE OF NITROGEN


Yeast are living organisms and require a balance of energy sources (sugar), nitrogen-containing compounds, vitamins, minerals, and survival factors to perform at their best. Nitrogen is one of the most important nutrients for yeast and the nitrogen-containing compounds that yeast can use are known as yeast assimilable nitrogen (YAN). YAN comes in two main forms: ammonia, an inorganic source of nitrogen (does not contain carbon), and amino acids which are complex organic based compounds (containing carbon).


Historically, nitrogen in the form of diammonium phosphate (DAP) has been the focus for yeast nutrition. In fact, most academic recommendations for YAN supplementation are based on DAP addition (see box on Measurable YAN vs YAN Equivalent this page). However, nitrogen supplied as DAP accumulates very quickly which can lead to uncontrolled cell growth and hot fermentations and does not necessarily give yeast the staying power to complete a fermentation. Alternatively, when nitrogen is supplied in the form of amino acids (from autolyzed yeast) the fermentation profiles are very different. Ferments do not get as hot, the yeast population is controlled, and the cells are healthier. Interestingly, both aroma and mouthfeel are also improved when DAP is avoided. Organic and inorganic nitrogen each have a distinct role and impact on fermentation. While yeast may show an affinity for

inorganic nitrogen, a yeast diet balanced with organic nitrogen can produce healthier fermentations, better aromatics (e.g. terpenes and esters) and lower levels of undesirable compounds (e.g. ethyl acetate and hydrogen sulfide).

To illustrate the relative effects of different nitrogen sources on fermentation kinetics, trials were done by Lallemand and the ICV in collaboration with the INRA Pech Rouge Research Station in the Languedoc region of France. The purpose of the trials was to compare the efficacy of adding DAP (inorganic nitrogen) versus Fermaid O™. The trial musts and fermentation protocols were identical. The only difference was that one lot received an addition of the equivalent of 16 ppm of YAN in the form of DAP while another received a similar YAN addition from Fermaid O. This addition was split into two for both treatments, with the first addition added at the onset of fermentation and the second addition added at 1/3 sugar depletion. The control received no addition of nitrogen.

The addition of YAN from Fermaid O resulted in a complete fermentation (Figure 2) in approximately 10 days (Figure 1). Further, the fermentation involving only DAP had a significantly slower conclusion and higher final residual sugars than the wine made with Fermaid O (Figure 2). These trials show the importance of the source of yeast available nitrogen.





MEASURABLE YAN VS YAN EQUIVALENT

Most academic recommendations for YAN supplementation have been based on measurable YAN, often supplemented hL dose of Fermaid O has 10 ppm measurable YAN but a YAN in the form of inorganic nitrogen (usually DAP). Lallemand has demonstrated that organic forms of YAN are 4-6 times

more efficient than inorganic YAN. This means that a 25 g/ equivalent of 40-60 ppm. Throughout our recommendations we have taken this efficiency into account.

HOW TO

NUTRIENT SUPPLEMENTATION PLANNER

In order to conduct a healthy and complete fermentation, yeast require minerals, vitamins, fatty acids, sterols and nitrogen. Minerals, vitamins, fatty acids and sterols are provided by GoFerm Protect Evolution™, whereas nitrogen is supplied by Fermaid OTM or Fermaid KTM. If we consider the individual needs of the yeast, how much fermentable sugar is present and how much nitrogen is required by the yeast under these conditions we can tailor a program designed for success. Use the following step-by-step guide to develop a complete yeast nutrition program for each fermentation:

- 1. Choose the yeast strain. Strains can be found on pages 11-16 and are classed as low, medium or high nitrogen-requiring.
- 2. Determine the yeast strain's Measurable YAN requirement using Table 1.
- 3. Calculate the amount of Measurable YAN that needs to be supplemented:
- [Yeast Measurable YAN Requirement (using Table 1)] - [Measurable YAN of Juice or Must] = Amount of YAN Required to Supplement (ppm)
- 4. Determine fermentation goal and follow program as outlined below:

Table 1: Yeast Assimilable Nitrogen (YAN)* needs of yeast at different starting sugars

Sugar	Yeast Strain Measurable YAN* Requirements (ppm N)				
°Brix	Low	Medium	High		
20	150	180	250		
22	165	200	275		
24	180	220	300		
26	195	240	325		
28	210	260	350		
30	225	280	375		

^{*} based on supplementation with inorganic nitrogen source, see pg 42 for info on YAN Equivalents

GOAL — FERMENTATION SECURITY

YAN Required to Supplement	At Yeast Rehydration Phase	At 2–3 °Brix Sugar Drop	At 1/3 Sugar Drop
0-50 ppm		No addition	30 g/hL (2.5 lb/1000 gal) Fermaid O
51-100 ppm	30 g/hL (2.5 lb/1000 gal) Go-Ferm Protect Evolution	20 g/hL (1.7 lb/1000 gal) Fermaid O	20 g/hL (1.7 lb/1000 gal) Fermaid O + 12.5 g/hL (1.0 lb/1000 gal) Fermaid K
101-150* ppm		40 g/hL (3.3 lb/1000 gal) Fermaid O	40 g/hL (2.5 lb/1000 gal) Fermaid K

GOAL — FERMENTATION SECURITY AND REVELATION OF THIOLS

YAN Required to Supplement	At Yeast Rehydration Phase	At 2–3 °Brix Sugar Drop	At 1/3 Sugar Drop
0-50 ppm			10 g/hL (0.8 lb/1000 gal) Fermaid O
51-100 ppm	30 g/hL (2.5 lb/1000 gal) Go-Ferm Protect Evolution	40 g/hL (3.3 lb/1000 gal) Stimula Sauvignon blanc	20 g/hL (1.7 lb/1000 gal) Fermaid O
101-150* ppm	oo remirroteet Evolution	J J	40 g/hL (3.3 lb/1000 gal) Fermaid O

GOAL — FERMENTATION SECURITY AND PRODUCTION OF ESTERS

YAN Required to Supplement	At Yeast Rehydration Phase	At 2–3 °Brix Sugar Drop	At 1/3 Sugar Drop
0-50 ppm		No addition	
51-100 ppm	30 g/hL (2.5 lb/1000 gal) Go-Ferm Protect Evolution	20 g/hL (1.7 lb/1000 gal) Fermaid O	40 g/hL (3.3 lb/1000 gal) Stimula Chardonnay
101-150* ppm		40 g/hL (3.3 lb/1000 gal) Fermaid O	

flyour calculation requires >150ppm nitrogen it is suggested to choose a yeast strain with a lower nitrogen requirement.

Rehydration is the first stage of a yeast nutrient strategy. Yeast rehydration nutrients provide natural micronutrients (vitamins and minerals) and survival factors (sterols and unsaturated fatty acids) to the yeast at a time when they can be used most effeciently. Yeast cells soak these nutrients up like a sponge making them biologically available for many essential reactions. Further, nutrients are available for their intended purpose since they are not consumed by competitive microorganisms, bound up by organic acids, anions, polysaccharides and polyphenols, or inactivated by SO₂.

Never use nutrients containing DAP during yeast rehydration—they are toxic to the yeast.




Go-Ferm Protect EvolutionTM is the latest generation of yeast rehydration nutrients. This formulation has optimized the bioavailability of vitamins, minerals and sterols, all of which are derived from inactivated wine yeast. The benefits are clearly seen at the end of alcoholic fermentation (Fig. 1).

Yeast rehydrated in Go-Ferm Protect Evolution have enhanced viability (Fig. 2), vitality and tolerance to wine stresses such as ethanol, acid, sugar and temperature. These yeast also express more aromatic varietal aromas (Fig. 3) due to Go-Ferm Protect Evolution's high ergosterol content which enables yeast membrane transport systems better aromatic precursor assimilation.


When used in fermentations where oxygen additions are difficult, Go-Ferm Protect Evolution's enhanced sterol content can replace the second oxygen addition recommended at 1/3 sugar depletion.

Fig. 1: Impact of Go-Ferm Protect Evolution on Fermentation Kinetics in a High Nitrogen, Low Sugar Ferment.




STAFF PICK

GoFerm Protect Evolution makes yeast happy, that makes me happy—Nichola Hall, PhD, Staff Scientist and Yeast Physiologist based in Sonoma Co.



Evolution

Fig. 3: Impact of Go-Ferm Protect Evolution vs Oxygen on Varietal Thiol Production



Recommended Dosage

Note: This recommendation is based on a yeast inoculum of 2 lb/1000 gallons (25 g/hL). If using more or less yeast, use a ratio of 1 part yeast to 1.25 parts Go-Ferm Protect Evolution


Usage

Mix Go-Ferm Protect Evolution in 20 times its weight of clean 43°C(110°F) water. Let the mixture cool to 40°C(104°F) then add the selected active dried yeast. Let stand for 20 minutes. Slowly (over 5 minutes) add equal amounts of juice/must to be fermented to the yeast slurry. Do not allow more than 10°C(18°F) difference. Acclimatize yeast as necessary (see page 36 for more details).

Storage

Dated expiration. Store in a cool and dry environment at $18^{\circ}\text{C}(65^{\circ}\text{F})$. Once opened, keep tightly sealed and dry.

Note: Due to the unique nature of Go-Ferm and Go-Ferm Protect Evolution, they will not go into solution completely. This is due to the fatty acid and sterol content and is to be expected.



Go-Ferm $^{\text{TM}}$ is the original yeast rehydration nutrient and contains a balance of micronutrients. It was developed to enhance fermentation kinetics and to help avoid fermentation problems like hydrogen sulfide.

Recommended Dosage

	l
30 g/hL	2.5 lb/1000 gal

Note: This recommendation is based on a yeast inoculum of 2 lb/1000 gallons (25 g/hL). If using more or less yeast, use a ratio of 1 part yeast to 1.25 parts of Go-Ferm.

Usage

Mix Go-Ferm in 20 times its weight of clean 43°C(110°F) water. Let the mixture cool to 40°C(104°F) then add the selected active dried yeast. Let stand for 20 minutes. Slowly (over 5 minutes) add equal amounts of juice/must to be fermented to the yeast slurry. Do not allow more than 10°C(18°F) difference. Acclimatize yeast as necessary (see page 36 for more details).

Storage

Dated expiration. Store in a cool and dry environment at 18°C(65°F). Once opened, keep tightly sealed and dry.

Stage of Winemaking: During yeast rehydration	Provides: Natural vitamins & minerals in autolyzed yeast base		
Impact: Supports healthy	YAN contribution:		

Insignificant

YEAST STIMULANTS FOR OPTIMIZING AROMAS


fermentations

The Stimula range of yeast nutrients are some of the most innovative products within the Lallemand portfolio. Yeast nutrients are generally used to nourish cells and assist them with the challenges of fermentation. The Stimula range is different. These natural yeast autolysates are formulated to supply optimal levels of specific amino acids, vitamins, minerals and sterols that stimulate the yeast cell functions involved in aroma compound revelation and production. When used at specific times during fermentation, ester production, and thiol uptake, revelation and release, are increased. The Stimula natural yeast autolysates can be used in any varietal where you wish to optimize thiol expression or ester production.



Stimula Chardonnay™ is a 100% autolyzed yeast added at the end of yeast growth phase, usually at about 1/3 sugar depletion. At the end of growth phase, yeast use Stimula Chardonnay's naturally occurring amino acids, riboflavin, biotin, vitamin B6 complexes, sterols, manganese and zinc to produce esters rather than for growth. Esters are desirable and contribute fruity and floral aromas. Stimula Chardonnay optimizes the aromatic potential of white and rosé wines.

Impact of Stimula Chardonnay on Ester Production in Languedoc Chardonnay



Recommended Dosage

40 g/hL 3.3 lb/1000 gal

Usage

Mix Stimula Chardonnay in 10 times its weight of clean, chlorine-free water or juice and add to the fermentation at $\frac{1}{3}$ sugar depletion. It is essential that the timing of addition is respected. Stimula Chardonnay is not fully soluble. Stir to maintain suspension before and during addition.

Storage

Dated expiration. Store in a dry environment at 18°C (65°F). Once opened, use immediately.

Stage of winemaking:	Provides: Organic nitrogen
During fermentation at 1/3	with natural vitamins and
sugar depletion	minerals
Impact: Stimulates fruity and floral ester production	Measurable YAN at 40 g/ hL dose: 16 ppm YAN equivalents at 40 g/ hL dose: 64-96 ppm

Recommended Dosage

3.3 lb/1000 gal 40 g/hL

STIMULA SAUVIGNON BLANC (ALLEMAND

Stimulates positive thiol production in aromatic whites and rosés

#15246	1 kg	\$44.00
#15255	10 kg	\$383.00

Stimula Sauvignon Blanc™ is a 100% autolyzed yeast added at the beginning of fermentation, after approximately 2-3°Brix drop. It enhances volatile thiol production in Sauvignon blanc, Chardonnay, Riesling, and Sémillon, as well as rosés made from Syrah, Grenache and Cabernet Sauvignon. Volatile thiols are responsible for the varietal aromas associated with tropical (passion fruit, guava), citrus (grapefruit), gooseberry, and blackcurrant flavors.

Stimula Sauvignon Blanc is particularly rich in calcium pantothenate, thiamin, vitamin B6 complexes, folic acid, manganese and zinc. These vitamins and minerals stimulate yeast uptake of odorless thiol precursors and their subsequent conversion into aromatic volatile thiols (4MMP and 3MH).

Usage

Mix Stimula Sauvignon blanc in 10 times its weight of clean, chlorine-free water or juice and add to the fermentation at 2-3°Brix drop. It is essential that the timing of addition is respected. Stimula Sauvignon blanc is not fully soluble. Stir to maintain suspension before and during addition.

Storage

Dated expiration. Store in a dry environment at 18°C (65°F). Once opened, use immediately.

Stage of winemaking:	Provides: Organic nitrogen
During fermentation at	with natural vitamins and
2-3°Brix sugar drop	minerals
Impact: Optimizes uptake of thiol precursors	Measurable YAN at 40 g/ hL dose: 16 ppm YAN equivalents at 40 g/ hL dose: 64-96 ppm

ESTERS OR THIOLS: WHICH STIMULA NUTRIENT SHOULD YOU USE?

Despite their names, Stimula nutrients can be used on varietals other than Chardonnay or Sauvignon blanc. Which Stimula to use depends on whether esters or thiols are desired.

STIMULA CHARDONNAY FOR ESTERS

Esters contribute sweet-fruity aromas and flavors in white, rosé and red wines. It is the synergy of esters that contributes to overall complexity of wine aromas. Recent research has shown that ester production happens in two phases with the majority of esters produced during last two thirds of fermentation.

Fermentation esters can be split into two major groups: acetate esters, responsible for rose/floral aromas, and ethyl esters, responsible for red berry/fruit aromas. Although yeast vary in their ability to produce esters (see charts pgs 11-16), ester production is also influenced by nutrient composition and fermentation conditions. Lipids, vitamins and specific amino acids all support ester production which is why Stimula Chardonnay is recommended for all fruity and floral wine styles.

STIMULA SAUVIGNON BLANC FOR THIOLS

Volatile thiols are compounds that contribute tropical notes reminiscent of passion fruit, guava and grapefruit in white wines. Although Sauvignon blanc is the poster child for thiols we know that volatile thiol precursors are in the skin of many other white varieties like Chardonnay, Colombard, Gewürztraminer, Grenache blanc, Pinot gris, Pinot blanc and Sémillon. Interestingly, the blackcurrant flavor found in red wines like Cabernet Sauvignon, Merlot and Syrah are also due to the presence of thiols. These compounds are released from their bound form due to yeast enzymatic activity, and yeast establish this enzymatic activity very early in fermentation. Using Stimula Sauvignon blanc early in any thiolic varietal can help to optimize the potential of volatile thiol production.

NUTRIENTS FOR FERMENTATION SECURITY

Yeast nutrition refers to the utilization of essential nutrients for cellular reactions which ultimately ensures the growth and survival of the cell. Fermentation nutrients are a vital part of a controlled fermentation strategy. Yeast cells use nitrogen for growth, enzyme synthesis, protein synthesis and sugar transport. Yeast cells also require a balanced supply of minerals (magnesium, zinc, etc.), vitamins, sterols including ergosterol and natural sterols from the grapes (phytosterols), polyunsaturated fatty acids, and oxygen.

Tailor your fermentation regime for optimal yeast reproduction, sugar transport and aromatic expression.



Diammonium phosphate (DAP) should only be used to supplement severely deficient juices/musts. DAP provides inorganic nitrogen and should only be used if necessary and always in combination with complex nutrients.

Suspend DAP in water or juice/must and mix well before adding, especially during fermentation to avoid CO2 release and overflowing of vessel.

Storage

Dated expiration. Store in a cool and dry environment at 18°C(65°F). Once opened, keep tightly sealed and dry.

Stage of winemaking: 1/3 sugar depletion if YAN needs cannot be achieved using Fermaid O or Fermaid K	Provides: Ammonia and phosphate
Impact: Supports cell growth, drives fermentation rate	Measurable YAN at 25 g/hL dose: 50 ppm YAN equivalents at 25 g/hL dose: 50 ppm



#15073 2.5 kg \$63.00 \$162.00 #15070 10 kg

Fermaid K (Kosher) - certified Kosher for Passover #15070K 10 kg \$273.00

Fermaid KTM is a complex yeast nutrient that contains a blend of assimilable amino acids from inactivated and autolyzed yeast, sterols and unsaturated fatty acids, magnesium sulfate, thiamin, folic acid, niacin, calcium pantothenate, diammonium phosphate (DAP), and inactivated yeast. This blended nutrient assists with many of the fermentation challenges yeast face. The balance of amino acids and ammonia salts can be used to boost YAN. The sterols and unsaturated fatty acids provide important survival factors which are needed for alcohol resistance and sugar uptake. Inactivated yeast act as nucleation sites that help keep yeast in suspension and absorb toxic short and medium chain fatty acids.

For optimal results, Fermaid K should be used in conjunction with Go-Ferm Protect Evolution™ rehydration nutrient (pg 45).

Recommended Dosage

25-50 g/hL 2-4 lb/1000 gal

Usage

Suspend Fermaid K in water or juice/must and mix well before adding, especially during fermentation to avoid CO2 release and overflowing of vessel.

Storage

Dated expiration. Store in a cool and dry environment at 18°C(65°F). Once opened, keep tightly sealed and dry.

*Note: The ingredients in Fermaid K and Fermaid K (Kosher) are listed by the TTB as acceptable in good commercial winemaking practice in 27 CFR 24.250 together with 27 CFR 24.246. The ingredients in all other products shown on pages 48-53 are listed by the TTB as acceptable in good commercial winemaking practice in 27 CFR 24.246. For more information please visit www.TTB.gov. This product contains thiamin. The TTB Maximum Legal Dose for thiamin hydrochloride = 0.60 mg/L (0.005 lb/1000 gal) of wine or juice. 21 CFR 184.1875.

.....

Stage of winemaking:	Provides: Complex
1/3 sugar depletion	nutrient blend
Impact: Fermentation health and security	Measurable YAN at 25 g/hL dose: 25 ppm YAN equivalents at 25 g/hL dose: 25 ppm



#15067	2.5 Kg	\$92.00
#15107	101	\$346.00

Fermaid OTM is a blend of highly specific inactivated yeast fractions that are rich in assimilable amino acids (organic nitrogen). It's amino acid profile is highly consistent. Though Fermaid O does not supply a lot of Measurable YAN (see pg 43 for more info), it is a highly effective nutrient. It reliably lowers peak fermentation temperatures, produces lower levels of negative sulfur compounds, and improves fermentation kinetics. Organic nitrogen use has been correlated with positive aromatic expression (thiols and esters) and mouthfeel. For more info, see article on pg 43.

Fermaid O does not contain any DAP or supplemented micronutrients. For optimal results, Fermaid O should be used in conjunction with Go-Ferm Protect Evolution™ rehydration nutrient (pg 45).

Recommended Dosage

lb/1000 gal
J

Usage


Suspend Fermaid O in water or juice/must and mix well before adding, especially during fermentation to avoid CO, release and overflowing of vessel.

Storage

Dated expiration. Store in a cool and dry environment at 18°C(65°F). Once opened, keep tightly sealed and dry.

Note: Due to high nutrient requirements, some yeast strains may benefit from additional nutrient supplementation (see yeast reference chart on pgs 11-16 and Nitrogen Supplementation article on pg 44).

Stage of winemaking:	Provides: Highly
Onset of fermentation and/	consistent source of
or 1/3 sugar depletion	amino acids
Impact: Fermentation security and enhanced aroma production	Measurable YAN at 40 g/hL dose: 16 ppm YAN equivalents at 40 g/hL dose: 64-96 ppm



RESKUE LALLEMAND

Specific inactivated yeast for treating sluggish

#15224	1 kg	\$42.00
#15242	10 kg	\$312.00

and stuck fermentations

Reskue™ is a specific wine yeast that has been inactivated and treated with a specialized process to create cells with very high bioadsorptive properties specific for short- and mediumchain fatty acids. These fatty acids are toxic to yeast and can be created by yeast during stressful fermentation conditions. Their presence interferes with yeast membrane sugar transport proteins thereby interfering with sugar uptake rates. Using Reskue removes these toxins and reinvigorates sluggish or stuck alcoholic and/or malolactic fermentations.



Reskue has unique lumps and bumps! This increased surface area allows for greater adsorption of toxins.

SEM photo provided by Lallemand. Research collaboration with Professor Aude Vernhet at SupAgro Montpellier.

Dosage

3.3 lb/1000 gal 40 g/hL

Usage

Suspend Reskue in 10 times its weight of clean 30-37°C(86-98°F) water and mix. Wait 20 minutes then add to challenging fermentation. For stuck fermentations, allow Reskue to settle for 48 hours then rack off and follow restart protocol (pg 38-40).

Storage

Dated expiration. Store in a cool and dry environment at 18°C(65°F). Once opened, keep tightly sealed and dry.

Stage of winemaking: Any point during fermentation	Provides: Highly specific autolyzed yeast with bioadsorptive properties
Impact: Reinvigorates and detoxifies sluggish/ stuck fermentations	YAN contribution: Insignificant



Inactivated yeast for compromised fruit and challenging conditions: OMRI listed

#15679 2.5 kg

This specific inactivated yeast can be used at any stage of the fermentation process. Due to its bioadsorptive properties Nutrient Vit End™ can be used early to bind residual fungicides or later to bind specific fermentation derived inhibitors like short- and medium-chain fatty acids. When used preventatively, Nutrient Vit End can bind these toxins and help minimize the risk of sluggish or stuck fermentations.

Recommended Dosage

30-40 g/hL 2.5-3.3 lb/1000 gal

Usage

Suspend Nutrient Vit End in water or juice/must and mix well before adding.

Storage

Dated expiration. Store in a cool and dry environment at 18°C(65°F). Once opened, keep tightly sealed and dry.

Stage of winemaking: Any point during fermentation	Provides: Highly specific autolyzed yeast with bioadsorptive properties
Impact: Binds fungicides and other fermentation inhibitors	YAN contribution: Insignificant

YEAST DERIVATIVE NUTRIENTS

Yeast derivative nutrients are produced from specific strains All yeast derivative nutrients will contribute some nitrogen of wine yeast that have been inactivated and then fully or partially autolyzed to provide enologically attractive used for different reasons. The nitrogen (YAN) contribution compounds like polysaccharides and peptides. These is only mentioned if the goal of the product is fermentation compounds are harvested in their most reactive form. Each of our yeast derivative nutrients can be differentiated by: strain, level of refinement, functional contribution, and the presence of specific fractions such as glutathione. These winemaking tools contribute certain fermentative advantages and significant wine quality improvement.

to a fermentation, but different autolyzed yeast products are security. Used alone, these nutrients they should not be viewed as a substitute for the complete range of fermentation nutrition products listed in the preceding pages.

SELECTING YEAST DERIVATIVE NUTRIENTS FOR SUCCESS

Yeast derivatives have been used for centuries, historically in the form of autolyzed lees. Lees aging enhances the complexity and stability of wines but the process is slow and can take years to complete. It also comes with risks of sulfur off-odor production, microbial spoilage, and unpredictable outcomes due to the variability of the yeast used for fermentation. Yeast derivative nutrients are autolyzed (inactivated) yeast that can contribute to balance, aroma preservation and color stability in red, white and rosé wines without the risk of lees aging. They can be used at various stages of the fermentation process,

AROMA STABILITY	COLOR STABILITY	PEPTIDES
Glutathione and other peptides protect aromas due to their anti-oxidant and quinone-scavenging properties. Polysaccharides can bind with some aroma compounds leading to a stabilizing effect as well as a lengthing of aroma sensations.	High molecular weight polysaccharides can interact positively with polyphenolic compounds. This complex can help stabilize polymeric pigments (color).	Peptides act as anti-oxidants and quinone-scavengers, and give the perception of sweetness.
MOUTHFEEL	GLUTATHIONE	POLYSACCHARIDES
Aging on lees releases mannoproteins and polysaccharides that result in	Glutathione is a natural tripeptide found in grapes and yeast in two forms:	The main sources of polysaccharides in wine are from grape skin walls or

reduced astringency and an increase in mouthfeel components. When polysaccharides complex with tannins there are that can scavenge ortho-quinones and less reactive sites where the tannin can react with salivary proteins, thus lowering the perception of astringency.

reduced (GSH) and oxidized (GSSH). In winemaking, GSH is the active form can act as a buffer in redox reactions. This powerful antioxidant helps to protect juice and wine from the deleterious effects of oxygen.

yeast. Yeast-based polysaccharides can improve aroma, color stability and mouthfeel. They can add palate weight, sweetness and decrease astringency depending on the molecular weight of the compound, its composition and structure.

Protects and stabilizes aroma and color compounds against oxidative damage

Aromatic Whites and Rosés

#15265	1 kg	\$71.00
#15266	10 kg	\$454.00


Glutastar™ is a yeast derivative nutrient that is used early in white and rosé winemaking to scavenge quinones. Quinones quickly lead to oxidative damage when left untreated. By scavenging quinones, aroma compounds and color are preserved. Glutastar is a highly soluble, unique, autolyzed yeast that brings protective qualities of both specialized peptides and reactive glutathione to wines. The effect of Glutastar is longlasting and its positive impact on varietal and fermentationderived aromas (Fig. 1) and wine color (Fig. 2) contribute to a prolonged wine shelf-life.

Glutastar can be used in no- and low-SO2 winemaking.

Fig. 1: Impact of Glutastar on Volatile Thiol Content in a Sauvignon blanc at End of Fermentation



Fig. 2: Color Analysis in a 2018 Provence Rosé of Syrah/Grenache. Trial Compares Control Wine with **Glutastar added after Pressing**



Recommended Dosage

30 g/hL 2.5 lb/1000 gal

STAFF PICK

Glutastar is my favorite new product for 2020. Merely explaining what this product does doesn't do it justice. Yes, it's an antioxidant and it protects aromas and colors, but it's even more interesting than that. It reminds me of seeing a dress on a hanger and not realizing how cool it is until you try it on and then thinking "Damn! This is *so* good." This product needs to be experienced to be appreciated. —Jessica Just, Fermentation & Enology Dept. General Manager

Usage

Mix Glutastar in 10 times its weight of water or juice. Add directly to juice post-pressing for optimal protection. This product is mostly soluble. Stir to maintain suspension before and during addition.

Storage

Dated expiration. Store in a cool and dry environment at 18°C(65°F). Once opened, keep tightly sealed and dry.

Stage of winemaking:	Provides: Peptides,
Add directly to juice	polysaccharides and
post-pressing	glutathione
Impact: Scavenges quinones to protect aromas and color	YAN contribution: insignificant

GLUTASTAR: MORE THAN GLUTATHIONE

Glutathione protects color and aromas from oxidation during the earliest stages of post-harvest winemaking. Glutathione is a tripeptide naturally found in grapes and yeast in its reduced or oxidized form. In winemaking, only glutathione in its reduced form, GSH, protects musts and wines against oxidation due to its ability to scavenge ortho-quinones.

GSH plays a critical role in preventing the oxidation of wine phenols via the reaction of its sulfhydryl group with caftaric acid, one of the most browning-susceptible phenols in wine, to generate stable and colorless products. Other wine compounds contain sulfhydryl groups (some thiols, the amino acid cysteine, and the glutamyl-cysteine dipeptide) but only GSH can react with caftaric acid.

GSH can also outcompete several wine aromatic thiols such as 3MH, 3MHA and 4MMP, for oxidative ortho-quinones thus protecting these wine aromas.

Pure glutathione is not allowed to be added to must or wines but the early addition of GlutastarTM, a new GSHrich yeast derivative, provides a natural alternative to optimize wine quality. Glutastar was developed for the protection of white and rosé wines against oxidation phenomena responsible for color browning and loss of aromas. In fact, studies have shown Glutastar to be more effective than glutathione alone.

NOBLESSE (ALLEMAND OMRI

OPTI-MUM RED (ALLEMAND OMR)

For increased color stability and roundness in red wines; OMRI listed

#15229	1 kg	\$57.00
#15250	10 kg	¢220.00

The yeast strain behind Opti-MUM Red™ was specifically selected and autolyzed for its highly reactive polysaccharides and oligosaccharides. Upon addition, Opti-MUM Red's high molecular weight polysaccharides are released and quickly participate in reactions that stabilize color and polyphenolic compounds (tannins). The earlier that Opti-MUM Red is used the more effective it is in reacting with early diffused color molecules. Using Opti-MUM Red results in wines that are more intense in color and have a rounder and softer mouthfeel with a decreased perception of astringency.

Recommended Dosage

1.7-3.3 lb/1000 gal 20-40 g/hL

Usage

Mix Opti-MUM Red in 10 times its weight of water or juice and add directly to the grapes or must. If adding later in fermentation, add during a pump-over or during tank mixings. This product is mostly soluble. Stir to maintain suspension before and during addition.

Storage

Dated expiration. Store in a cool, dry environment at 18°C(65°F). Once opened, keep tightly sealed and dry.

Stage of winemaking: Add	Provides: High molecular
directly to grapes or at	weight polysaccharides
first mixing	and oligosaccharides
Impact: Color stabilty,	YAN contribution:
volume and softness	Insignificant

Contributes to balance, sweetness and softness on the finish; OMRI listed

Reds, Complex Whites and Rosés

#15105 \$102.00

Noblesse™ is a partially autolyzed yeast derivative nutrient that gives the perception of sweetness and promotes harmony between mouthfeel characteristics in red, white and rosé wines. Upon addition, Noblesse starts to release polysaccharides that can help mask sensations of acidity, astringency or bitterness while helping to integrate alcohol and oak.

Wines made using Noblesse appear to have more fruit and sweetness due to the contribution of low molecular weight polysaccharides. There is also a decrease in tannin intensity and a reduction in both drying and aggressive characters due to the softening effect of the high molecular weight polysaccharides. Noblesse can be used at any time during fermentation and although immediate results are possible, full integration may take three to five months.

Recommended Dosage

2.5 lb/1000 gal 30 g/hL

Usage

Mix Noblesse in 10 times its weight of water or must/juice. Add during a pump-over or tank mixing. This product is partially soluble. Stir to maintain suspension before and during addition.

Storage

Dated expiration. Store in a cool and dry environment at 18°C(65°F). Once opened, keep tightly sealed and dry.

•••••••••••

Stage of winemaking:	Provides: High and
Anytime during	low molecular weight
fermentation processes	polysaccharides
Impact: Adds sweetness, harmonizes and integrates mouthfeel	YAN contribution: Insignificant



For rounder and smoother tannins in reds; OMRI listed

#15148	1 kg	\$48.00
#15138	2.5 kg	\$102.00
#15211	10 kg	\$295.00

Opti-RED™ is an inactivated and partially autolyzed yeast derivative nutrient. Opti-RED may be used either at the beginning or towards the end of red wine fermentations. Using Opti-RED in the must quickly releases polysaccharides. These polysaccharides are then available to complex with polyphenols. This early complexing results in red wines with better color stability. Using Opti-RED in the latter part of alcoholic fermentation allows the winemaker to shape harsh polyphenolics into smoother, more approachable tannins.

Recommended Dosage

2.5 lb/1000 gal 30 g/hL

Usage

Mix Opti-RED in 10 times its weight of must or water and add during a punch-down or a pump-over to ensure Opti-Red is mixed in well. This product is partially soluble. Stir to maintain suspension before and during addition.

Storage

Dated expiration. Store at 18°C(65°F). Once opened, keep tightly sealed and dry.

Stage of winemaking: Anytime before the	Provides: High molecular weight
completion of fermentation	polysaccharides
Impact: Early use promotes color stabilty, late use smoothes harsh tannins	YAN contribution: Insignificant

OPTI-WHITE CALLEMAND OMRI

Promotes roundness and smoothness and protects aromatics; OMRI listed

Complex Whites and Rosés

#15165	1 kg	\$48.00
#15136	2.5 kg	\$102.00
#15216	10 kg	\$295.00

Opti-WHITE™ is prepared using a specific production process that results in a yeast derivative nutrient containing both antioxidant peptides and polysaccharides. The peptides protect aromatics, whereas the polysaccharides help stabilize aroma compounds and enhances roundness.

When added to the juice at the onset of fermentation Opti-WHITE helps to prevent oxidative browning* while bringing smoothness and complexity. When Opti-WHITE is added during the later stages of fermentation, it helps integrate the flavors.

Recommended Dosage

25-50 g/hL 2-4 lb/1000 gal

*Use 50 g/hL for maximum antioxidative properties or use Glutastar[™] (pg 51) for maximum anti-browning potential.

Usage

Mix Opti-WHITE in 10 times its weight of juice or water. Add to the juice after settling or directly to the barrel or tank prior to the onset of fermentation. If adding during the later stages of alcoholic fermentation, add during a tank mixing for proper homogenization. This product is partially soluble. Stir to maintain suspension before and during addition.

Storage

Dated expiration. Store in a cool and dry environment at 18°C(65°F). Once opened, keep tightly sealed and dry.

Stage of winemaking: Anytime before the completion of fermentation	Provides: Polysaccharides and antioxidant peptides
Impact: Balances mouthfeel and protects aromas	YAN contribution: Insignificant

FREQUENTLY ASKED QUESTIONS: YEAST NUTRIENTS

What is the difference between Go-Ferm and Go-Ferm Protect Evolution?

Go-Ferm Protect Evolution is the latest generation of rehydration nutrients, developed in conjunction with INRA, France, for today's winemaking needs. In addition to the vitamins and minerals that Go-Ferm provides Go-Ferm Protect Evolution contains higher levels of unsaturated fatty acids and sterols for improved sugar uptake capacity and fermentation security.

Why doesn't my Go-Ferm and Go-Ferm Protect Evolution go into

This is a good thing! Due to their high content of sterols and fatty acids, they will not go completely into solution.

Can I use Fermaid K in my yeast rehydration water instead of Go-Ferm?

No, using nutrients that contain ammonia salts during the rehydration phase can be toxic to the yeast. Rehydration nutrients should be fully autolyzed so that the nutrients are freely available to the yeast.

Every harvest I add 2 lb/1000 gal of a complete yeast nutrient 1/3 of the way through fermentation. Is that what is recommended?

A 2 lb/1000 gal addition at 1/3 of the way through fermentation may suffice, however, this depends on the specific conditions of each fermentation. To help build a nutrient supplemntation program, see the planner on pg 44.

I missed the addition of nutrients at 1/3 sugar depletion. Should I add Fermaid product past this point?

The purpose of a nitrogen addition at this point of fermentation is for re-synthesis of the sugar transport system in the yeast cell so that fermentation can continue. Ammonia uptake is inhibited above 10% alcohol. New research has shown that amino acids may be used even at a late stage. A small addition of Fermaid O or Nutrient Vit End may help. This really is a case-by-case scenario.

Some suppliers say their nutrients contain a lot more nitrogen than Fermaid O. Why?

Other suppliers may be calculating total nitrogen versus the amount of nitrogen that can be utilized by the yeast (YAN). Not all nitrogen is assimilable by yeast and not all nitrogen is utilized equally. Nitrogen supplied as amino acids from autolyzed yeast are very efficiently used. Research shows that YAN from amino acids can be four times more efficient than YAN from ammonia (DAP) (see article "Fermaid O is More Efficient than Ammonia" on pg 43). That means that an addition of 40 g/hL of Fermaid O can be calculated as having a yeast assimilable nitrogen equivalent value of 64 ppm. A 40 g/ hL addition of ammonia as a comparison gives 80 ppm yeast

assimilable nitrogen, but this is used up very quickly leading to a deficiency.

I checked my YAN and added DAP accordingly. Why do I still have offaromas and/or stuck fermentations?

Both inorganic (ammonia) and organic (amino acids and peptides) nitrogen occur naturally in grape must. Each type of nitrogen has a distinct role and impact on fermentation. While yeast may show an affinity for inorganic nitrogen, adding only ammonia (in the form of DAP) is not what is best for the yeast. A diet balanced with organic nitrogen, vitamins and minerals can produce healthier fermentations, better aromatics and lower levels of undesirable compounds.

I am noticing sulfur off-odors during fermentation — what should I do?

First, assess your nutrient program. If it is early enough in the fermentation, consider increasing your nutrient additions. Organic nutrients such as Fermaid O can go a long way in improving aromatics. If you are past the point where additional complex nutrients are recommended, run a bench trial with Noblesse and Reduless. If this is a continual problem, consider using our low- to no-H₂S strains.

As fermentation progresses, I have noticed an increased perception of 'hotness' on the finish of my wine. Are there any products that can help

Try an addition of Opti-MUM Red, Opti-WHITE or Noblesse.

My whites and rosés tend to lose their aromatic freshness quickly. What can I do to preserve the aromatics?

Inactivated yeast derivative products like Glutastar can help retain aromatic intensity and longevity.

Why don't some nutrients increase YAN?

All yeast derived nutrients will have some nitrogen to contribute to a fermentation, but different autolyzed yeast products are used for different reasons. The YAN contribution is only mentioned if the goal of the product is nitrogen supplementation and fermentation security.



MALOLACTIC FERMENTATION

acid and has a direct impact on wine quality. Uncontrolled, spontaneous malolactic fermentations or wild lactic acid reduced esters, masked aromas and off-characters. The can contribute positively to wines while minimizing risks.

Malolactic fermentation (MLF) converts malic acid to lactic importance of choosing a selected malolactic (ML) strain has increased due to evolving winemaking preferences (e.g. higher pH levels, lower SO₂, higher alcohol, etc.), as well as concerns bacteria can result in diminished varietal and fruit flavors, such as biogenic amines. The use of selected malolactic strains

SELECTING BACTERIA FOR SUCCESS

It is very important to know the properties of the wine prior to inoculating with malolactic bacteria. Analyze the wine for pH, SO,, volatile acidity (VA), residual sugar, malic acid and alcohol level. Extremes in one or more of these properties can have a compounding inhibitory effect on the growth of malolactic bacteria. For example, if a wine has low pH and high SO₂, that will be more antagonistic to the bacteria than low pH alone. Creating an optimal environment for malolactic bacteria includes:

TEMPERATURE	ERATURE ALCOHOL LEVEL pH		
Optimal: 20-25°C(68-77°F)	Optimal: <13% (v/v)	Optimal: >3.5	Optimal:
Challenging: <60°F or >85°F	Challenging: >16% (v/v)	Challenging: <3.5	free SO ₂ <10 ppm, total SO ₂ <45 ppm molecular SO ₂ <0.3 ppm Challenging: free SO ₂ >10 ppm, total SO ₂ >60 ppm molecular SO ₂ >0.3 ppm
EFFECT OF pH, SO TEMPERATURE ON ML (-	16 15 14 13 12 - 3.3 Temperature °C Alcohol % 10 - 20 18 16 14 12 20 - 30 - 40 - 50 - Total SO ₂ PPM Favorable	

VOLATILE ACIDITY (VA)

If the pH is high, other bacteria strains may already be growing, causing elevated VA The wine should be monitored for unwanted bacteria.

NUTRITIONAL STATUS

Malolactic bacteria require sugar (fructose, glucose), organic acids (malic, citric, pyruvic), organic nitrogen (amino acids, peptides), vitamins (B group, pantothenic acid) and trace minerals (Mn, Mg, K, Na). Good nutrition is important for malolactic bacteria and nutrients such as Opti'Malo Blanc and ML Red Boost will help with the growth and survival of specific malolactic bacteria. Malolactic nutrients are not as critical in a co-inoculation.

STRAIN COMPATIBILITY

Choose a yeast strain which is compatible with the selected malolactic bacteria. See MLF Compatibility in the yeast charts on pages 11–14.

MALIC AND LACTIC ACID

Measure malic acid levels. Wine conditions are difficult for bacteria if the malic level is <0.5 g/L or >7.0 g/L. The higher the malic acid levels the higher the resulting lactic acid levels which can be stressful for bacteria. Lactic acid levels of 1.5 g/L slow down bacteria and 3 g/L starts to inhibit MLF.

CHOOSING ML BACTERIA AND NUTRIENTS

A mile					Direc	ct Inoculati	on (MBR) (Cultures				Effervescent Direct Inoculation Cultures		Nut	rients	
 Highly Recommended Recommended Note: The limits shown vidually stressful. In costresses are increased aspects such as nutritible critical. 	mbination, . Other	Beta Co-Inoc	Alpha	Beta	Elios 1	MBR 31	0-MEGA	PN4	Silka	Solo Select	VP41	Malotabs	Acti-ML	Opti'Malo Plus	Opti′Malo Blanc	MI Red Boost
	Page#	57	57	58	58	58	58	59	59	59	59	60	60	61	61	60
Alcohol tolerance(% v/v))	<15.0	<15.5%	<15.0	<14.0	<14.0	<16.0	<16.0	<16.0	<16.0	<16.0	<16.0				
pH limit		>3.2	>3.2	>3.2	>3.4	>3.1	>3.1	>3.1	>3.3	>3.2	>3.1	>3.2				
Total SO ₂ limit (mg/L)		<60	<50	<60	<50	<45	<60	<60	<60	<50	<60	<60				
Temperature °C(°F)		>14° (57°)	>14° (57°)	>14° (57°)	>18° (64°)	>13° (55°)	>14° (57°)	>16° (61°)	>15° (59°)	>15° (59°)	>16° (61°)	>16° (61°)				
Relative nutrient demand	1	High	Low	High	Med	Med	Low	Med	Med	Med	Low	Low				
Typical fermentation	Start	Slow	Fast	Slow	Mod	Slow	Fast	Mod	Mod	Mod	Fast	Fast				
kinetics Finish	Finish	Fast	Slow	Fast	Fast	Fast	Fast	Fast	Mod	Mod	Fast	Mod				
Reds		٠	٨	٠	٠	٨	٨	٨	٠	٨	٠	•	٥	٨		٠
Whites and Rosé		٨	٨	٥		٨	٨	٥			٨	•	٥	٠	٥	
Fruit, Cider and Mead			٥			٠		٥					٠	٥		
Compatible with yeast co	-inoculation	٨	٥	٥	٥	٥	٥		٥	٥	٥	٥				
Higher diacetyl production	on		٥	^ *		٥		٠	٥							
Enhances mouthfeel and	fullness		۵	٥	٥			٥	٠		٨	•				
Enhances structure			٥		٠				٠	٥	٥	٥				
Enhances fruitiness and/	or spiciness	٨			٥	٠	٠	٥		•	٠					
Restart stuck or sluggish	MLF						٥			٥	٠					٥
Bacteria rehydration nut	rient												٨			
Nutrient for difficult red	MLFs															٨
Nutrient for difficult whi	te MLFs														٠	
General ML Nutrient														٨		
OMRI listed															٥	4
	ı		-		:	-	-	1	1	1	1			: :		

*when inoculated in sequential order with yeast

Wine environments are hostile. To compensate, Lallemand developed the MBR™ process which prepares the bacterial cell membranes for difficult conditions. The MBR process allows for the direct inoculation of the bacteria into the wine without any rehydration.

None of our commercial ML strains contain the decarboxylase enzymes known to produce biogenic amines. They are also cinnamyl esterase negative meaning they can't produce the precursors for ethyl phenol production by Brettanomyces.

CO-INOCULATION

Malolactic bacteria can be added early in primary fermentation, known as co-inoculation, or toward the end of primary fermentation, known as sequential inoculation (see SEQUENTIAL INOCULATION below). Adding bacteria in co-inoculation, or within 24-48 hours of adding yeast, can have many benefits. Due to the temperature development of primary fermentation, lack of alcohol, and better nutrient availability, malolactic bacteria growth conditions are more favorable and MLF can finish shortly after primary fermentation. Another benefit is the effect on flavor. Because of the reductive environment of the alcoholic fermentation, very little diacetyl (butter) aroma or flavor is produced. The resulting wines are fresh and fruity.



250 hL (6600 gal) dose #15618 \$556.00 Enoferm Beta Co-Inoc™ was specifically selected by Lallemand for reliable performance in co-inoculation of wines with

Wines that are co-inoculated have a more fruit-forward profile due to diacetyl consumption by yeast and bacteria.

pH >3.2. Not recommended for use in a sequential MLF.

Beta Co-Inoc is added to the juice/must 24-48 hours after yeast inoculation and before alcohol reaches 5% (v/v). Recommended temperature at inoculation is between 18-25°C(64-77°F) and recommended ongoing temperatures are between 15-28°C(59-82°F). Total SO₂ at crusher should not exceed 50 ppm.

Note: In co-inoculation, the health and success of the primary fermentation are keys to success. Factors such as pH, turbidity, temperature and nutrition must be considered. If the primary fermentation is sluggish or stuck, it may be necessary to add Bactiless™ (pg 90), or Lysovin (pg 89). This is especially important if the pH is over 3.5. Beta Co-Inoc is not recommended for wines with alcohol potential >15% (v/v).

Usage

Add directly to juice 24-48 hours after yeast inoculation and mix thoroughly.

Storage

Dated expiration. For short term (<18 months) store at $4^{\circ}C(40^{\circ}F)$. For long term (>18 months) store at $-18^{\circ}C(0^{\circ}F)$.

Alcohol Tolerance:		Total SO ₂ at crush: <50	once alcohol
<15%	•	ppm	>5% (v/v)

SEQUENTIAL INOCULATION

Many winemakers prefer to add malolactic bacteria toward the end of primary fermentation. This is known as sequential inoculation. In wines with pH >3.5, residual sugar can be consumed by malolactic bacteria to form volatile acidity (VA). When malolactic fermentation is conducted after primary fermentation the risk of VA is minimized. Wines made by sequential inoculation can also have higher levels of diacetyl when using certain bacteria strains (see article on "Using Timing of Inoculation to Influence Diacetyl Levels and Drive Wine Style" on page 63 for more information).



Oenococcus oeni adapted to high alcohol; enhances mouthfeel White, Red

#15601	2.5 hL (66 gal) dose	\$24.00
#15602	25 hL (660 gal) dose	\$122.00
#15603	250 hL (6,600 gal) dose	\$639.00

Enoferm Alpha $^{\text{TM}}$ was selected by the IFV (formerly ITV) from a spontaneous fermentation. It shows good fermentation activity and provides a positive sensory contribution.

It is often described as enhancing mouthfeel and complexity while reducing perceptions of green and vegetative characters.

Usage

Add directly to wine and mix thoroughly.

Storage

Dated expiration. For short term (<18 months) store at $4^{\circ}C(40^{\circ}F)$. For long term (>18 months) store at $-18^{\circ}C(0^{\circ}F)$.

Alcohol Tolerance: <15.5%	pH: >3.2	Total SO ₂ : <50ppm	Temp: >57°F
<15.5%	- 3.2	Зорріп	





Oenococcus oeni adapted to high SO₂ with positive aroma impact White, Red

#15604	2.5 hL (66 gal) dose	\$24.00
#15605	25 hL (660 gal) dose	\$122.00
#15606	250 hL (6,600 gal) dose	\$639.00

Enoferm Beta[™] was isolated in the Abruzzi wine region of Italy. Its name comes from its capacity to increase levels of beta-damascenone and beta-ionone which are compounds that contribute floral notes, particularly in Merlot. Beta contributes fruity and berry notes in Cabernet Sauvignon and can enhance diacetyl in white wines when used in a sequential fermentation.

Beta benefits from the addition of a malolactic nutrient.

Usage

Add directly to wine and mix thoroughly.

Storage

Dated expiration. For short term (<18 months) store at $4^{\circ}C(40^{\circ}F)$. For long term (>18 months) store at -18°C(0°F).

Alcohol	pH:	Total SO ₂ : <60ppm	Temp:
Tolerance: <15%	>3.2		>57°F
	••••	• • • • • • •	• • •

ELIOS 1

Oenococcus oeni adapted to high pH, contributes to tannin mouthfeel intensity

#15108	25 hL (660 gal) dose	\$108.00
#15109	250 hL (6,600 gal) dose	\$556.00

Lalvin Elios 1TM was isolated by the Institut Coopératif du Vin (ICV) from a spontaneous malolactic fermentation for use in warm region red wines with high pH.

Contributes mouthfeel to the finished wine by enhancing perception of overall tannin intensity while avoiding green and vegetative characters.

Usage

Add directly to wine and mix thoroughly.

Storage

Dated expiration. For short term (<18 months) store at $4^{\circ}C(40^{\circ}F)$. For long term (>18 months) store at $-18^{\circ}C(0^{\circ}F)$.

Alcohol Tolerance: <14%	pH >3	: Total SO ₂ : 4 <50ppm	Temp:
Tolerance. \14/0	: '3.	4 : Soppin	: ^0 4 F

MBR 31 (ALLEMAND



Oenococcus oeni adapted to low temperature and pH, enhances polyphenolic content and fruit character

White, Red, Fruit, Cider

#15022	2.5 hL (66 gal) dose	\$24.00
#15032	25 hL (660 gal) dose	\$108.00
#15127	250 hL (6,600 gal) dose	\$556.00

Lalvin 31™ was selected by the IFV for use in red and white wines. Known for its positive sensory characteristics. In reds, it may increase berry fruit flavors and mouthfeel. In whites, it is known for light buttery flavor, respect for fruit, increased body and length of finish.

It is sometimes slow to start, but finishes quickly. It performs well even under stressful conditions such as low pH (3.1) and low temperature, though not below 13°C(55°F).

Usage

Add directly to wine and mix thoroughly.

Storage

Dated expiration. For short term (<18 months) store at $4^{\circ}C(40^{\circ}F)$. For long term (>18 months) store at $-18^{\circ}C(0^{\circ}F)$.

Alcohol	Total SO ₂ :	Temp:
Tolerance: <14%	<45ppm	>55°F
	 	• • •

O-MEGA (ALLEMAND



Oenococcus oeni adapted to high alcohol and cooler temperatures

White, Red

#15615	25hL (660 gal) dose	\$122.00
#15616	250hL (6,600 gal) dose	\$639.00

O-MEGATM was selected in the south of France by the Institut Français de la Vigne et du Vin (IFV) in Burgundy for its ability to complete MLF in a wide range of applications.

Due to its late degradation of citric acid, only very low levels of diacetyl are produced. This makes it suitable for fruit-forward wines. Using this bacteria in reds helps stabilize color because of the slow degradation of acetaldehyde. Also does well in cold climate Pinot noirs. Low volatile acidity producer.

Usage

Add directly to wine and mix thoroughly.

Storage

Dated expiration. For short term (<18 months) store at $4^{\circ}C(40^{\circ}F)$. For long term (>18 months) store at $-18^{\circ}C(0^{\circ}F)$.

•••••	··::·····:::::::::::::::::::::::::::::	:	• • • • • • • • • • • • • • • • • • • •
Alcohol	pH:	Total SO ₂ :	Temp:
Tolerance: <16%	>3.1	<60ppm	>57°F

PN4 (ALLEMAND

Oenococcus oeni adapted to difficult pH, alcohol and SO₂ Red, White

#15607	25 hL (660 gal) dose	\$122.00
#15608	250 hL (6,600 gal) dose	\$639.00

PN4TM was isolated from a spontaneous malolactic fermentation in a Pinot noir by the Institute of San Michele in the Trentino region of Italy and is known for its fast fermentation kinetics.

For Chardonnay, PN4 is one of the highest diacetyl producers resulting in wines that tend to be creamy and buttery with a full, round mouthfeel. When used in sequential inoculation, more diacetyl is produced. Using PN4 on reds leads to more structured and spicy wines. PN4 can also increase the perception of fruitiness in reds which can diminish unripe characters.

Usage

Add directly to wine and mix thoroughly.

Storage

Alcohol Tolerance: <16%	Total SO ₂ : <60ppm	Temp: >61°F	

STAFF PICK

VP41 is my go-to malolactic bacteria for almost all wine styles. It is a low diacetyl producer, can ferment in high alcohol and low pH condition, and the resulting wines maintain good fruit character and mouthfeel. *Plus* it is workhorse when dealing with a stuck malolactic fermentation.

-Rebekka DeKramer, Dir of Ops, Enology & Cellar, Sonoma Co.



Oenococcus oeni adapted to high alcohol that enhances mouthfeel and oak integration

25 hL (660 gal) dose \$134.00

Lalvin Silka™ was isolated in Rioja, Spain and selected by the ICVV during an extensive research program.

Silka is recognized for its positive impact on mouthfeel and softening of astringency and bitterness. It is well-suited for wines aged in contact with oak.

Kinetics are regular and nutrient demand is moderate, so Silka would benefit from an addition of ML Red Boost nutrient (pg 60).

Usage

Add directly to wine and mix thoroughly.

Storage

Dated expiration. For short term (<18 months) store at $4^{\circ}C(40^{\circ}F)$. For long term (>18 months) store at $-18^{\circ}C(0^{\circ}F)$.

	•		:	
Alcohol	÷		Total SO ₂ :	Temp:
Tolerance: <16%	:	>3.3	<60ppm	>59°F

NEW

SOLO SELECT



Oenococcus oeni for fast fermentation, enhances structure and spice Red

#15270 25 hL (660 gal) dose	\$134.
-----------------------------	--------

Anchor Solo Select was isolated in the Yarra Valley, Australia and selected by the Australian Wine Research Institute for its good implantation rates and efficient fermentation kinetics, even in challenging conditions.

Solo Select is known to enhance dark fruit and spicy notes while enhancing structure and complexity. The production of diacetyl and volatile acidity is low due to the late degradation

This strain has a moderate nutrient demand and will benefit from ML Red Boost nutrient (pg 60). Fast and steady kinetics.


Usage

Add directly to wine and mix thoroughly.

Storage

Dated expiration. For short term (<18 months) store at Dated expiration. For short term (<18 months) store at $4^{\circ}\text{C}(40^{\circ}\text{F})$. For long term (>18 months) store at $-18^{\circ}\text{C}(0^{\circ}\text{F})$. $4^{\circ}\text{C}(40^{\circ}\text{F})$. For long term (>18 months) store at $-18^{\circ}\text{C}(0^{\circ}\text{F})$.

Alcohol Tolerance: <16%	pH:	Total SO ₃ :	:
----------------------------	-----	-------------------------	---



Oenococcus oeni adapted to high SO₂ and alcohol, enhances complexity and mouthfeel

Red, White

#15048	2.5 hL (66 gal) dose	\$24.00
#15042	25 hL (660 gal) dose	\$108.00
#15044	250 hL (6,600 gal) dose	\$556.00

Lalvin VP41™ was isolated in Italy during an extensive European Union collaboration.

Chosen for its strong implantation, steady fermentation, high alcohol tolerance (up to 16% v/v), enhanced mouthfeel and ability to improve wine structure. Both red and white wines fermented with VP41 have increased richness and complexity.

An excellent strain for restarting stuck malolactic fermentation (see Restart ML protocol page 62). At temperatures below 16°C(61°F) it is a slow starter but can complete fermentation.

Add directly to wine and mix thoroughly.

Storage

Dated expiration. For short term (<18 months) store at $4^{\circ}C(40^{\circ}F)$. For long term (>18 months) store at $-18^{\circ}C(0^{\circ}F)$.

	• • • • • • • • • • • • • • • • • • • •	· · · · · · · · · · · · · · · · · · ·	
Alcohol	pH:	Total SO ₂ :	Temp:
Tolerance: <16%	>3.1	<60ppm	>61°F

EFFERVESCENT DIRECT ADDITION BACTERIA

MALOTABS (ALLEMAND

Oenococcus oeni in tablet form for barrel additions

2.5 hL (66 gal) dose (5/box) \$150.00

Malotabs™ are an easy-to-use form of malolactic bacteria designed by Lallemand for direct addition into barrels. Malotabs dissolve immediately and are dispersed throughout the barrel. They were designed for sequential inoculations to complement fresh and fruit driven red and white wines.

Malotabs are produced from a known strain developed for good implantation, moderate to fast kinetics, and low volatile acid and diacetyl production. Red and white wines fermented with Malotabs™ show increased fruit, mouthfeel, balance and structure.

Usage

Add directly to wine.

Once opened, tablets should be used immediately. Keep unused tablets sealed and stored in their original packaging until ready for use.

STAFF PICK

I think Malotabs are really cool. Not only is this bacteria strain really tolerant to tough conditions but the ease of use is amazing! I picture myself climbing a stack of barrels back when I was an intern and the thought of being able to drop in a tablet of ML that would self-mix is just awesome.

—Annamarie "Onnie" Howard, Outside Technical Sales, Sonoma Co.

Storage

Dated expiration. For short term (<18 months) store at $4^{\circ}C(40^{\circ}F)$. For long term (>18 months) store at $-18^{\circ}C(0^{\circ}F)$.

••••••••••••••••••••••••••••

Alcohol Tolerance: <16%	pH: >3.2	Total SO ₂ : <60ppm	Temp: >61°F
----------------------------	----------	--------------------------------	-------------

MALOLACTIC BACTERIA NUTRITION

Malolactic bacteria have complex nutrient needs. If one of the essential nutrients are missing, then malolactic fermentations may struggle or stick completely. Even under ideal conditions, malolactic bacteria grow slowly. Taking care of their nutritional needs will alleviate the challenges associated with malolactic fermentation (MLF). We classify our ML strains' relative nutrient requirement as low, medium or high nutrient. See "Choosing ML Bacteria and Nutrients" chart (pg 56) for more information



Acti-ML™ is a bacteria nutrient used during rehydration. It was developed by the Lallemand Bacteria R&D team led by Dr. Sibylle Krieger-Weber. Acti-ML is a specific blend of inactive yeasts rich in amino acids, mineral cofactors and vitamins. These inactive yeasts are mixed with cellulose to provide more surface area to help keep bacteria in suspension. Acti-ML can strengthen the development of bacteria growth under difficult conditions

Recommended Dosage

Usaae

Mix Acti-ML into 5 times its weight of 20°C(68°F) chlorinefree water. Add bacteria, then wait 15 minutes before adding the suspension to the wine.

Storage

Dated expiration. Store at 18°C(65°F). Once opened, keep tightly sealed and dry.



ML Red Boost™ protects malolactic bacteria against polyphenolics in red wines that have an inhibitory effect on malolactic fermentation. This malolactic bacteria nutrient is formulated from specific inactivated yeast fractions and the availability of certain peptides and polysaccharides improves bacterial health and can reduce the duration of ML fermentation.

ML Red Boost™ is highly recommended for restarting sluggish and stuck malolactic fermentations (see protocol on pg 62).

Recommended Dosage

20 g/hL	50 g/60 gal	1.7 lb/1000 gal

Usaae

Suspend in small amount of water or wine and then add directly to the wine 24 hours before adding the malolactic bacteria. ML Red Boost should not be added to the ML rehydration water (if rehydrating ML).

Storage

Dated expiration. Store at 18°C(65°F). Once opened, keep tightly sealed and dry.

60

Malolactic nutrient for white and rosé fermentations; OMRI listed

White and Rosés

#15217 : 1 kg : \$55.00

Opti'Malo Blanc $^{\text{TM}}$ is a unique malolactic nutrient specifically formulated for white and rosé wines from a blend of selected inactivated yeasts.

Opti'Malo Blanc helps compensate for amino nitrogen and peptide deficiencies. The bioavailability of certain peptides stimulates the growth of selected bacteria and shortens the duration of MLF, especially under difficult white winemaking conditions.

Recommended Dosage

20 g/hI	50 a/60 as1	1.7 lb/1000 gal
20 g/hL	50 g/60 gal	1.7 lb/1000 gal

Usage

Suspend in small amount of water or wine and then add directly to the wine just before adding the malolactic bacteria. Opti'Malo Blanc should not be added to ML rehydration water (if rehydrating ML).

Storage

Dated expiration. Store at 18°C(65°F). Once opened, keep tightly sealed and dry.

OPTI'MALO PLUS Complete malolactic nutrient Reds, White and Rosés #15141 1 kg \$55.00

Opti'Malo PlusTM is a general-purpose MLF nutrient. It is a blend of inactive yeasts rich in amino acids, mineral cofactors, vitamins, cell wall polysaccharides and cellulose. The cellulose provides surface area to keep the bacteria in suspension and to help adsorb toxic compounds that may be present at the end of primary fermentation.

ML Red Boost™ (pg 60) is the preferred ML nutrient over Opti-Malo Plus for red wines and Opti-Malo Blanc (this page) is preferred for white and rosé wines.

Recommended Dosage

	1	1
20 g/hL	50 g/60 gal	1.7 lb/1000 gal
20 g/11L	30 g/00 gai	1./ 10/1000 gai

Usage

Suspend in a small amount of water or wine and add directly to the wine just before adding the malolactic bacteria. Opti'Malo Plus should not be added to ML rehydration water (if rehydrating ML).

Storage

Dated expiration. Store at 18°C(65°F). Once opened, keep tightly sealed and dry.

TROUBLESHOOTING GUIDE FOR MALOLACTIC FERMENTATIONS

There are many factors that can influence the success of a malolactic fermentation (MLF). Before jumping into a full restart, it's a good idea to assess each of these factors. Sometimes only a small adjustment is needed to help a MLF complete successfully. If MLF continues to struggle after considering the factors listed below, a full MLF restart may be necessary. Our MLF restart protocol is available on the next page.

WINE TEMPERATURE MIGHT BE TOO LOW

Try warming the tank or barrels; 18-20°C(64-68°F) is optimal. A MLF will progress much slower at cooler temperatures.

WINE MIGHT BE LACKING NUTRIENTS

Try adding an ML-specific nutrient like ML Red Boost™ or Opti'Malo Blanc™ (pages 60 and 61, respectively).

WINE MIGHT NEED A DETOX

If you've already done a nutrient addition, the bacteria should have what it needs. Sometimes toxins can be present that impede the success of an MLF. Reskue[™], a specific inactivated yeast for treating stuck fermentations, can be extremely beneficial for detoxification. Reskue should be added and racked after 48 hours (dosage and usage information on page 49).

WINE CHEMISTRY MIGHT BE CHALLENGING OR INHIBITORY TO THE BACTERIA

It is essential that you check your pH, alcohol, and free and total SO_2 to see if one of these factors might be inhibiting the fermentation. Winemakers are often surprised by the amount of SO_2 in a wine when they've added little to no SO_2 . SO_2 can come from several sources including: yeast during alcoholic fermentation, vineyards, old barrels, or erroneous

cellar additions. Total SO_2 is just as important to check. SO_2 is often bound to acetaldehyde and when bacteria consume acetaldehyde, free SO_2 is liberated which can inhibit MLF. If wine chemistry is challenging, make sure you've inoculated with a strain that can handle the challenges.

THERE MAY NOT BE ENOUGH HEALTHY OENOCOCCUS OENI TO GET THE JOB DONE

If you did not inoculate with *Oenococcus oeni*, there may not be enough healthy bacteria to complete MLF. Consider inoculating with a known strain that is appropriately suited to handle the chemistry of your wine. If you've already inoculated, and the wine has low turbidity, it's possible that the bacteria are struggling to stay in suspension. Try stirring your tanks or barrels more frequently.

YOU MIGHT JUST NEED TO GIVE IT MORE TIME

MLF can be a test of patience taking weeks, or even months, to complete. To determine if MLF is complete, malic acid must be measured — it's nearly impossible to determine completion by sensory analysis — and is considered complete when malic acid is ≤ 0.1 g/L (some say ≤ 0.2 g/L). If initial malic acid content was high (>7.0 g/L) then lactic acid produced by MLF may be high. Lactic acid levels >3g/L can inhibit ML bacteria.

HOW TO

RECOMMENDED METHOD TO RESTART A STUCK MALOLACTIC FERMENTATION

PREPARE THE STUCK WINE

- 1. Add 30 g/hL (2.5 lb/1000 gal) of Reskue[™] prior to restarting. Suspend Reskue in 10 times its weight of warm water 30–37°C(86–98°F) (see pg 49 for more about Reskue). Wait 20 minutes then add to stuck wine.
- 2. Allow tank to settle for 48 hours then rack off the settled lees.
- 3. Adjust temperature of Reskue-treated wine to 18–22°C(64–72°F).


MALOLACTIC ACTIVATOR ADDITION

- 4. Add 20 g/hL (1.7 lb/1000 gal) of ML Red Boost™ to Reskuetreated wine. When restarting a stuck MLF, ML Red Boost is used for white, red, and rosé wines.
- 5. Mix gently and wait 24 hours before bacteria addition.

MALOLACTIC BACTERIA ADDITION

- 6. Add a double dose of Lalvin MBR VP41™ direct inoculation culture (Example: for 1000 gallons, add 3 x 25hL (660 gal) packets).
- 7. Check for MLF activity by analyzing L-malic acid degradation every 2–4 days.

62



USING TIMING OF INOCULATION TO INFLUENCE DIACETYL LEVELS AND DRIVE WINE STYLE

Figure 2:

Malolactic fermentation is more than a simple conversion of malic acid to lactic acid. The ability of the malolactic bacteria, Oenococcus oeni, to affect wines in a positive way, both texturally and sensorially, is now being used to influence wine aromas and drive wine style. Common terms used to describe the positive effect of MLF on wine flavor are fruity, spicy, toasty, nutty and buttery. The butter aroma is due to diacetyl, an intermediate metabolite in the metabolism of citric acid (see Figure 1). High diacetyl concentrations in wine can be perceived as overtly 'buttery' and may be regarded as undesirable by consumers. Lower diacetyl concentrations, depending on wine type and style, can contribute a desirable 'buttery' or butterscotch flavor character.

The timing of inoculation has a strong impact on diacetyl levels. In citric acid metabolism, pyruvic acid is decarboxylated to diacetyl via an α -acetolactate intermediate (see figure 1).

Diacetyl is chemically unstable and can be reduced further by active O. oeni and yeast to less flavor-active products (acetoin and 2,3-butanediol). When ML bacteria is added 24-48 hours after yeast inoculation and alcoholic and malolactic fermentations occur together (co-inoculation), diacetyl is converted to the less buttery compounds resulting in fruitier wines.


Using a co-inoculation strategy in white wine or red wines is a powerful tool to enhance fresh, fruit-driven styles and to avoid the production of diacetyl, even with bacteria known for high diacetyl production (see Figures 2 and 3).

If high diacetyl concentrations are desired, a sequential inoculation of O. oeni after alcoholic fermentation will promote the retention of diacetyl. The potential of diacetyl production is strain dependent (see Figure 2). For protocols to increase or decrease diacetyl go to www.scottlab.com.

Effect of ML Strain on Diacetyl Concentration

Figure 1:

CITRIC ACID METABOLISM



OUR MBR™ MALOLACTIC BACTERIA CAN HANDLE TEMPERATURE CHALLENGES: A STUDY OF THE EFFECT OF SHIPPING AND STORAGE TEMPERATURE ON MALOLACTIC VIABILITY RATE

We recommend that our malolactic bacteria be kept cool. In fact, our recommendation is that bacteria be kept at -18°C/0°F for long-term storage. In the real world we know that bacteria can get warm during shipment and that not all wineries have perfect storage. The winemaker's question then becomes: "How can I be confident that my malolactic culture is in good shape?" This is a good question and deserves a good answer. Lallemand's unique malolactic bacteria processing methods, called MBRTM, have created important advantages. One advantage is that MBR cultures have very low water activity and are therefore more tolerant of moderate temperature variations when compared to other strain formats (frozen, liquid, etc.).

Lallemand ran studies to determine the effect of transport temperatures on MBR bacteria survival rate. Figure 1 shows the temperatures applied to bacteria during two simulated transport scenarios. The viability (survival rate), malolactic activity and water activity (directly linked to shelf life) were all tested. Results in both cases showed that MBR bacteria cell viability, malolactic activity, and shelf life were preserved.

Lallemand also tested the impact of moderate summer storage temperatures on MBR bacteria viability (see Fig. 2).

The results showed good tolerance to short-term temperature exposure. Even after two weeks at 30°C(86°F) viability remained over 60% and over the guaranteed viable cell count of 10¹¹ CFU/g.

CONCLUSION

If despite our best efforts, the ice is melted and the container is not cold to the touch when your bacteria arrives, do not be alarmed. Lallemand's proprietary manufacturing process means their bacteria are different. Provided that temperature variations are moderate (e.g. 30°C/86°F for less than 48 hours) viability should be excellent. In fact, sealed packets can be delivered and stored for 3 weeks at ambient temperature (<25°C/77°F) without critical loss of viability. So just put the bacteria in the cooler (-18°C/0°F is preferred, 4°C/40°F is acceptable) and keep it there until you need it.

Finally, we wish to emphasize that in spite of the superior temperature tolerance of Lallemand bacteria, cold is always preferred. To limit temperature variation, Lallemand ships MBR bacteria to Scott Laboratories by refrigerated transport. We ship to our customers overnight with icepacks. We ask that you store it cold. Such efforts will always have a positive impact on cell viability and malolactic activity.

Fig. 1: Temperature Profile Applied to MBR™ Bacteria in Two Simulated Transport/Storage Scenarios





Fig. 2: Impact of 30°C/86°F Storage Temperature on MBR Bacteria Viability Rate

TIME (WEEKS)

In both transport/storage scenarios, MBR bacteria cell viability, malolactic activity, and shelf-life were maintained. MBR bacteria are resistant to moderate temperature fluctuations!



Lallemand guarantees 55% viability which equates to 1011 CFU/g standard set forth by

Note: This graph is shown for illustrative reasons. We do NOT recommend that our customers store Lallemand MBR bacteria cultures at such temperatures after receipt

/	O-Mega	VP41	Lalvin 31	Alpha	Silka	Elios 1	Beta	PN4	
Less Diacetyl	Very low producer	Only attacks citric acid after completion of malic acid	Medium to low producer	Medium producer	Medium producer	Medium producer	High producer when used in sequential inoculation	Early attack of citric acid	More Diacetyl

FREQUENTLY ASKED QUESTIONS: MALOLACTIC BACTERIA & ML NUTRIENTS

Can I use half a sachet of bacteria now and save the other half to use later?

No. Once the sachet of bacteria is opened it must be used immediately. Exposure to oxygen and excess moisture can be detrimental to the survival of the bacteria.

My bacteria arrived and the ice pack has melted. How can I be confident that my malolactic culture is in good shape?

We ship bacteria overnight with ice packs. If, despite our best efforts, the ice pack has melted and the container is not cold to the touch when your bacteria arrive, **do not be alarmed**. Lallemand's proprietary manufacturing process means its bacteria is stable. Sealed packets can be delivered and stored for a few weeks at ambient temperature ($<25^{\circ}\text{C}/77^{\circ}\text{F}$) without significant loss of viability. Place the bacteria in the freezer ($-18^{\circ}\text{C}/0^{\circ}\text{F}$ is preferred but up to $4^{\circ}\text{C}/40^{\circ}\text{F}$ is acceptable) and store until you need it.

I would like to have less diacetyl in my white wines. Which strain should I choose?

High inoculation levels of neutral strains like O-MEGATM and Lalvin MBR VP41TM, will help control excessive diacetyl production. Co-inoculate by adding bacteria one day after yeast addition (if the pH is under 3.5). The diacetyl will be consumed by the yeast and bacteria. Leaving wine on the lees will also reduce diacetyl levels, as does conducting the MLF at warmer temperatures (24°C/75°F compared to 17°C/63°F). See article on page 63 for more information.

Can I use citric acid to acidulate my wine for increased diacetyl formation?

We do not recommend that you use citric acid for acidification before MLF is finished. Citric acid can promote acetic acid in addition to diacetyl formation during malolactic fermentation. If increased diacetyl is the goal, choose a bacteria strain that is a known diacetyl producer such as Enoferm BetaTM or MBR PN4®. See article on page 63 for more information.

Why is my malolactic fermentation not finishing?

Check wine parameters (free and total SO₂, alcohol, pH, VA, malic acid and temperature) to determine if there is an obvious reason that the fermentation is not completing. Pesticide and fungicide residue, juice concentrates and preservatives in juice or wine can also inhibit malolactic bacteria, as can lack of essential nutrients. See "Troubleshooting Guide for Malolactic Fermentations" on page 61 for more information.

When is my ML complete?

There is some controversy among wine scientists and professionals regarding this topic. At Scott Laboratories we think that MLF is complete when malic acid is ≤ 0.1 g/L. Others say that MLF is complete when malic acid is ≤ 0.2 g/L. See "Troubleshooting Guide for Malolactic Fermentations" on page 61 for more information.

Does the yeast strain used for primary fermentation affect the malolactic fermentation?

Yes. Some yeast strains are harder for malolactic fermentation than others. Yeast strains differ in nutrient demand, production of SO_2 and rate of autolysis which has a resulting effect on the bacteria. Please refer to the yeast charts on pages 11-14 for their MLF compatibility ratings.

Does my bacteria need nutrients?

Unfortunately, there are no analytical tools to determine nutrient deficiencies for bacteria. Bacteria need amino acids (not ammonium salts), peptides, vitamins and minerals to complete a successful MLF. Each strain of bacteria, like yeast, has specific requirements. See "Choosing ML Bacteria and Nutrient Chart" on page 56 and "Troubleshooting Guide for Malolactic Fermentations" on page 61 for more information.

How do I choose the correct strain of bacteria for my wine?

Each bacteria strain performs best within specific environmental parameters. Consider free and total SO₂ levels, pH, alcohol, and temperature constraints as well as malic acid concentration when choosing a ML strain (see page 56 for more information).

Why does the total SO2 need to be measured when choosing the correct strain of bacteria?

 ${
m SO}_2$ can be bound to acetal dehyde. Bacteria can break that bond, increasing free ${
m SO}_2$, making the wine environment more challenging for MLF.

I have tried everything to get my wine through MLF but nothing is working. What should I do?

Sometimes MLF might not be possible in certain wines. However, before giving up, consult the "Troubleshooting Guide for Malolactic Fermentations" on page 61 to make sure that all the factors have been considered.

I'm thinking of trying co-inoculation. Which bacteria strain should I use?

Enoferm Beta Co-InocTM (page 57) was developed by Lallemand for use in co-inoculation. Due to its slow growth, there is less risk of malolactic fermentation finishing before primary. Therefore, there is also less risk of volatile acid production resulting in timely completion of both fermentations.

If I am doing a co-inoculation, which bacteria nutrient do I need? When should I add it, and how much should I add?

As long as you have a good yeast nutrient strategy and add complex nutrients for primary fermentation, additional ML nutrients aren't always necessary. If wine conditions are very difficult — low pH (<3.2), high alcohol (>15.5 % v/v), high SO_2 (>45 mg/L total or 5 mg/L free SO_2) — and MLF has not started by the end of alcoholic fermentation, ML nutrient additions are recommended. Add 20 g/hL of ML Red BoostTM (pg 60) for structured red wines or 20 g/hL Opti'ML BlancTM (pg 61) for white wines.

ARTICLE

Chardonnay is the most popular white wine produced. Visit any wine region in the world, and there is at least one vineyard growing this grape. The wine can be simple or complex, aged for many years or consumed immediately. Chardonnay originally came to popularity in the Burgundy region of France, where it became known for its elegance and complexity. Other regions planted the variety as grow-

ers soon realized that the grape was relatively easy to grow, and winemakers could use a range of different winemaking techniques. Chardonnay is truly a grape that can be made into wines of many different styles.

Chardonnay produced in relatively hot growing regions, such as the interior valleys of California, South Africa and Australia, can produce wines with tropical fruit fla-

vors and even some suggestion of oakiness. In cooler wine regions, such as Chablis, Carneros and Tasmania, wines can be apple-crisp juice with razor sharp acidity. The best of which can benefit from five or more years in bottle to soften that acidity and develop rounder flavors for balance.

There are a number of protocols winemakers can use to create the Chardonnay style that fits their winery's portfolio and their consumer's preference the best.

For any particular style, factors to take into consideration are: turbidity (NTU), yeast strain, fermentation temperatures, additions of inactivated yeasts, nutrient regimes and malolactic fermentation choices. Below are some recommendations for achieving a desired Chardonnay profile.

	MINERAL PROFILE	FRUITY PROFILE	TROPICAL/CITRUS PROFILE	BARREL-FERMENTED PROFILE		
SOLIDS (TURBIDITY) GOAL	50-80 NTU	60-80 NTU	80-100 NTU	100-120 NTU		
REHYDRATION NUTRIENT	Go-Ferm Protect Evolution™ at 30 g	g/hL (2.5 lb/1000 gal) (pg 45)				
YEAST STRAIN at 25 g/hL (2 lb/1000 gal)	Lalvin W15™ (pg 32) or Lalvin DV10™ (pg 22)	CVW5 (pg 21), Cross Evolution™ (pg 21) or VIN 2000 (pg 32) (if mouthfeel volume is desired)	Lalvin QA23™ (pg 28) or Exotics Novello (pg 23)	Lalvin CY3079™ (pg 22) or Lalvin ICV D47™ (pg 22)		
FERMENTATION TEMPERATURE GOAL	15-18°C(59-65°F) 18-20°C(65-68°F)		18-20°C(65-68°F)	18-22°C(65-72°F)		
JUICE ADDITIONS	Glutastar™ at 30 g/hL (3 lb/1000 ga	ıl) (pg 51)				
NUTRIENT ADDITION at 2-3 °Brix drop	DDITION if YAN <150 ppm then: if YAN <150 ppm then: Stimula Sauvignon Blanc™ fermaid O 10 g/hL Fermaid O™ (pg 49) 10-40 g/hL 40 g/hL (3.3 lb/1000 gal) (Stimula Sauvignon Blanc™ 40 g/hL (3.3 lb/1000 gal) (pg 47)	if YAN <150 ppm then: Fermaid O 10-40 g/hL (1.67 - 3.3 lb/1000 gal)		
NUTRIENT ADDITION at 1/3 °Brix drop	Fermaid 0 10-40 g/hL (1.67 - 3.3 lb/1000 gal)	Stimula Chardonnay™ 40 g/hL (3.3 lb/1000 gal) (pg 46)	Fermaid 0 10-40 g/hL (1.67 - 3.3 lb/1000 gal)	Fermaid 0 10-40 g/hL (1.67 - 3.3 lb/1000 gal)		
ML STRAIN CHOICE (if desired)	O-MEGA™ (pg 58) Sequential inoculation and partial degradation	Beta Co-Inoc™ (pg 57) Simultaneous ALF and MLF	No MLF	Enoferm Beta™ (pg 58) Sequential inoculation		

WINE STYLE GUIDE: CHARDONNAY

^{*} Avoid DAP any time fruit flavors are desired.





OAK AND TANNINS

Scott Laboratories offers a varity of tannins and oak infusion distinct functions and all provide some degree of protection assist in improving wine quality. from oxidation. We also offer oak chips and oak infusion

products with multiple toast profiles to boost oak aroma and products to provide winemakers flexible tools to achieve flavors, structure, and color. Our proprietary Thermic range of wine-style goals. Sources of tannin include oak (American, oak infusion products from the Oak Lab™ positively impacts European, toasted, untoasted), grapes (skin and seeds), weight, length, and complexity of wine. Whether oak infusion chestnut, gall nuts and exotic woods. Each of these tannins have or tannin products, Scott Laboratories has a broad portfolio to

SELECTING OAK & TANNINS FOR SUCCESS

The goal of using oak and tannins is to bring out the best that grapes have to offer from the moment they enter the winery. Oak and tannins can be used in all aspects of winemaking and their selection is determined by the state of the grapes, juice or wine, the grape variety, and the intended wine style. Tannins and oak can affect structure, aroma, provide protection against oxidation and promote color stability. They can also be used to mask greenness and enhance fruit characters. Use of oak and tannins in aging and finishing are especially useful in wines that may lack structure, complexity and balance.

STABILITY

Fermentation tannins, which are generally a mix of condensed and ellagic tannins, combine with the anthocyanins to create optimal color stability. In protein-rich grape varieties, some of the gall nut derived tannins can help remove proteins. Tannins help protect juice from browning, especially in grapes affected by Botrytis and other rot. They act as an antioxidant and inhibit laccase.

STRUCTURE AND BALANCE

Untoasted oak chips added during fermentation can reinforce the structure of the juice, bringing length and perceived sweetness to the finished wine. Toasted oak chips can minimize the impact of astringency due to underripe fruit. Likewise, fermentation tannins added early can help mask greenness and build structure in a wine that is lacking in tannin. Oak infusion products and finishing tannins can be used during cellaring and aging, or as last-minute wine additions to bring balance, complexity and structure.

AROMA

The use of tannins and oak can positively impact aromas in almost all stages of winemaking. Tannins can reveal and enhance aromas and mask some undesired green/herbaceous characters. The addition of oak infusions can affect the ripe fruit profiles, and integrate wood and oak characters to balance the aromatic profile of the wine.

CHOOSING OAK AND TANNINS

								Tannin	S								0ak	
 ♦ Highly Recommended ♦ Recommended 		FT Blanc	FT Blanc Citrus	FT Blanc Soft	FT ColorMax	FT Rouge	FT Rouge Berry	FT Rouge Soft	Onyx	Radiance	Riche	Riche Extra	Royal	Uva'Tan	Uva'Tan Soft	Feelwood! Balance & Structure	Feelwood! Sweet & Fresh	Thermic – all profiles(1-5)
Page#	69	69	69	70	70	71	71	71	72	72	73	73	73	74	74	75	75	76
Reds	•	٥		٥	٥	٠	٠	٠	٨	٥	٠	٥	٥	٠	٥	٠	٨	٨
Whites and Rosé	٥	٠	٠	٠						۵	٥	٥	٥	٥	٥	٠	٨	٥
Fruit, Cider and Mead		٠	٠	٠		٥		٠		۵								٥
Protection from oxidation for white wine		٠	٨	٥														
Mouthfeel enhancement for white wine			٨	٥						٥						٥	٥	٥
Grape tannin														٥	٠			
Enhances structure	٠	٥	٥	٥		٠	۵	٥			٠	٥	٥	٥	٠	٠		٥
Enhances mid-palate volume	٠				٠	٠	٨	۵						٥	٠		٥	٠
Enhances aromatic potential			٥				۵			٠			٠				٥	٠
Stabilizes color					٠	٥	٥	٥						٥	٥			
Enhances fruit			٨				۵		٥	٥							٥	٥
Mitigates green, unripe chararacters						٥	۵	۵	٥			٥	٥			•	٥	٥
Vanillin oak character									٥	٥	٠	٥						٥
Protects grapes with rot		٠	٠	٠		٠	٠	٠										
Enhances aging potential	•	٥		٥	٥	٥	٠	٥						٥	٥			٨
Perception of sweetness											۵	٥						٥
Lowers perception of alcohol											٠	٥						
Rapid integration									٠	٠			٠					٠
Used during fermentation		٠	٠	٠	٠	٠	٨	٨								٠	٠	٥
Used during aging	٠										٥	٥		٥	٥			٥
Used for finishing			٨	٨			٨		٨	٨	٨	٨	٨					٥

70

A winemaker's goal is to showcase the grapes. This begins the moment the fruit enters the winery and continues until the wine is bottled. Tannins can be used to enhance aromas, mouthfeel, stabilize color and add structure.

ESTATE O Mid-palate volume enhancement during aging White, Rosé, Red

±15958 : 1 kg : \$140.00

Scott'Tan™ Estate can help compensate for lack of tannins in finished wine without the "dryness" associated with barrels. It enhances mid-palate, complexity and balance while providing a measure of antioxidant protection. Fruit characters can be enhanced. Estate is especially recommended when using older, tannin-depleted barrels.

Dosage

Prior to Barrel Aging Red Wine

50-300 ppm	5-30 g/hL	0.42-2.5 lb/1000 gal
Prior to Bottling (3–6 weeks) or During Racking		
50-100 ppm	5-10 g/hL	0.42-0.83 lb/1000 gal

Note: Estate is best used prior to barrel aging. This encourages tannin integration in the wine over time. It may also dramatically improve a red wine when added prior to bottling. Successful additions can be made closer to bottling, but this may result in less throughput during filtration.

Usage

During transfer or racking add Estate into the wine. Mix well to ensure homogeneity. Following organoleptic evaluations, 2–3 further additions can be made subsequent to rackings. Additions should be made at least 6 weeks before bottling to allow for polymerization and settling.

Storage

Dated expiration. Unopened, the shelf-life is 5 years at $18^{\circ}C(65^{\circ}F)$. Once opened, keep tightly sealed and dry.

Stage of Winemaking: Aging	Minimum Cont Time: 6 week	· · · · · · · · · · · · · · · · · · ·
	•••••	• • • • •
	FT BLANC O)
Prote	ection from oxidation	n
White,	Rosé, Red, Fruit, Cic	ler
:	:	
#15954	1 kg	\$51.00
#15969	5 kg	\$225.00

Scott'TanTM FT Blanc tannin is a white gall nut tannin specifically formulated for use on grapes with mold or rot (e.g. Botrytis). It helps protect juice from browning by acting as an

antioxidant and inhibiting laccase activity. On sound grapes, FT Blanc is an effective antioxidant when used with SO_2 . In protein-rich grape varieties such as Sauvignon blanc, FT Blanc can help remove proteins. In some wines it will also contribute notes of minerality.

Dosage			
White/Rosé Juice			
50-150 ppm	5-15 g/hL	0.42-1.2 lb/1000 gal	
Red Wine			
50-300 ppm	5-30 g/hL	0.42-2.5 lb/1000 gal	
Fruit, Cider, Mead			
50-200 ppm	5-20 g/hL	0.42-1.6 lb/1000 gal	
White/Rosé Wine*			
50-300 ppm	5-30 g/hL	0.42-2.5 lb/1000 gal	

*A small addition of 2.5-5.0 g/hL(0.21-0.42 lb/1000 gal) may help mask the perception of bitterness in a finished wine.

Usage

Add FT Blanc by sprinkling directly on grapes at the crusher, adding to juice, or adding to wine during a tank mixing. Good homogenization is important. If an addition is made post-fermentation, we recommend waiting 3–6 weeks after the tannin addition before racking, fining, filtering or bottling.

Storage

Dated expiration. Unopened, the shelf-life is 5 years at $18^{\circ}\text{C}(65^{\circ}\text{F})$. Once opened, keep tightly sealed and dry.

Finishing	••••••	•••
Stage of Winemaking: Fermentation,	Minimum Contact Time: 3 weeks	Impact: Antioxidant

FT BLANC CITRUS C Enhances fruity and floral aromas

White, Rosé, Cider

#15974	1 kg	\$118.00
#15975	5 kg	\$505.00

Scott'TanTM FT Blanc Citrus is a mixture of condensed tannins extracted from citrus wood and gallic tannins. The use of FT Blanc Citrus during alcoholic fermentation in combination with yeast strains that have beta-glycosidase activity (Alchemy II, Lalvin 71BTM, VIN 2000, Lalvin Rhône 4600TM, VIN 13, Lalvin QA23TM and Vitilevure 58W3TM), allows for the development

of enhanced aromatic potential. Resulting wines present more intense aromas of lemon, grapefruit, apple and white flowers, which complement varietal and fermentation aromas. FT Blanc Citrus also protects the must and wine from oxidation.

Dosage

White, Cider		
20-150 ppm	2-15 g/hL	0.17-1.2 lb/1000 gal
Rosé Must		
50-150 ppm	5-15 g/hL	0.42-1.2 lb/1000 gal

Usage

Add FT Blanc Citrus within 24–48 hours after yeast inoculation to maximize the benefit of its aromatic precursors. Dissolve in ten times its weight of water before adding.

Storage

Dated expiration. Unopened, the shelf-life is 5 years at 18°C(65°F). Once opened, keep tightly sealed and dry.

Stage of Winemaking: Fermentation, Finishing	Minimum Contact Time: 3 weeks	Impact: Aromatic Enhancement
	•••••	• • • • •

FT BLANC SOFT O

Oxidation protection and mouthfeel enhancement

White, Rosé, Red, Fruit, Cider, Mead

#15955	1 kg	\$74.00
#15980	5 kg	\$331.00

Scott'TanTM FT Blanc Soft combines the benefits of FT Blanc (see pg 69) with improved softness and mouthfeel. White and rosé wines made with FT Blanc Soft have enhanced texture with a perception of sweetness on the palate. Even relatively small dosages can contribute to minerality in wines. Similar improvements can be seen in fruit and mead wines.

Dosage

White/Rosé Juice		
50-150 ppm	5-15 g/hL	0.42-1.2 lb/1000 gal
	Red Wine	
50-300 ppm	5-30 g/hL	0.42-2.5 lb/1000 gal
Fruit, Cider, Mead		
50-200 ppm	5-20 g/hL	0.42-1.6 lb/1000 gal
White/Rosé Wine*		
50-300 ppm	5-30 g/hL	0.42-2.5 lb/1000 gal

^{*}A small addition of 2.5-5.0 g/hL(0.21-0.42 lb/1000 gal) may help mask the perception of bitterness in a finished wine.

Usage

Add FT Blanc Soft by sprinkling directly on grapes at the crusher, adding to juice, or adding to wine during a tank mixing. Good homogenization is important. If an addition is made post-fermentation, we recommend waiting 3–6 weeks after the tannin addition before racking, fining, filtering or bottling.

Storage

Dated expiration. Unopened, the shelf-life is 5 years at 18°C(65°F). Once opened, keep tightly sealed and dry.

Stage of Winemaking:	Minimum	Impact:
Fermentation,	Contact	Antioxidant
Finishing	Time: 3 weeks	and Mouthfeel
	COLORMAX Cote color stability Red, Fruit)

Scott'TanTM FT ColorMax is a natural catechin product developed for its superior ability to stabilize color. Its special formulation goes into solution more easily than conventional fermentation tannin products. It is intended for use in conjunction with FT Rouge or FT Rouge Soft (pg 71). Wines made with FT ColorMax tend to have a softer palate than those made with FT Rouge alone.

1 kg

Dosage			
Red Must			
100-300 ppm	10-30 g/hL	0.8-2.5 lb/1000 gal	

Usage

Add FT ColorMax at 1/3 sugar depletion during alcoholic fermentation. If a cold soak has been done, add FT ColorMax during the first pump-over.

Storage

Dated expiration. Unopened, the shelf-life is 5 years at 18°C(65°F). Once opened, keep tightly sealed and dry.

Stage of Winemaking: Fermentation	Contact Time: During fermentation	Impact: Color Stability
---	---	----------------------------

FT ROUGE O

Promotes color, structure and fruit

Red, Fruit

#15950	1 kg	\$41.00
#15951	5 kg	\$163.00

Scott'Tan™ FT Rouge is a proprietary tannin which is a blend of highly reactive tannins derived from exotic woods and chestnut. The addition of FT Rouge at the beginning of red wine fermentation helps preserve the grapes' natural tannins so they can combine with anthocyanins to create optimal color stability. Mouthfeel is also enhanced. FT Rouge provides antioxidative protection and may inhibit oxidative enzymes (such as laccase) associated with browning.

Dosage

Red Vinifera Must		
200-500 ppm	20-50 g/hL	1.6-4.0 lb/1000 gal
Red Non-Vinifera Must		
300-600 ppm	30-60 g/hL	2.5-5.0 lb/1000 gal
Fruit		
200-500 ppm	20-50 g/hL	1.6-4.0 lb/1000 gal

Usage

Gradually pour directly on grapes at the crusher or add to the must during a pump-over to obtain good homogenization. If subsequent additions are desired, this can be done in increments of 0.5 lb/1000 gal (~60 ppm) during pump-overs. If an addition is made post-fermentation, we recommend waiting 3-6 weeks after the tannin addition before racking, fining, filtering or bottling.

Storage

Dated expiration. Unopened, the shelf-life is 5 years at 18°C(65°F). Once opened, keep tightly sealed and dry.

Stage of :	Contact	Impact: Color
Winemaking:	Time: During	Stability;
Fermentation	fermentation	Structure

STAFF PICK

I think the FT Rouge Berry smells lovely! —Teniya Schipper, Inside Sales, based in Paso Robles, CA



Enhances red berry fruit, diminishes vegetative notes Rosé, Red, Hybrids

#15972	1 kg	\$118.00
#15072	5 kg	Ø505.00

Scott'Tan™ FT Rouge Berry is a mixture of condensed tannins extracted from the wood of red berry plants. The use of FT Rouge Berry during alcoholic fermentation in combination with yeast strains that have beta-glycosidase activity (Lalvin 71B™, Lalvin ICV GRE™) allows for the development of enhanced red berry characters. Resulting wines present intense aromas of cherry, strawberry, and blueberry, which complement varietal and fermentation aromas. FT Rouge Berry can also diminish green/vegetative notes in underripe fruit.

FT Rouge Berry promotes the stabilization of color and prevents oxidation of the primary aromas.

Dosage

	Rosé Must	
20-150 ppm	2-15 g/hL	0.17–1.2 lbs/1000 gal
	Red Must	
50-200 ppm	5–20 g/hL	0.42–1.6 lbs/1000 gal

Usage

Add FT Rouge Berry at the first pump-over or punch-down, or 24-48 hours after yeast inoculation. Dissolve in ten times its weight of water before adding.

Storage

Dated expiration. Unopened, store in a cool dry, ventilated area. Once opened, carefully reseal and use within the same harvest. ••••••••••••••••••••••••••••••••

Stage of	: Minimum Contact	Impact:
Winemaking:	Time: During	Aromatic
Fermentation	fermentation	enhancement



FT ROUGE SOFT •

Promotes color, mouthfeel and fruit

#15952	1 kg	÷ \$46.00
#15953	5 kg	Ø175.00

Scott'Tan™ FT Rouge Soft is a proprietary tannin specifically formulated for its gentle impact. It is particularly suitable for Pinot noir and early-to-release wines. FT Rouge Soft is reactive with natural grape proteins and thus helps promote optimal color and color stability while enhancing structure. Mouthfeel and roundness are improved while the potential for bitter characters is reduced.

FT Rouge Soft provides antioxidative protection.

Dosage

Red <i>Vinifera</i> Must		
200-500 ppm	20-50 g/hL	1.6-4.0 lb/1000 gal
Red Non-Vinifera Must		

Red Non-Vinifera Must		
300-600 ppm	30-60 g/hL	2.5-5.0 lb/1000 gal
	Fruit	
200-500 ppm	20-50 g/hL	1.6-4.0 lb/1000 gal

Usaae

Gradually pour directly on grapes at the crusher or add to the must during a pump-over to obtain good homogenization. If subsequent additions are desired, this can be done in increments of 0.5 lb/1000 gal (~60 ppm) during pump-overs. If an addition is made post-fermentation, we recommend waiting 3-6 weeks after the tannin addition before racking, fining, filtering or bottling.

Storage

Dated expiration. Unopened, the shelf-life is 5 years at 18°C(65°F). Once opened, keep tightly sealed and dry.

ONVX O		
Fermentation	fermentation	Mouthfeel
Winemaking:	Time: During	Stability,
Stage of	Contact	Impact: Color
••••••		

French oak for "last minute" complexity and flavor integration Red, Rosé

#15977 \$145.00

Scott'Tan™ Onyx is derived from French oak. It was designed for use in red and rosé wines to bring out berry and sweet red fruit notes. Onyx is known for maintaining varietal characteristics while adding complexity and minimizing greenness. It helps soften and integrate flavors.

Onyx integrates rapidly and is great for "last-minute" additions. Can be added up to 48 hours before membrane (final) filtration. Always conduct filterability trials prior to addition to avoid filtration challenges.

Dosage	
1-10 g/hL	0.08-0.83 lb/1000 gal

Usaae

10-100 ppm

Dissolve Onyx in about ten times its weight of warm water 35-40°C(95-104°F) until fully dissolved. Add to wine gradually during a transfer or pump-over. Good mixing is important.

Storage

Dated expiration. Unopened the shelf-life is 4 years at 18°C(65°F). Once opened, keep tightly sealed and dry.

Stage of Winemaking: Pre-bottling	Minimum Contact Time: 48 hours	Impact: Complexity, Integration
· · · · · · · · · · · · · · · · · · ·		

RADIANCE O



Tannin blend for "last minute" fresh fruit highlights White, Red, Rosé, Cider

\$145.00

Scott'Tan™ Radiance is a blend of tannins for use in white, red and rosé wines as well as ciders. It will help unmask and refine aromas and flavors of fresh fruit, vanilla, coconut and caramel. Radiance promotes balance and mouthfeel while maintaining acidity.

Radiance integrates rapidly and is great for "last-minute" additions. Can be added up to 48 hours before membrane (final) filtration. Always conduct filterability trials prior to addition to avoid filtration challenges.

Dosage

10-100 ppm	1–10 g/hL	0.08-0.83 lb/1000 gal

Usage

Dissolve Radiance in about ten times its weight of warm water 35-40°C(95-104°F) until fully dissolved. Add to wine gradually during a transfer or pump-over. Good mixing is important.

Storage

Dated expiration. Unopened the shelf-life is 4 years at 18°C(65°F). Once opened, keep tightly sealed and dry.

Stage of Winemaking: Pre-bottling	Minimum Contact Time: 48 hours	Impact: Mouthfeel, Aromas
---	-----------------------------------	---------------------------------

Scott'Tan™ Riche is a cellaring and finishing tannin notable for enhancing complexity. Derived from 100% toasted French oak, Riche imparts hints of coconut and vanilla together with a perception of sweetness. It can contribute the final touch to your wine.

Dosage

	White/Rosé Wine	e
m	3-10 g/hL	0.25-0.83 lb/1000 gal

30-100 ppr

Red Wine		
30-200 ppm	30-20 g/hL	0.25-1.6 lb/1000 gal

Usaae

Dissolve in about 10 times its weight of warm water (35-40°C/95-104°F) then add it to the wine and mix well. Good homogenization is important. Final additions should be made at least 3 weeks prior to bottling. After additions, proceed with normal racking.

Storage

Dated expiration. Unopened, the shelf-life is 5 years at 18°C(65°F). Once opened, keep tightly sealed and dry.

` ′	, 1 8 3	3
Stage of Winemaking: Finishing	Minimum Contac Time: 3 weeks	Impact: Aroma, Mouthfeel
RICHE EXTRA O Smoothness and richness Red, White		
#15963	500 g	\$208.00

Scott'Tan™ Riche Extra was specifically developed from 100% toasted American oak. This proprietary tannin contributes nuances similar to Scott'Tan™ Riche but with heightened perception of vanilla. Riche Extra can help smooth a wine's finish.

Dosage

vviiite/Rose vviiie		
30-100 ppm	3-10 g/hL	0.25-0.83 lb/1000 gal
Red Wine		
30-200 ppm	30-20 g/hL	0.25-1.6 lb/1000 gal

Usage

Dissolve in about 10 times its weight of warm water (35-40°C/95-104°F) then add it to the wine and mix well. Good homogenization is important. Final additions should be made at least 3 weeks prior to bottling. After additions, proceed with normal racking.

Storage

Dated expiration. Unopened, the shelf-life is 5 years at 18°C(65°F). Once opened, keep tightly sealed and dry.

Stage of Winemaking: Finishing	Minimum Contact Time: 3 weeks	Impact: Aroma, Mouthfeel
ROYAL American oak for "last minute" structure and balance White, Red		
#15979	250 g	\$145.00

Scott'Tan™ Royal is derived from American oak. It may be used in red and white wines to add structure, balance and length on the palate. Royal is a good complement for wines aged with American oak. It is known to bring out hints of cocoa, chocolate, coffee and butterscotch. Royal has also been known to help mask off-aromas and flavors of Brettanomyces.

Royal integrates rapidly and is great for "last-minute" additions. Can be added up to 48 hours before membrane (final) filtration. Always conduct filterability trials prior to addition to avoid filtration challenges.

Dosage		
10-100 ppm	1-10 g/hL	0.08-0.83 lb/1000 gal


Usage

Dissolve Royal in about 10 times its weight of warm water 35-40°C(95-104°F) until fully dissolved. Add to wine gradually during a transfer or pump-over. Good mixing is important.

Storage

Dated expiration. Unopened the shelf-life is 4 years at 18°C(65°F). Once opened, keep tightly sealed and dry.

Stage of Winemaking: Pre-bottling Minimum Contact Time: 48 hours	Impact: Structure, Balance
---	----------------------------------



UVA'TAN 🔿

Grape seed and skin tannin for structure and color stability

Red, White, Rosé

#15964 500 g \$189.00

Scott'Tan™ Uva'Tan is composed entirely of grape tannins (seeds and skins). It is high in polyphenols and low in astringency. Uva'Tan can be used both during fermentation and later during cellaring and finishing. For fermentation, Uva'Tan is particularly useful when natural grape tannin levels are deficient. Post-fermentation it can be used to stabilize color, enhance structure and provide antioxidant protection. Used prior to barreling it can improve integration of tannins in wines. It is recommended that Uva'Tan additions be made well in advance of bottling (six weeks at least) for better integration. Additions closer to bottling will still have a beneficial effect but filtration throughput will likely be reduced.

Dosage		
Red Must		
50-400 ppm	5-40 g/hL	0.42-3.3 lb/1000 gal
White Wine		
50-150 ppm	5-15 g/hL	0.42-1.2 lb/1000 gal
Rosé Wine		
50-200 ppm	5-20 g/hL	0.42-1.6 lb/1000 gal
Red Wine		
50-300 ppm	5-30 g/hL	0.42-2.5 lb/1000 gal
1		

Usage

Pour Uva'Tan evenly on the must/juice at the crusher or into wine during a transfer or racking. If further additions are required, two to three adds can be made after racking. Final additions can be made up to three weeks before bottling, though six weeks are recommended for a more complete polymerization, settling, and optimal filtration.

Storage

Dated expiration. Unopened, the shelf-life is 5 years at 18°C(65°F). Once opened, keep tightly sealed and dry.

Stage of Winemaking: Fermentation, Aging	Minimum Contact Time: 6 weeks	Impact: Color Stability, Structure
---	-------------------------------------	--

UVA'TAN SOFT •

Grape skin tannin for color stability and roundness Red, White, Rosé

	•		•	
			•	
#15965		500 g	•	\$211.00
π 13703		300 g		φ211.00

Scott'Tan™ Uva'Tan Soft is made entirely from white grape skin tannins extracted from fresh grapes immediately after pressing to avoid oxidation of polyphenols. These highly reactive tannins have very low astringency. Like Uva'Tan, Uva'Tan Soft can be used in fermentations as well as in cellaring and finishing. During fermentation Uva'Tan Soft is useful when the grapes' natural tannins are insufficient and softness is a concern. Post-fermentation it can be used to stabilize color, soften structure and provide antioxidant protection. Used prior to barreling it can improve integration of tannins.

Additions of Uva'Tan Soft should be made well in advance of bottling (six weeks at least). Additions closer to bottling may still have a beneficial effect but filtration throughput will likely be reduced. At low dosages, Uva'Tan Soft will optimize the aging potential of white and rosé wines.

	Dosage					
	Red Must					
50-400 ppm	5-40 g/hL	0.42-3.3 lb/1000 gal				
	White Wine					
50-150 ppm	5-15 g/hL	0.42-1.2 lb/1000 gal				
	Rosé Wine					
50-200 ppm	5-20 g/hL	0.42-1.6 lb/1000 gal				
	Red Wine					
50-300 ppm	5-30 g/hL	0.42-2.5 lb/1000 gal				

Usage

Pour Uva'Tan Soft evenly on the must/juice at the crusher or into wine during a transfer or racking. If further additions are required, two to three adds can be made after racking. Final additions can be made up to three weeks before bottling, though six weeks are recommended for a more complete polymerization, settling, and optimal filtration.

Storage

Dated expiration. Unopened, the shelf-life is 5 years at 18°C(65°F). Once opened, keep tightly sealed and dry.

Stage of Winemaking: Fermentation, Aging	Minimum Contact Time: 6 weeks	Impact: Color Stability, Mouthfeel
•••••	• • • • • • • • • • • • • • • • • • • •	• • • • • • • • • • • • • • • • • • • •

harsh and astringent characters in fruit. Herbaceous notes mentation to enhance fruit, add mid-palate sweetness and inare minimized while fruit aromatics are amplified. Foremouth crease the length of the finish. Feelwood! SWEET & FRESH volume and mid-palate sweetness are enhanced. These 100% French oak chips are aged for 24 months and are a blend of toast levels (untoasted, light, medium).

Dosage

	Whites, Rosé	
0.5 - 1 g/L	50-100 g/hL	4.15-8.3 lbs/1000 gal
	Reds	
1-3 g/L	100-300 g/hL	8.3-25 lbs/1000 gal

Usage

For whites and rosés, chips must be used with infusion bags. For reds, add into the tank while filling or by using infusion bags.

Storage

Dated expiration. Unopened, the shelf-life is 4 years at 25°C(77°F). Once opened, keep tightly sealed and dry.

•••••	:	
Stage of	Minimum	Impact: Minimize
Winemaking:	Contact Time:	Herbaceousness,
Fermentation	2 weeks	Enhance Structure

NEW

FEELWOOD! SWEET & FRESH 🐉 😊

Enhances fruit profile, sweetness and length Red, White, Rosé

	•		•	
U. = 0.40	•	- o1 (o -1)	•	400.00
#15940	•	10kg (2 x 5kg units)	•	\$90.00
π 13740		TORE (2 A SKE units)	•	φ>0.00

Feelwood! BALANCE & STRUCTURE oak chips minimizes These 100% untoasted French oak chips are used during ferchips are aged for 24 months.

Dosage

White, Rosé	
50-100 g/hL	4.15- 8.3 lb/1000 gal
Reds	
100-300 g/hL	8.3 - 25 lb/1000 gal
	50-100 g/hL Reds

Usage


For whites and rosés, chips must be used with infusion bags. For reds, chips can be removed from infusion bags and added directly into the tank while filling if preferred.

Storage

Dated expiration. Unopened, the shelf-life is 4 years at 25°C(77°F). Once opened, keep tightly sealed and dry.

Stage of	Minimum	Impact: Enhance
Winemaking:	Contact	Fruit, Sweetness,
Fermentation	Time: 2 weeks	Length

Impact of feelwood! Oak Chips on Merlot



Impact of 3 q/L feelwood! Balance & Structure and Sweet & Fresh on the flavor and aroma profile of a 2018 Merlot from Bordeaux, France- 2 week contact time

OAK INFUSION PRODUCTS/BARREL ALTERNATIVES

Oak has been used to ferment and store wine for centuries. Oak impacts wine color, texture and structure. Its volatile flavor componets are an important contributor and driver of many wine styles. Oak barrels are the traditional way to impart oak character, but barrels are costly. Modern winemaking includes the use of oak infusion products and other barrel alternatives to impart oak character to wine while saving money, space and labor.

Scott Laboratories launched The Oak Lab™ last year to provide high quality oak infusion products and barrel alternatives. Using our products alone, or in conjunction with our full range of Scott'TanTM tannins, enables winemakers the freedom to craft wines to achieve their oak goals. Please visit theoaklab.com for more information.

THERMIC & öaklab.

Range of oak infusion products that provide consistent oak flavors, structure, and mouthfeel

Red, White

The Oak Lab™ Thermic range of oak infusion products and barrel alternatives are produced using a breakthrough modification process that we call Thermic. The Thermic process provides a level of accuracy and consistency superior to other products that are toasted, baked, or electrically radiated. Using only wood and heat, our Thermic process occurs under vacuum in an oxygen-free and combustion-free environment, enabling the creation of a wide spectrum of flavor profiles.

The Thermic products come in four formats and five distinct profiles (see descriptions below) that provide a range of aroma, structure, and mouthfeel possibilities.


Thermic products are consistent and predictable, scale effortlessly from bench trials to production and will provide the same profile year after year.

These products taste great! Trials are highly recommended.

Thermic Profile Description

		•			
	Thermic Profile 1	Thermic Profile 2	Thermic Profile 3	Thermic Profile 4	Thermic Profile 5
Aroma	coconut, sweet oak	nutty, toasty, toffee	vanilla, dark fruits, complexity		espresso, smoked meat, complexity
Mouthfeel	fresh and light, addition of length	rounding, boost of mid-palate	texture, weight, volume, length	full, viscous, rich	balanced, rich, round

SINGLE ROD



Single rods are added to tanks during the aging process. Rods can be used in loose form or stacked in a matrix formation at the base of the tank. Available in Thermic Profiles 1-5.

\$5.00

Size...... 36" x 1 1/16" x 13/16"

Surface area... 1 sq. ft.

Dosage rate . . . 60-160 per 1000 gal Contact time.. 1-18 months Wood variety.. Quercus alba

CUBE BAG

Cube bags are added to tanks during fermentation, aging, and just before bottling to quickly add oak (flashing). Cubes are added to tanks in sewn, food grade polyethylene infusion bags. Available in Thermic Profiles 1-5.

Cube Size..... 1" x 1 1/16" x 13/16" ea.

Dosage rate ... 2-8 bags per 1000 gal

Contact time.. 1-9 months

Wood variety. . Quercus alba

FAN PACK




Fan packs are added to tanks during fermentation and aging process. Fan packs are bound by food grade nylon zip ties to allow for easy installation and removal. Available in Thermic Profiles 1–5.

\$90.00

Size.......... 20 rods-36"x 1 1/16" x 13/16"

Surface area... 20 sq. ft. Dosage rate . . . 3–8 per 1000 gal Contact time.. 1-18 months

Wood variety.. Quercus alba




\$200.00

Package Size . . 20 lb bag

Surface area... 34 sq. ft.

BUNG SLEEVE INSERT



Bung sleeves are added during the fermentation and aging process and are added to barrels directly through the bung hole. Each sleeve is made of 20 sections of oak in food grade polyethylene netting and fastened to the barrel bung with a #304 stainless steel eyelet. Available in Thermic Profiles 1-5.

\$80.00

Size.......... 20 sections-9" x 1 1/16" x 13/16"

76

Surface area... 5.5 sq. ft. Dosage rate . . . 1 per 60 gal Contact time.. 3-12 months

Wood variety. . Quercus alba

TANNINS USED IN WINEMAKING: ORIGIN, EFFECTS AND IMPACTS

The phenolic content of grapes is influenced by grape variety, climatic conditions and viticultural practices. Phenolic compounds impact wine color, taste and mouthfeel. It is the polymerization of phenols in grapes that creates tannins. In addition to their antioxidant properties, tannins provide mid-palate texture and stabilize color by condensing with anthocyanins to create polymeric pigments.

Tannins can play a role in improving wines made with rot-compromised grapes. Tannin additions at the grape stage can combat many of the negative effects cause by *Botrytis cinerea* and other rot-causing organisms. *Botrytis* grows intracellularly and infects fruit primarily under the grape skin, secreting a damaging and stable enzyme called laccase. Depending on the mold and bacteria present, serious enological issues such as oxidative browning, degradation of color and aromatic compounds, as well as clarification and possibly filtration challenges can occur. Early tannin additions can minimize these damaging effects.

Even in healthy grapes, nature often conspires to provide conditions that are less than ideal for phenolic development in the vineyard and/or phenolic extraction during winemaking. Enological tannins can be used to make up for phenolic defeciencies.

Tannins come from a variety of sources including grapes, oak, oak gall nuts and exotic woods (such as Tara and Quebracho). At the crusher/ press gallic tannins (FT Blanc and FT Blanc Soft), are added for their antioxidant properties. They can also be used to supplement grapes that are lacking in tannin or have a weak mid-palate. During fermentation of reds, enological tannins derived from either grapes or trees are added at the crusher or directly into the tank to bind proteins, begin color stabilization, and add structure. It is recommended that tannins such as FT Rouge, FT Rouge Soft, and FT ColorMax are added when there is a sizeable pool of acetaldehyde in the fermenting must. Acetaldehyde acts as a bridge during tannin polymerization and anthocyanin condensation

During aging the addition of tannins are beneficial. Aging tannins are derived from oak (Riche or Riche Extra), grapes (Uva'Tan or Uva'Tan Soft), and exotic woods or blends thereof (Estate, FT Rouge Berry or FT Blanc Citrus). At this point even small tannin additions can assist with structural enhancement and protect against oxidation.

Sometimes, just prior to bottling, a final touch of tannins can be used to elevate fruit, freshness and balance. The highly refined **Onyx**, **Radiance** and **Royal** can do just that.







TARA TREE

Botanical origin: *Tara spinosa*Tannin source: heartwood

Chamical description of tannin

Chemical description of tannin: galloylated (gallic) tannin

EFFECTS ON MUST AND WINE

- Antioxidant
- Stabilizes color in rosé wines
- Delay onset of color loss and yellowing

OAK

Botanical origin: *Quercus robur*, *Q. petraea*, *Q. alba*, *Quercus* spp.

Tannin source: heartwood

Chemical description of tannin: ellagic

EFFECTS ON MUST AND WINE

- Antioxidant activity
- Develops tannin balance
- Structure and roundness in white wines

GALL NUT

Botanical origin: Quercus infectoria, Rhus semialata

Tannin source: galls

Chemical description of tannin: gallic tannin

EFFECTS ON MUST AND WINE

- Highly antioxidant
- Binds proteins, protects from browning

GRAPE SKIN

Botanical origin: *Vitis vinifera*Tannin source: fermented or not fermented white grape skins
Chemical description of tannin: condensed tannin

EFFECTS ON MUST AND WINE

- Direct color stabilization
- Increase of body and tannic structure
- Some antioxidant properties

QUEBRACHO

Botanical origin: *Schinopsis lorentzii*Tannin source: heartwood
Chemical description of tannin:
condensed tannin

EFFECTS ON MUST AND WINE

- Direct color stabilization
- Light increase of body and tannic structure

GRAPE SEEDS

Botanical origin: *Vitis vinifera*Tannin source: grape seeds
Chemical description of tannin: condensed tannin

EFFECTS ON MUST AND WINE

- Antioxidant properties
- Increase of body and tannic structure

FREQUENTLY ASKED QUESTIONS: OAK & TANNINS

When is the best time to add fermentation tannins and/or oak chips? How do I add them?

Fermentation tannins and oak chips are best added early in the winemaking process. In red wine, an addition during the fermentation stage integrates tannin into the wine and offers the greatest opportunity for color stability and increased midpalate structure. Tannins can be added at the crusher or to the tank during the first pump-over, depending on the grape quality (rotten vs. sound). Additional tannin can be added with each pump-over. If adding tannins to a white wine, add directly to the grapes at the crusher or to the tank during a tank mixing.

Oak chips can be added at the time of filling the tank or after settling. Using mesh bags (chips or cubes) is often the easiest method. Make sure the bags remain below the cap to avoid fermentation problems.

I am using tannin and enzymes. Will SO₂ interfere with my additions?

Using all three products together is fine, but timing is important! High SO_2 content can inhibit enzyme activity. Do not add SO_2 and enzymes at the same time. It is okay to add enzymes after the SO_2 is adequately dispersed OR to add SO_2 after the enzymes are adequately dispersed. Follow with a tannin addition six to eight hours later. When enzymes are not being used, add SO_2 first, allow to disperse, then follow with the tannin addition. (See more information on pg 86.)

Can I use tannins or oak on white juice and wine?

Yes, a tannin addition in white juice may be beneficial to remove off-aromas, to improve clarification, to inhibit laccase activity from *Botrytis* or rot, or to serve as an antioxidant. We recommend using either Scott'Tan Uva'Tan, Scott'Tan Uva'Tan Soft, Scott'Tan FT Blanc, Scott'Tan FT Blanc Citrus or Scott'Tan FT Blanc Soft. Tannins can also be added later to wine to improve mid-palate structure or softness.

Oak can also be used with similar results. Oak may also bring toasted oak or sweet oak characteristics depending upon the toast level of the product.

Why should I use tannins or oak on my "premium" red grapes?

Tannins can be used to protect the color and phenolic structure of your wines. For the easiest and most efficient integration of tannins, add Scott'Tan FT Rouge, Scott'Tan FT Rouge Soft, or Scott'Tan FT Rouge Berry at the crusher. If needed, an addition of Scott'Tan Uva'Tan, Scott'Tan Uva'Tan Soft or Scott'Tan Estate prior to aging can help reinforce phenolic balance. During long maturation in barrels, Estate will help prevent excessive oxidation that can result in loss of structure and freshness. For improved SO_2 management add small amounts of Estate (5–7.5 g/hL) during each racking. Oak has long been used in red wine production and brings increased structure, mouthfeel and aromatics to red wines. See our line of products on pages 75-76 for more details.

Will tannin additions increase color in low-color grape varieties?

Tannins do not add color to the must of low color grapes. Recent research indicates that early addition of tannins, such as FT Rouge, binds up available proteins. This preserves grape's own natural tannins making them available to bind with grape anthocyanins, thereby providing increased color stability.

What if I did not add enough tannin during the primary fermentation?

If increased tannin structure and flavor is desired post-fermentation, make additions with Scott'Tan Estate. Addition is best before barrel aging when tannins can be incorporated into the wine and when oxidation and polymerization are slow. Scott'Tan Riche, and Scott'Tan Riche Extra are the best tannins to use prior to bottling (3–6 weeks) when a bit of oak influence is desired. Any of these tannins can be used throughout winemaking, depending on the desired effect. Bench trials are required to determine the best tannin for a particular wine or style.

Oak infusion products can be added before or after fermentation to boost tannin structure and elevate aromatics. In addition, oak infusion products can add oak aromas and mask vegetative characters.

Will adding tannins or oak inhibit barrel aging?

Tannins protect wine from oxidation during barrel aging. The wood tannins extracted from a new barrel protect the wine from over-oxidation during the slow process needed for tannin polymerization and wine development. When using old barrels, indigenous tannin may have been completely leached out. A small tannin addition of 5–10 g/hL of Scott'Tan Estate will act as an antioxidant and help protect the wine. Attaining a good phenolic profile will slow the maturation process and still protect the wine.

Oak infusion bung sleeve inserts can be used to impart new oak aromas and flavors while using neutral barrels.

Can tannins or oak help remove undesirable astringency or bitterness?

Yes. Over-astringency is caused by an imbalance of tannin molecules or by insufficiently bound tannin complexes. By adding either a more refined, highly polymerized tannin or oak infusion product to the wine, balance can be restored and the perception of astringency or bitterness reduced. This frequently improves the perception of fruit.

What if I only want to use pure grape tannin in my wine?

Scott'Tan Uva'Tan (tannins from grape skins and seeds) and Scott'Tan Uva'Tan Soft (tannins from white grape skins only) are comprised of 100% grape tannin. All other tannins are sourced from a combination of grapes, exotic woods, oak or chestnut.

Why can ONLY Onyx, Radiance and Royal be added 48 hours before bottling?

Scott'Tan Onyx, Scott'Tan Radiance and Scott'Tan Royal undergo a specific extraction process. The tannins are extracted from heartwood at low temperature which makes them easily soluble in the wine matrix. This process reduces the concentration of high molecular weight compounds which greatly reduces the risk of any precipitation.

Will Onyx, Radiance and Royal cause filtration problems?

These tannins have undergone extensive research under various conditions. No filtration problems were found 48 hours after the tannin addition. It is not recommended to filter less than 48 hours after addition.



ENZYMES

Enzymes have been used in the fruit industry since the 1930s. structural polysaccharide, linked together into a matrix with Scott Laboratories began offering specialized enzymes for grapes over 25 years ago. In the early days, enzymes for grapes were poorly understood pectinases meant for increasing juice yields. After decades of experience and research we now provide methylesterase and pectin lyase) or a blend of pectinases with interesting properites like cellulase and glycosidase side-activities. Winemaking enzymes are used to accelerate natural reactions that would otherwise occur slowly in grapes, juice, must, and wine. Grape skins and grape pulp are rich in pectins, a proper enzyme use can improve quality and save costs.

other molecules such as cellulose and hemicellulose. Pectin is the backbone that gives grape cells firmness and structure; it is a viscous compound that can impede filtration, clarification, extraction, and aroma expression. Pectin can be highly enzymes that are a blend of pectinases (polygalacturonase, pectin branched with many side chains, affecting the efficiency of every enzyme blend.

> Enzymes can be used to increase yield before fermentation, improve aromas and mouthfeel as well as improving clarification and filtration. At almost every stage in the winemaking process

SELECTING ENZYMES FOR SUCCESS

It is important to match the winemaking goal, enzyme blend and correct dosage to achieve maximum success. The amount of enzyme necessary to achieve success will depend on: the method of harvest, varietal, pectin content, skin thickness, contact time, grape chemistry (pH and temperature) and the presence of inactivating agents like SO₂, bentonite and tannins. Consider

VARIETAL OPTIMIZATION	CLARIFIC	CATION & PRESSING	COLOR & PHEN	OLICS	MOUTHFEEL		
Skin contact enzymes can help release bound aroma precursors into the must or juice.	pulp thre juice, dec increasin in higher	break down grape by releasing trapped reasing solids, g yield and resulting quality juice. Press e optimized and lees compact.	Enzymes accelerate lease of anthocyanin nins resulting in win brighter, more stable and enhanced struct	s and tan- es with e color	Enzymes promote tannin extraction which impacts mouthfeel. Some enzymes, like beta-glucanase will aid with yeast autolysis, releasing mannoproteins which increases mouthfeel and sweetness perception.		
AROMA REVEALING		SUGAR	RLEVEL		FILTRATION		
Aroma compounds, if not rele from their precursor form, car undetectable. Some enzymes I ability to release these compo after fermentation.	n be have the	Enological beta-gludenzymes are inhibited recommended that the used post-fermentated level is <0.5°Brix.	ed by sugar. It is these enzymes are	tration ni down glu that are c	npacted by <i>Botrytis</i> can be filghtmares. Enzymes help break cans and other polysaccharides olloidal in nature and can wine very difficult to filter.		

CHOOSING ENZYMES

		Lallzymes Rapidase Scottzymes												
♦ Highly Recommended ♦ Recommended *Note: The ingredients in MMX are listed by the TTB as acceptable in good commercial winemaking practice in 27 CFR 24.250. For more information, please visit www.TTB.gov. All other enzymes are listed in CFR 24.246.	Cuvée Blanc	EX	EX-V	MMX	Clear Extreme	Expression Aroma	Revelation Aroma	BG	Cinn-Free	Color Pro	ЭН	Ş	KS Plus	Pec51
Page#	81	81	81	81	82	82	83	83	83	83	84	84	85	85
Reds		٨	٠	٨			٥	٥		٨		٥	٥	
Whites and Rosé	٥			٠		٥	۵	٠	٨	٥	٥	٥	٥	٥
Fruit, Cider and Mead				٠				٠		٥	٥	٥	٥	٨
Hybrids and non- <i>vinifera</i>					٠						۵	٥	٥	٠
Aroma enhancement for aromatic white wines	٠			٥		٨	٠	٠	٥					
Macerating enzyme for fruit forward reds		٠								٠				
Macerating enzyme for premium reds			•					• • • • • • • • • • • • • • • • • • • •		٠				
Hard-to-press grapes (e.g. Concords, Muscat, Thompsons), fruit											٠			٠
Gentle extraction	٥	٥				٥			٨	٠				
Improved pressability	٨								•	٥				4
Never use BEFORE pressing					•							٥	٥	
Enhanced settling					•				٨	٥		٥	٥	4
Improved clarification	٥			٥	•	٥			٨	٥		٥	٥	4
Increased yield	٥					٥			٨	٥	٥			٥
Reduced solids					٠				٥	٥	٥	٥	٥	4
Improved filterability	٠	٨		٥	٠				٠	٨	٥	٠	٠	4
Improved flowrate in crossflow												٥	٥	
Use on botrytised wines				٥								٥	٥	
Contains beta-glucanase				٠										
Listed in 27 CFR 24.250				•						# · · · · · · · · · · · · · · · · · · ·				



Lallzyme Cuvée Blanc™ is a granular enzyme that was developed by Lallemand for use on white grapes during skin contact prior to pressing. It is a very specific blend of pectinases with glycosidase side activities and low in macerating activities. Lallzyme Cuvée Blanc is used to enhance aromatic complexity, provide gentle juice extraction and fast clarification after pressing.

Dosage	9
--------	---

Crushed Grapes	Juice	Wine
20 g/ton	Not recommended	Not recommended

Usage

Dissolve Lallzyme Cuvée Blanc in 10 times its weight of water, gently stir and allow to sit for a few minutes. Add directly to the grapes or add in the press.

Storage

hydrated, use within a few hours.

Stage of Winemaking: White Grapes	Activity: Pectinase and glycosidase	Impact: Enhanced aromatics
	•••••	• • • • • •
	LALLZYME EX	LALLEMAND
Macerating enz	zyme for light to medi	um-bodied reds
#16204	100 g	\$26.00
#16205	250 g	\$51.00

Lallzyme EX™ is a granular enzyme with pectinase and hemicellulase activities to improve color stability and mouthfeel in red wines. Specific side activities contribute to the macerating action on the grape cell wall which allows progressive liberation of polyphenols and tannin bound-polysaccharides. EX increases juice extraction, improves wine filterability and provides gentle maceration, even in low-maturity grapes.

Dosage

Crushed Grapes	Juice	Wine
15-30 g/ton	Not recommended	Not recommended

Usage

Dissolve Lallzyme EX in 10 times its weight of water, gently stir and allow to sit for a few minutes. Add directly to grapes at the beginning of fermentation or start of cold soak.

Storage

Dated expiration. Store dry enzyme at 25°C(77°F). Once rehydrated, use within a few hours.

Stage of	Activity:	Impact: Gentle
Winemaking:	Pectinase,	extraction of
Red Grapes	Hemicellulase	juice and color

LALLZYME EX-V (ALLEMAND



Macerating enzyme for medium to full-bodied reds

#16206	: 100 g	\$39.00
#16208	500 g	Ø110.00

Lallzyme EX-V™ is a granular enzyme with pectinase, cellulase and hemicellulase activities for use in red wines intended for aging. It has a specific action on grape cell walls and cell membranes that allows for rapid and efficient release of anthocyanins and tannins leading to stable polymeric pigments. This results in structured wine with deep, stable color. Aromatic analysis shows that Lallzyme EX-V increases the release of aromatic compounds while respecting varietal characteristics.

Dosage

Crushed Grapes	Juice	Wine
10-20 g/ton	Not recommended	Not recommended

Usage

Dissolve Lallzyme EX-V in 10 times its weight of water, gently Dated expiration. Store dry enzyme at 25°C(77°F). Once restir and allow to sit for a few minutes. Add to the grapes at the beginning of fermentation or the onset of cold soak.

Storage

Dated expiration. Store dry enzyme at 25°C(77°F). Once rehydrated, use within a few hours.

Impact: Enhanced tructure and color

LALLZYME MMX (ALLEMAND

Enzyme to increase yeast autolysis rates and/or to improve filterability of Botrytis infected wines

			4
#16207	100 g	•	\$50.00
#10 2 07	100 €		<i>p</i> 30.00

Lallzyme MMX™ is a granular enzyme with beta-glucanase and pectinase activities sourced from Trichoderma harzianum and Aspergillus niger. This enzyme improves yeast autolysis of wine aged on lees, leading to rounder, fuller-bodied wines. Glucanase and pectinase activities act synergistically to improve clarity and filterability of wines infected with Botrytis. In order to maximize benefit of MMX, a contact time of 6-8 weeks is recommended.

Beta-glucanase enzymes from Trichoderma harzianum are listed in 27 CFR 24.250.

DosageBench trials recommended for wine

Crushed Grapes	Juice	Wine
Not recommended	Not recommended	1–3 g/hL 40–114 g/1000 gal

Usage

Dissolve Lallzyme MMX in 10 times its weight of water, gently stir, allow to sit for a few minutes then add to wine.

Storage

Dated expiration. Store dry enzyme at 25°C(77°F). Once rehydrated use within a few hours.

Stage of	Activity:	Impact: Mouthfeel,	
Winemaking:	Pectinase and	clarification and	
Wine	beta-glucanase	filterability	
	wine beta-glucanase interability		

RAPIDASE CLEAR EXTREME Hard to settle Hybrid and American grapes

100g

Hybrid and American grape varieties may be difficult to clarify. Rapidase® Clear Extreme is a granular enzyme that can be used after pressing to preserve aromatic freshness, reduce viscosity, improve juice clarity, help compact lees and speed clarification even in difficult conditions (low temperature, low pH, hard to settle varieties). Rapidase Clear Extreme will remain active at 6-50°C(43-122°F).

Dosage

Crushed Grapes	Juice	Wine
Not recommended	1-4 g/hL 38-152 g/1000 gal	Not recommended

Usage

Dissolve Rapidase Clear Extreme in 10 times its weight of water, stir gently, allow to sit for a few minutes, then add to the juice right after pressing.

Storage

Dated expiration. Store refrigerated at 4-8°C(40-45°F). Once rehydrated, use within a few hours.

Impact: Stage of Activity: Clarification Winemaking: Pectinase under extreme Juice Settling conditions RAPIDASE EXPRESSION AROMA For extraction of aroma precursors #16260 100g \$25.00

Rapidase® Expression Aroma is a granular enzyme specifically formulated for early extraction of aroma precursors (such as thiols) from white grapes optimizing aromatic compounds and complexity of the final wine. It is particularly useful for thick skin or early harvested grapes.

Dosage

Crushed Fruit	Juice	Wine
20-25 g/ton	Not recommended	Not recommended

Usage

Dissolve Rapidase Expression Aroma in 10 times its weight of water, stir gently, allow to sit for a few minutes. Pour over fruit or add in the press.

Storage

Dated expiration. Store refrigerated at 4-8°C (40-45°F). Once rehydrated, use within a few hours.

Stage of Winemaking: White grapes	Activity: Pectinase	Impact: Varietal optimization
---	------------------------	-------------------------------------

ARTICLE

ENZYMES FOR AMERICAN AND HYBRID GRAPE VARIETIES

All grapes contain pectin, a polysaccharide responsible for holding the flesh of the grape in its semi-solid state. Most native American grape varieties and their hybrids tend to have higher levels of pectin compared to Vitis vinifera. This pectin can inhibit juice extraction and clarification, wine sedimentation, and create nightmare filtrations, clogging filter media and significantly increasing costs.

Pectins can be broken down using pectinase enzymes. There are many types of pectinase. Some are stronger and some gentler. Side activities also affect the action of the pectinase. Those side activities may include protease, cellulase, and hemi-cellulase activities which aid the breakdown of grape cell walls and help extract color, tannin and flavor. The gentlest pectinases (e.g. Rapidase Expression Aroma) are designed to extract the juice of white grapes without breaking down solids and extracting potentially bitter phenolics.

All pectinases will aid the settling of solids in both juice and wine. However, some American and hybrid grapes may need further help with additional enzymes at the juice stage (e.g. Rapidase Clear Extreme, Scottzmye Pec5L and Scottzyme HC) to help settling.

Generally, red grapes will require stronger enzymes with more side activities for early extraction of color and tannins (e.g. Scottzyme ColorPro, Scottzyme HC and Lallemand EX-V). In

years with high fungal pressure, these enzymes will help shorten maceration times to allow for early pressing and separation of the wine from infected solids.

Once the wine is made, some of the highest pectin varieties (such as Concord, Edelweiss, and other varieties with Vitis labrusca in their background) may be difficult to filter. The most effective treatment is with the strongest enzymes (e.g. Scottzyme KS and KS Plus), which should never be used on the actual fruit. To aid the final clarification and filtration, Scottzyme KS can be used on white juice or finished wine, while Scottzyme KS Plus should only be used on finished wine.

Several enzymes have very specialized activites. One of these is glycosidase activity (e.g. Scottzyme BG, Rapidase Revelation Aroma). Many aroma compounds, especially terpenes, are bound to sugars. These glycosides have no aroma and require either enzymes or time and acid hydrolysis to release them as free aromatic compounds. These enzymes are most effective on finished wine since sugar inhibits their action. The other specialized activity is that of beta-glucanase (Lallemand MMX). Wines heavily infected by Botrytis often have high levels of glucans that are not affected by regular pectinases and cause nightmare filtrations. Lallzyme MMX breaks down the glucans and improves the filterability of botrytised wines.

RAPIDASE REVELATION AROMA For fast, early release of varietal aroma precursors #16266 100g \$51.00

Rapidase® Revelation Aroma is a granular enzyme that contains alpha- and beta-glycosidase activities to breakdown sugar-bound aroma precursors. Respects varietal characters and increases thiols and terpenes for intense and complex aromas. Since glycosidase activity is inhibited by high sugar levels, Revelation Aroma addition after fermentation gives good results. Once the desired aroma has been obtained, enzyme can be halted via a bentonite addition.

Dosage

Bench trials recommended for wine

Whites		
Crushed Fruit	Juice	Wine
15-22 g/ton	1–1.5 g/hL	1-2 g/hL
	35–55 g/1000 gal	35-70 g/1000 gal
Reds		
Crushed Fruit	Juice	Wine
20-25 g/ton	2-2.5 g/hL	2-2.5 g/hL
	70-90 g/1000 gal	70-90 g/1000 gal

Usage

Dissolve Rapidase Revelation Aroma in 10 times its weight of water, stir gently, allow to sit for a few minutes. Pour over crushed fruit, add to the juice before the start of alcoholic fermentation, or add to wine post-fermentation.

Storage

Dated expiration. Store refrigerated at 4-8°C (40-45°F). Once rehydrated, use within a few hours

Stage of Winemaking: Red or white grapes, juice or wine	Pecti	tivity: nase an osidase		Impact: Aroma release
SC Aroma releasing en	OTTZYME			vines
#16176	1 kg		\$202.00	

Scottzyme® BG is a powdered pectinase with beta-glucosidase side-activity for the release of bound terpenes. It is generally used in white wines, but may also be used in red, rosé and fruit wines for the release of aroma and flavor compounds. BG should only be used at the end of fermentation, never on grapes or in juice as the glucosidase activity is inhibited by sugars. The wine should have less than 0.5% residual sugar for proper enzyme activity.

Dosage

Bench trials recommended for wine

Crushed Grapes	Juice	Wine
Not	Not	3-5 g/hL
recommended	recommended	114-190 g/1000 gal

Usage

Dissolve Scottzyme BG in 10 times its weight of cool water, stir gently, allow to sit for a few minutes and add to wine.

Storage

Store at room temperature for 1–2 years. Once opened, keep tightly sealed and dry. Once rehydrated, use within a few hours.

Stage of	Activity:	Impact:
Winemaking:	Pectinase and	Aroma
Wine	beta-glucosidase	release
	••••••	• • •

SCOTTZYME CINN-FREE •

Used in white must for release of varietal aromas

#16175	1 kg (890 mL)	\$93.00
#16165	25 kg (22.25 L)	\$1314.00

Scottzyme® Cinn-Free is a purified liquid pectinase with very low cinnamyl esterase activity which helps reduce the formation of vinyl phenols. It is used in white must for the release of varietal aromas and aromatic precursors. In addition to releasing desirable pectin-trapped aromas, Scottzyme Cinn-Free aids in pressability, yield, settling, clarification and filtration. It is recommended for aromatic varieties like Sauvignon blanc, Viognier, Pinot gris, Gewürztraminer, Riesling and Vignoles. It can also be used in varieties like Chardonnay to bring out the full aromatic potential of the grape.

Dosage

Crushed Grapes	Juice	Wine
15-30 mL/ton	1.3–1.6 mL/hL 50–60 mL/1000 gal	Not recommended

Usage

Dilute Scottzyme Cinn-Free to approximately a 10% solution in cool water. Pour over the grapes before pressing or add to juice before the start of alcoholic fermentation.

Storage

Store at 4°C(40°F) for 1–2 years. Keep tightly sealed and refrigerated once opened.

Stage of Winemaking: White grapes or juice	Activity: Pectinase	Impact: Aroma and clarification
--	------------------------	---------------------------------------

SCOTTZYME COLOR PRO O

Macerating enzyme for aged and early-to-market reds, whites

#16172	1 kg (890 mL)	\$80.00
#16162	25 kg (22.25 L)	\$1016.00

Scottzyme® Color Pro is a specialty liquid pectinase with protease side-activities. These side-activities are important for helping break down cell walls of red grapes to gently extract anthocyanins, polymeric phenols and tannins. This gentle extraction creates wines that are rounder in the mouth and

bigger in structure, with improved color stability. Wines made with Color Pro tend to have increased tannins, improved clarity and reduced herbaceous or "veggie" characters. Lower doses of Scottzyme Color Pro are recommended for red varieties that are underripe, low in anthocyanins or high in seed tannins. For "big" reds from ripe fruit with mature seeds, higher doses of Scottzyme Color Pro are recommended.

Scottzyme Color Pro is also used in white winemaking for settling and clarifying juice. The improved clarification helps lead to more compact lees, less fining, cleaner fermentation and easier filtration.

Dosage

Bench trials recommended for wine

Reds		
Crushed Grapes	Juice	Wine
60-100 mL/ton	Best used before fermentation	Best used before fermentation
Whites		
Crushed Grapes	Juice	Wine
15-30 mL/ton	2–4 mL/hL 75–150 mL/1000 gal	2.6-5.3 mL/hL 100-200 mL/1000 ga

Usage

Dilute Scottzyme Color Pro to approximately a 10% solution in cool water. Pour the solution over the crushed grapes, or add directly to tank and mix thoroughly.

Storage

Store at $4^{\circ}C(40^{\circ}F)$ for 1–2 years. Keep tightly sealed and refrigerated once opened.

Stage of Winemaking: Grapes, juice and wine	Activity: Pectinase and protease	Impact: Color and structure in red, clarification in whites
	•••••	• • • • • • •

SCOTTZYME HC O

To increase yield and enhance processing in fruits and American grapes

#16171	1 kg (890 mL)	\$80.00
#16161	25 kg (22.25 L)	\$1016.00

Scottzyme® HC is a liquid pectinase and cellulase blend developed to increase yield, reduce solids and improve filtration. It is a strong enzyme useful for hard-to-press or slimy grapes (such as Concords), pome fruit (apple or pear), and stone (pitted) fruits. Scottzyme HC is best used in conjunction with Scottzyme Pec5L.

Dosage

Bench trials recommended for wine

Crushed Fruit	Juice	Wine
	5.3-7.9 mL/hL	6.6-9.2 mL/hL
60-100 mL/ton	200-300 mL/	250-350 mL/
	1000 gal	1000 gal

Usage

Dilute Scottzyme HC to approximately a 10% solution in cool water. Pour the solution over the crushed fruit or add during a tank mixing before alcoholic fermentation. If adding to wine, gently mix a 10% solution into the tank for even dispersion.

Storage

Store at 4°C(40°F) for 1–2 years. Keep tightly sealed and refrigerated once opened.

Stage of	Activity:	Impact:
Winemaking:	Pectinase and	Clarification
Grapes and Fruit	cellulase	and filtration
•••••••		:

SCOTTZYME KS O

Blend of enzymes for enhanced settling and filtration

#16174	1 kg (890 mL)	\$80.00
#16164	25 kg (22.25 L)	\$1016.00

Scottzyme® KS is a liquid blend of enzymes developed to create a special formulation for difficult-to-settle or hard-to-filter juice or wine. The earlier in the process Scottzyme KS is used, the more effective it will be. However, it should never be used before pressing in either red or white grapes. It is never too late to use Scottzyme KS. Customers have reported very favorable results when used to solve "nightmare" filtrations before bottling.

Dosage

Bench trials recommended for wine

Reds			
Crushed Grapes	Must	Wine	
Not	Not	5.3-7.9 mL/hL	
recommended	recommended	200-300 mL/1000 gal	
Whites			
Crushed Grapes	Juice	Wine	
Not	2.6-4.0 mL/hL	5.3-7.9 mL/hL	
recommended	100–150 mL/ 1000 gal	200–300 mL/ 1000 gal	

Usage

Dilute Scottzyme KS to approximately a 10% solution in cool water. Add to the juice after pressing or to the wine after alcoholic fermentation during a tank mixing.

Warning: Never use Scottzyme KS before pressing. Scottzyme KS has very aggressive enzymatic activities that will break down skins and create too many fine solids. After pressing, these activities will help with settling and the breakdown of sticky solids (even from *Botrytis*). The goal is to make the juice or wine more manageable.

Storage

Store at $4^{\circ}C(40^{\circ}F)$ for 1–2 years. Keep tightly sealed and refrigerated once opened.

Stage of Winemaking: Juice or wine	Activity: Pectinase, cellulase and protease	Impact: Clarification and filtration
--	--	--

SCOTTZYME KS PLUS •

Enzyme blend for enhanced clarification and filtration of difficult lots

#16178	1 kg (890 mL)	\$239.00
#16168	25 kg (22.25 L)	\$3046.00

Scottzyme® KS Plus is a powerful liquid enzyme created for use in wine that is very difficult to clarify. It has higher enzyme activities for the most difficult tasks. Scottzyme KS Plus should be used on finished wine only, either to assist with settling or to help with filtration issues before bottling.

Dosage

Bench trials recommended for wine

Fruit	Juice	Wine
Not recommended	Not recommended	4 mL/hL 150 mL/1000 gal

Usage

Dilute Scottzyme KS Plus to approximately a 10% solution in cool water. Add to the wine after alcoholic fermentation during a tank mixing.


Warning: Never use Scottzyme KS Plus before pressing or on the juice. It is our most aggressive enzyme and may result in over clarification of juice.

Storage

Store at 4°C(40°F) for 1-2 years. Keep tightly sealed and refrigerated once opened.

Stage of Winemaking: Wine	cellulase and	Impact: Clarification and filterability in very difficult lots
---------------------------------	---------------	---

Impact of Scottzyme KS Plus on Turbidity after Four Day **Settling at Room Temperature**



SCOTTZYME PEC5L •

Pressability, settling and clarification for white and fruit wines

#16170	1 kg (890 mL)	\$80.00
#16160	25 kg (22.25 L)	\$895.00

Scottzyme® Pec5L is a highly concentrated liquid pectinase blend developed and formulated specifically for winemaking.

It is used on crushed grapes for easier pressing and higher yields and in juice for improved settling, clarification and filtration. It is also useful for berries, pome and stone fruits. When adding to fruit, it is sometimes beneficial to use in conjunction with Scottzyme HC.

Dosage

Crushed Grapes	Juice	Wine	
10-20 mL/ton	1.0-1.3 mL/hL	1.3-1.6 mL/hL	
10-20 IIIL/t0II	40-50 mL/1000 gal	50-60 mL/1000 gal	

Usage

Dilute Scottzyme Pec5L to approximately a 10% solution in cool water. Pour over the grapes or fruit before pressing or add to the juice before the start of alcoholic fermentation.

Storage

Store at 4°C(40°F) for 1-2 years. Keep tightly sealed and refrigerated once opened.

Stage of Winemaking: White grapes and fruit, juice and wine	Activity: Pectinase	Impact: Clarification
---	------------------------	--------------------------


EXPERT TIP FROM OUR **FILTRATION SPECIALIST**

A powerful enzyme such as Scottzyme KS Plus has a great fringe benefit in that it can unclog crossflow and cartridge filters. This is especially useful after filtering colloidally dramatic wines, or specific varietals with naturally higher pectin levels that tend to struggle on filtration day (assuming prefiltration was done properly and within the recommended 24 hour time limit, and a 20 psi differential has not been exceeded). Use KS Plus in the filter after filtration but before the alkaline cleaning cycle. The enzyme should always be used before a hot water or steam sanitization so the solids are not baked in. The use of the KS Plus will then enable a more successful cleaning.

FREQUENTLY ASKED QUESTIONS: ENZYMES

What is the best way to add liquid enzymes?

First calculate the dosage then dilute Scottzymes to approximately a 10% solution (v/v) in cool water (see below). Pour the solution over the crushed grapes/fruit or during a pump-over before fermentation. If adding to juice or wine, gently mix a 10% solution into the tank for even dispersion. Thorough mixing is important.



Scottzyme liquid enzymes are sold by weight but doseage recommendations are given in volume. What's the conversion?

One kg of Scottzyme liquid enzyme equals 890 mL and 25 kg liquid enzyme equals 22.25 liters.

How do I add powdered or granular enzymes?

Granular enzymes need to be dissolved in 10 times their weight of water (for every gram of enzyme dissolve in 10 mL water), gently stirred and allowed to sit for a few minutes. They are then ready to be added to juice or wine. Powdered enzymes tend to scatter across water or wine. It is best to add just enough cool water (~21°C/70°F) to the enzyme to create a paste. Then add more cool water to dissolve the enzyme completely. It is now ready to be added to the tank. Make sure you have gentle motion in the tank to disperse the enzyme or use a dosing pump.

How long will powdered/granular enzymes remain active after rehydration? Rehydrated powdered/granular enzymes should not be kept in liquid form for more than a few hours at room temperature. The liquid solution of these enzymes may be kept a few days

at 4°C(39°F) in water acidified with tartaric acid to pH 3.5 with 50 mg/L of SO₂.

Are enzymes deactivated by SO₃?

Yes, enzymes are inhibited by SO₂. Deactivation occurs around 200 ppm. Do not add SO₂ and enzymes together. It is okay to add enzymes after the SO₂ is adequately dispersed or to add the SO₂ after the enzymes are adequately dispersed.

I have already added bentonite. Can I still use enzymes?

You may still use enzymes but not until the wine has been racked off the bentonite. Bentonite inactivates enzymes. It is best to use bentonite after the enzyme treatment is complete.

When should I add Scottzyme Color Pro, Lallzyme EX or Lallzyme EX-V?

Add at the crusher or the fermenter as soon as possible. Anthocyanins are water-soluble and are released as the grapes are crushed. Most of a red wine's color potential is achieved very early.

Why should I use Scottzyme Color Pro on whites?

Scottzyme Color Pro improves settling, fining and filterability

of white wines.

When should I choose Lallzyme EX or Lallzyme EX-V?

Lallzyme EX is recommended for fruit forward red or rosé wines and EX-V is formulated for premium, aged reds.

What should I do if the optimal time to add enzymes has passed?

Low temperatures, alcohol and SO₂ all inhibit enzyme activity, but the enzymes will still work. This is why recommended enzyme dosage levels for wine are higher than for juice in most cases. Reaction time will also increase when conditions are not optimal.

I have problems settling and clarifying my late harvest white wines. When should I treat with Scottzyme KS?

It is best to add Scottzyme KS after pressing and before fermentation. If added later, you will need a higher dose and a longer reaction time in the wine. If you know you have problems with a specific white wine, add Scottzyme KS to the juice tank. Preventative use is more effective and quicker.

Warning: Do not use Scottzyme KS before pressing. Never use Scottzyme KS on red grapes or must.

I have enzymes left from last year. Are they still OK to use?

Leftover liquid Scottzymes should be tightly sealed and stored in a refrigerated environment. Granular enzymes should be kept in a dry, cool environment. If the dry enzymes get moisture in them, they should be thrown out. If kept properly, liquid enzymes should be good for at least one year with only a small activity loss. Granular enzymes will be good for several years.

I had Botrytis on my grapes this harvest and I want to use a betaglucanase enzyme. Do you carry a beta-glucanase enzyme?

Yes, Lallzyme MMX is a blend of beta-glucanase and pectinase. It is currently listed in 27 CFR 24.250.


How long should I leave the enzyme on white grapes before pressing? In general, waiting 2–12 hours before pressing should be enough time for the enzyme to work.

I am using tannin and enzymes. Will SO₂ interfere with my additions?

Using all three products together is fine, but timing is important! High SO₂ content can inhibit enzyme activity. Do not add SO₂ and enzymes at the same time. It is okay to add enzymes after the SO₂ is adequately dispersed OR to add SO₂ after the enzymes are adequately dispersed. Follow with a tannin addition six to eight hours later. When enzymes are not being used, add SO₂ first, allow to disperse, then follow with the tannin addition.



Timing of Additions: SO₂, Enzymes and Tannins



Add SO₂ and mix well prior to adding enzymes. Tannins can be added 6-8 hours later. Yeast derivative nutrients (e.g. Opti-Red) can be added at any point during fermentation.

MICROBIAL CONTROL

An important part of making wine is controlling microbes during the winemaking process. Though many wine spoilage problems pre-fermentation, fermentation, aging and packaging. Practices can be prevented with good winemaking practices, there are such as adding yeast and ML starter cultures, controlled sulfur still circumstances that require extra microbial control. This dioxide additions, acidification, winery hygiene, and filtration section describes some of the tools that Scott Laboratories are all ways in which microbial control is applied throughout offers to inhibit or eliminate unwanted microorganisms.

MICROBIAL CONTROL ACTION									
REMOVAL	INHIBITION	DESTRUCTION							
Microorganisms are physically removed from the wine. Removal strategies include filtration, centrifugation and some types of fining followed by racking.	Microbe replication is slowed or stopped, but organisms are not necessarily killed. Microbes may start to grow and multiply once the inhibitory pressure is removed. Inhibition strategies include acidification to lower pH and use of sulfur dioxide and Lysovin at non-lethal concentrations.	Microorganisms are killed and will not survive to replicate. Destruction strategies include No Brett Inside™ or Bactiless™ additions, use of Lysovin (especially at pH >4.0) and the addition of alcohol (as in the case of fortified wines).							

SELECTING MICROBIAL CONTROL AGENTS FOR SUCCESS										
INCREASING VOLATILE ACIDITY	HIGH pH WINEMAKING	MICROBIAL STABILIZATION	ACETIC ACID BACTERIA (AAB)	LACTIC ACID BACTERIA (LAB)	YEAST Highly diverse					
VA can be increased by stressed wine yeast, spoilage yeast and bacteria (acetic and lactic acid bacteria). In general, pre-fermentation VA increases are due to acetic acid bacteria and non-Saccharomyces yeast.	The higher the pH, the more diverse the microbial population. Careful attention to wine microbiology and chemistry is advised.	Strategies include pH, temperature management, thoughtful rackings, filtration and the use of Bactiless, Lysovin, No Brett Inside or SO ₂ . Generally accepted SO ₂ levels to control microbes in winemaking are 0.5ppm molecular for bacteria and 0.8ppm molecular for yeast.	AAB are generally problematic in the pre- and post-fermentation phases. They are responsible for the oxidation of ethanol to acetic acid (VA), production of polysaccharides that can give clarification and filtration issues as well as changes in aromas and flavors. Control growth via Bactiless and SO ₂ and by limiting oxygen.	LAB are responsible for converting malic acid into lactic acid. Oenococcus oeni is favorably associated with malolactic fermentation (MLF) but can also produce volatile acidity (VA) under certain conditions. Pediococcus and Lactobacillus are usually considered spoilage organisms. Some LAB can convert sugar to VA. Control growth with Bactiless, Lysovin or SO ₂ .	group of organisms that can be both beneficial or detrimental depending on the stage of winemaking. Control growth postfermentation with No Brett Inside if Brettanomyces is present and SO ₂ .					

CHOOSING MICROBIAL CONTROL AGENTS

	Lysozyme	:	Sulfur Dio	xide	Chitosan	Chitin-Glucan
Highly Recommended Recommended		Si				
	Lysovin	Inodose Granules	Inodose Tablets	Potassium Metabisulfite	No Brett Inside	Bactiless
Page#	89	91	91	91	90	90
Reds	•	•	٨	٨	٨	•
Whites and Rosé	•	•	٨	٠	٨	٨
Fruit, Cider and Mead	•	•	٨	٠	٨	٨
Protection from indigenous yeast		•	٨	•		
Control gram positive bacteria (Lactic Acid Bacteria)	•	•	٨	•		٨
Control gram negative bacteria (Acetobacter)		•	٥	٨		٥
Inhibit oxidation of grapes and juice		•	٨	٨		
Control spoilage yeast (<i>Brettanomyces</i>)		•	۵	٥	٨	
Protection during stuck and sluggish fermentations	•	٥	٥	٥		
Delay MLF	•					
Helps prevent refermentation in bottle		٠	٨	٠		
Chitosan					٨	
Chitin-Glucan						•
Listed in 27 CFR 24.250					٥	•

LYSOZYME, CHITOSAN, AND CHITIN-GLUCAN

LYSOVIN EDPERATUTION

Lactic acid bacteria inhibitor for reds, whites, and rosés

#16402	500 g	\$99.00
#16400	1 kg	\$173.00
#16401	5 kg	\$856.00

Lysovin is a powdered lysozyme that is used to control or inhibit lactic acid bacteria including *Oenococcus* spp., *Pediococcus* spp. and Lactobacillus spp. at any stage of winemaking. The enzymatic activity of lysozyme can degrade the cell walls of gram-positive bacteria (LAB) but not gram-negative bacteria (Acetobacter spp.) or yeast. Lysozyme's effectiveness depends on the type of bacteria and the number of cells present. Recommended Lysovin contact time is seven days, after which time wine should be removed from lysozyme be racking. In red wines, Lysovin will interact with tannins rendering it inactive. In white wines Lysovin should be removed with bentonite.

Recommended Dosage

Lysozyme Applications			Lysovin Dos	e	Timing of Addition		
Inhibit Growth of LAB in Must and Juice Inhibit spoilage characters due to uncontrolled mice This is especially important in high pH conditions o containing rot.	U	200 ppm	20 g/hL	0.75 g/gal	Add prior to fermentation		
Protection During Stuck/Sluggish Fermentations Reduce the risk of VA production by lactic acid bactuse of SO ₂ to encourage yeast growth	250-400 ppm	25-40 g/ hL	0.94–1.50 g/gal	Add at first signs of a stuck fermentation			
Delay MLF/Post-MLF Stabilization Protect wine without the negative effects of SO ₂ during maceration or aging;	Delay	100-200 ppm	10-20 g/ hL	0.38-0.75 g/gal	Add at juice stage or immediately after alcoholic fermentation		
allow for implantation of selected bacteria; delay MLF to increase efficiency of Phase I micro- oxygenation	Stabilize	250-500 ppm	25-50 g/ hL	0.94–1.90 g/gal	Add immediately after MLF completion		
Inhibit MLF when Blending Partial and Complete	e ML Wines	300-500 ppm	30-50 g/ hL	1.10–1.90 g/gal	Add during blending		

Usage

Rehydrate Lysovin in 5-10 times its weight of warm water. Store in dry form for 5-10 years at 18°C(65°F). Once rehydrat-Stir gently for one minute and avoid foaming. Allow to soak for 45 minutes. Repeat until the solution is a clear, colorless liquid. To ensure accurate results, wait one week before culturing for microbes. If lysozyme-treated samples are assessed too quickly after treatment, results may show a false-positive for bacterial growth. It is important to note that lysozyme requires a minimum seven day contact time to allow the enzyme to work.

Storage

ed, Lysovin should be used immediately.

Warning: In the case of low color potential grapes such as Pinot noir, caution is needed when adding Lyzovin prior to completion of alcoholic fermentation (See FAQ for more details). If spoilage yeasts such as Brettanomyces are suspected, SO₂ addition should not be delayed. Lysovin is only effective against gram-positive bacteria and has no effect on yeast or gram-negative bacteria.

LYSOVIN OR BACTILESS?

Which lactic acid bacteria inhibitor you choose will depend on several factors. Has malolactic fermentation finished? Is malolactic desired? What is the microbial load? Is the wine destined for export?

Lysovin is a natural product isolated from egg whites that is active against lactic acid bacteria but not acetic acid bacteria. Lysovin can be used at any stage of winemaking, even if ma-

lolactic fermentation is still desired. Lysozyme should also be your inhibitor of choice if you are exporting the wine.

Bactiless is fungal derived and targets lactic acid bacteria and acetic acid bacteria. Bactiless should not be used unless malolactic fermentation is complete or not desired. Bactiless is listed as an ingredient for domestic wine production and, at this time, should not be used in wines destined for export.



Bactiless™ is a 100% natural, non-allergenic source of chitinglucan and chitosan from a non-GMO strain of Aspergillus niger. Bactiless helps protect wine from acetic acid and lactic acid spoilage bacteria. Bactiless can be used to drastically reduce bacteria populations and to help prevent bacterial growth in wines, especially after malolactic fermentation. It offers an interesting alternative to lysozyme treatment and/or significant amounts of SO₂. The effectiveness of Bactiless can be enhanced with SO₂, but it does not replace the use of SO₂ since it does not have antioxidant or antifungal properties. Bactiless can help inhibit malolactic fermentation when it is not desired. In wines where malolactic fermentation is desired, Bactiless should not be used until after MLF is complete.

Bactiless is shown to be effective against a broad spectrum of wine bacteria, but does not affect yeast populations.

Recommended Dosage

200-500 ppm		1.67-4.16 lb/	45-113 g/60
200-500 ppm	20-50 g/nL	1000 gal	gallon barrel

Usage

Suspend Bactiless in 5-10 times its weight of cool water or wine (Bactiless is insoluble, so it will not go into solution). Bactiless should be mixed to obtain a homogenous addition. Leave Bactiless in contact with the wine for 10 days and then conduct a clean racking. If malolactic fermentation is desired, Bactiless should not be added until after MLF is complete.

To assess Bactiless effectiveness wait 20-30 days post-racking before microbial analysis by traditional plating, microscopic observations or RT-PCR.

Storage

Dated expiration. Store in a dry environment below 25°C(77°F).

Note: This product contains ingredient(s) currently listed by the TTB as acceptable in good commercial winemaking practices in 27 CFR 24.250. For more information please visit www.TTB.gov.

IMPACT OF BACTILESS ON SIX DIFFERENT ORGANISMS 30 DAYS AFTER TREATMENT

	Control	Bactiless at 20 g/hL
Acetic acid bacteria (cells/mL)	2,033,333	54,800
Lactobacillus brevis (cells/mL)	35,733	1,030
Lactobacillus plantarum (cells/mL)	99,333	4,867
Lactobacillus kunkeei (cells/mL)	313	73
Oenococcus oeni (cells/mL)	1,733,333	46,667
Pediococcus species (cells/mL)	100,033	2,700

Trials conducted by ETS Laboratories, St. Helena, California. Trial results are the average of three replicates.



No Brett Inside™ is a commercial preparation of chitosan that specifically targets Brettanomyces cells. The active ingredient, chitosan, works in two ways: 1) Brettanomyces cells adsorb onto chitosan and settle out of the wine and 2) a biological action occurs which results in cell death. This double action of No Brett Inside helps control contaminating populations to preserve wine quality.* However, No Brett Inside cannot decrease any sensory contribution already produced by Brettanomyces.

*No Brett Inside should be added post-ML.

Recommended Dosage

40-80 ppm	4-8 g/hL	0.33-0.67 lb/1000 gal	9–18 g/60 gallon barrel
		1b/1000 gai	ganon barrer

Usage

Suspend No Brett Inside in 5 times its weight of cool water (No Brett Inside is insoluble, so it will not go into solution). No Brett Inside can be added during a pump-over or tank/barrel mixings to ensure a homogenous addition. Leave the No Brett Inside in contact with the wine for 10 days and then conduct a clean racking.

To assess Bactiless effectiveness wait 20-30 days post-racking before microbial analysis by traditional plating, microscopic observations or RT-PCR.

Storage

Dated expiration. Store in a dry, odor-free environment below 25°C(77°F).

Note: This product contains ingredient(s) currently listed by the TTB as acceptable in good commercial winemaking practices in 27 CFR 24.250. For more information please visit www.TTB.gov.

VISUALIZATION OF NO BRETT INSIDE EFFECT ON BRETTANOMYCES



Before

Scanning Electron Micrograph x 20,000 magnification Brettanomyces cells prior to being treated with No Brett



Scanning Electron Micrograph x 20,000 magnification Brettanomyces cells treated with 4 g/hL of No Brett Inside. Image shows Brettanomyces cells attached to the surface of the Chitosan.

Images courtesy of Biljana Petrova and Dr. Charles G. Edwards, Washington State University, Pullman, WA.

SULFUR DIOXIDE AND TARTARIC ACID

Wine quality can be preserved with sulfur dioxide (SO_2) and is used for its antioxidant and antimicrobial properties.

The effectiveness of SO_2 as an antimicrobial agent is dependent upon pH as well as the presence of other SO_2 -binding compounds. As pH increases, the portion of sulfur dioxide that is active against microorganisms decreases. Therefore, increases in pH require the addition of more SO_2 to maintain adequate antimicrobial activity. Inodose Granules and Tablets are an easy and effective way to add SO_2 to grapes, juice or wine.

INODOSE GRANULES Effervescent sulfur dioxide granules #15780 100 g \$11.00

Note: Volume discounts are available. Please contact us for details.

Inodose Granules are small, effervescent granules made of potassium metabisulfite and potassium bicarbonate. As they dissolve the granule release a precise dose of SO_2 . Inodose granules are packaged in pre-measured 100 g and 400 g packs. Inodose granules are perfect for SO_2 additions to incoming must, juice, and wines prior to clarification and fining. The potassium bicarbonate in these granules has little or no effect of pH.



Note: Volume discounts are available. Please contact us for details.

Inodose Tablets are a blend of potassium metabisulfite and potassium bicarbonate. They are packaged in 2 g and 5 g dosage levels. As they dissolve into must or wine, the tablets release a precise dose of SO₂. The effervescent action of the bicarbonate provides mixing in barrels or small tanks while reducing time and labor needed for stirring. The easy-to-use tablet helps prevent overdose problems associated with traditional forms of SO₂. Sealed strip packages keep unused tablets fresh for optimal efficacy. The potassium bicarbonate fraction in these tablets has little or no effect on pH.

Dosage

Inodose Granules and Tablets Conversion Chart— PPM of Total Sulfur Dioxide

SO ₂ Dose	1 Liter	1 Gallon	60 Gallons	100 Gallons	1000 Gallons
2 g	2,000	529	9	5	0.5
5 g	5,000	1,321	22	13	1.3
100 g	100,000	26,420	440	264	26.4
400 g	400,000	105,680	1,761	1,057	106

Note: The SO_2 products contribute a precise dose of pure SO_2 when added to the wine, measured as total SO_2 . These products are blends of potassium metabisulfite and potassium bicarbonate and weigh more than 2 g, 5 g, etc.

Usage

Various applications include:

- Add to gondolas or picking bins to inhibit oxidation of grapes and juice, especially from *Botrytis* or mold.
- Add during transport of must or juice.
- To inhibit indigenous yeast and bacteria.
- Add in tanks before or after fermentation.
- Add directly into barrels after malolactic fermentation.
- To make SO₂ additions to wine during aging.

Storage for Granules and Tablets

Store in a dry, well-ventilated environment at temperatures below 25°C(77°F). Once the pack has been opened it should be used immediately.



Potassium metabisulfite can be used throughout the wine-making process from grape receipt to finished wine.



Used to correct tartaric acid deficiencies, to decrease the pH and increase the titratable acidity of grapes, juice and wine thereby enhancing microbial stability, wine color and flavor.

FREQUENTLY ASKED QUESTIONS: MICROBIAL CONTROL

LYSOZYME

How long does it take for lysozyme to work?

The rate of activity depends on many factors including temperature, pH, bacterial load, bacterial resistance and the specific matrix of any given wine. Even though lysozyme starts working immediately, it doesn't necessarily kill all the bacteria immediately. If lysozyme-treated wine samples are plated too quickly after treatment, results may show a false-positive. To ensure accurate results, wait one week before culturing for microbes.

Is lysozyme effective against all lactic acid bacteria?

No. Some lactic acid bacteria strains show resistance to lysozyme. Bench trials MUST be performed to accurately determine the effectiveness and correct addition rate of lysozyme for your wine.

How soon after a lysozyme addition can I bottle?

Wait at least one week, even if you have diligently completed your lab trials. Lysozyme is a protein and may produce lees (especially in reds) and affect the protein stability in whites. It is not recommended to bottle white wines that contain residual lysozyme.

Will lysozyme treatment affect the color of red wine?

Lysozyme added to red must can bind with tannins and other polyphenols that otherwise would have stabilized anthocyanins. This tannin loss can result in reduced color. In general, using 100–200 ppm should not cause a visually observed decrease in color. Lysozyme added post-MLF for microbial stability during barrel aging may have positive color effects when compared to stabilization with SO₂. Any decrease in color should occur in the first few days of treatment. For low color potential grapes (e.g. Pinot noir) lysozyme should be added with extreme care before alcoholic fermentation is complete, however, the consequences of adding lysozyme versus not doing so must be heavily weighed. Bench trials are critical.

SULFUR DIOXIDE

Can I use a partial bag of Inodose granules?

No. Use the entire packet for a single dose of SO₂. The formulation (therefore dosage) can be affected if the granules absorb any moisture.

Can I break the Inodose tablets in half to deliver a smaller dose?

No. Do not break the tablets for smaller dose additions. The combination of potassium metabisulfite and potassium bicarbonate may not be evenly distributed in the tablet. The tablets are available in two sizes to help give dosing choices.

I added a 5 g tablet of SO_2 to my 60 gallon barrel. Does this mean I have 22 ppm of free SO_2 ?

You will have 22 ppm total SO₂ added. The amount of free SO₂ depends on pH, residual sugar, solids, etc.

BACTILESS

Do I have to rack my wine after 10 days?

Yes.

Can I just add Bactiless to the top of my vessel?

No. A thorough mixing is essential.

Does Bactiless have an impact on yeast?

Bactiless has no impact on *S. cerevisiae*. It can have a minimal impact on *Brettanomyces*, but it is not as effective as No Brett Inside. It is possible that some yeast can be caught up in the chitin-glucan matrix but this is not the best use of the product and it may not be reproducible.

Can I induce malolactic after a Bactiless addition?

This is still to be determined, however, it is highly advisable to wait until malolactic fermentation is complete before using Bactiless. If you have a lactic acid bacteria issue prior to inducing MLF you may wish to consider the use of lysozyme.

Does Bactiless impact wine sensory character?

Bactiless is neutral with regards to its sensory impact, however, it does not have the ability to remove any negative sensory compounds that may have been produced by bacterial contaminants prior to treatment.

Can Bactiless or No Brett Inside be used if I am exporting?

These products are currently approved by the TTB for use in domestic winemaking (27 CFR 24.250) and cannot be used in wines destined for export (even if it is permitted for use in the country that you are exporting to).

NO BRETT INSIDE

Do I have to rack off the No Brett Inside lees after 10 days?

Can I just add No Brett Inside to the top of my vessel?

No. A thorough mixing is essential.

Can I induce malolactic fermentation after a No Brett Inside addition?

This is still to be determined, however, it is highly advisable to wait until malolactic fermentation is complete before using No Brett Inside.

Does No Brett Inside impact the sensory of the wine?

No Brett Inside is insoluble so it should not impact wine sensory. This also means that it will not remove any of the sensory compounds that may already be present due to a *Brettanomyces* infection (4-ethylphenol and 4-ethylguiacol).

What is the difference between Bactiless and No Brett Inside?

No Brett Inside is chitosan and Bactiless is chitin-glucan. The source is the same (*Aspergillus niger*), but the formulations are different. They are active in controlling different microbial groups.



FINING AND STABILITY

Fining and stabilizing are complementary actions that that are then removed by racking, filtration, centrifugation, or remediate and protect juice and wine from off-odors, offcolors, and unsightly hazes and precipitates.

physical removal. Though fining agents work by different mechanisms, they all react with or adsorb unwanted substances

other means. Stabilizers react with substances to prevent wine hazes and precipitates from occuring.

Fining removes unwanted elements from juice and wine by A properly fined, stabilized, and filtered wine ultimately leads to a bottle-stable wine.

SELECTING FINING & STABILITY AGENTS FOR SUCCESS

To properly select appropriate fining and stabilizing agents many considerations must be taken into account. First identify the fining or stability goal and then choose a treatment appropriate for the stage of winemaking. Early, proactive treatments are always recommended. Treating problems now can avoid compounded problems later.

BROWNING & OXIDIZATION

Grape juice and wine can oxidize leading to unwanted visual, sensory, and chemical changes. Conditions leading to browning and oxidation are not always understood, but treating problems early is always encouraged. Early fining with activated carbon and PVPP/Casein based products can help remove oxidized phenolics and brown pigments in both the juice and wine phase.

CLARIFICATION

High solids can be problematic. Solids removal can be achieved using enzymes, gelatins, PVPP, bentonite, and casein. These options can be used preand post-fermentation. Post-fermentation isinglass can be used to reduce turbidity due to polysaccharides and colloids thereby eliminating multiple filtration steps.

HAZE

Haze can be caused by many things: microbes, | Preventing tartrate heat unstable proteins, tartrates, residual fining aids, etc. Protein can be removed by Hot and chilled close to Mix Sparkolloid and silica gels like Gelocolle. Microbial hazes can be reduced via fining and filtration. Microbial stability can also be achieved through appropriate used of microbial control agent (see pgs 87-91).

TARTRATE INSTABILITY

precipitation in a finished wine can be achieved in a number instability can be reme- of ways. Traditionally, died by using bentonite | tanks are seeded with and residual fining aids | potassium bitartrate freezing temperatures to induce tartrate precipitation before bottling. Recent advances include adding tartrate inhibitors like mannoproteins and gum arabic. These products work by inhibiting tartrate crystal formation, thereby keeping tartrates in solution.

SENSORY ASPECTS

Wines with perceived astringency and bitterness may be improved with the use of gelatins or other protein-based products that complex with polyphenols. When the goal is to improve aromatic profiles, products like isinglass (pg 103), tannins (see pgs 68-74) as well as gelatins (pg 100) are useful.

ALWAYS CONSIDER THE FOLLOWING FACTORS WHEN CHOOSING OR APPLYING A FINING OR STABILIZING AGENT:

Fining/stability agent preparation Most dry agents should be prepared in water. Always read product directions and follow accordingly.

Dosage Bench trials must be conducted on each wine to determine proper dose rate.

Contact time Most agents react rapidly when contact is made, but may

need time to

settle out.

Shape and size of vessel Vessel type may impact settling time.

Temperature Temperature imapets settling time. Both high and low temperatures

can inhibit

sedimenta-

tion.

Winemaking stage

Previous treatments Previous treatments can interfere with downstream treatments.

method Pumping using a Venturi is an efficient way to disperse agents. Closed circulation afer addition is also beneficial.

Addition

CHOOSING FINING & STABILITY AGENTS

◆ Highly Recommended		Bent	onite			vated bon		PV	PP & Cas	ein		Gela	atins	Isinglass	Inert Cl Ag	arifying ents	Yeas	ivated st For iing	Gum Arabic	Mannoprotein	Gum Arabic/ MannoproteinBlends
♦ Recommended	Blanc obent UF	FermoBent PORE-TEC	GranuBent PORE-TEC	NaCalit PORE-TEC	Granucol FA	Granucol GE	Bentolact S	Caséinate de Potassium	Freshprotect	Polycacel	Polycel	Colle Perle	Inocolle	Cristalline Plus	Gelocolle	Hot Mix Sparkolloid	Pure-Lees Longevity +	Reduless	Flashgum R Liquide	Claristar	UltiMA Soft
Page#	96	96	97	97	95	95	98	98	98	99	99	100	100	103	102	102	101	101	104	103	104
Reds					٥	٥						٠	٥		٥	٥		٠	٠	٠	•
Whites and Rosé	٠	٠	٨	٠	٥	٥	٠	٠	٨	٠	٠	٥	٠	٠	٠	٠	٠	٠	•	٠	•
Fruit, Cider and Mead	٥	٥	٥	٥	٥	٥	٠	٨	٨	۵	٠	٠	٨	٠	٠	٨	٨	٨	•		
Treat moldy juice (Botrytis)			٥	٥	٨	٨	٠	٨	٨	٨	٠		٨								
Prevention/Treatment of oxidization in juice			٥	٥	٥		•	٨	٨	٠	٠									•	
Treatment of oxidization and color defects in wines	•				٠		٠	٠	٠	٥	٠	************			***************************************						
Prevent oxidation and preserve color in wine							٥	٥	٥	٥	٥						٥				
Promote protein stability	٠	٨	٨	٥											٥						
Wine clarification			٥	٥								٥	٥	٠	٥	٠					
Help compact lees							٥						٥		٥	٠					
Remove haze left by other fining agents	•														٠	٨					
Colloidal stability																			٠	٥	٥
Tartrate (KHT) stability																			٥	٠	٥
Diminish bitterness	•					٥	٠	٨	٨	٥	٨	٥		٥							
Diminish harsh tannins and astringency	•						٥		٥			•	٥						٥	٥	٥
Diminish greenness and other off flavors						٠			٠			٠	٥								
Enhance/unmask aromatics									٥	٥		٥	٨				٥	٠			
Aromatic stability																	٠			٠	٥
Add perception of sweetness and softness																			٠	٥	٨
Reduces sulfur defects						٨	٥							[۵			

GRANUCOL FA Decolorizing carbon White, Red, Rosé #15331 1 kg \$21.00

Granucol FA is a decolorizing carbon for the elimination of off-colors due to browning in juice and wine. These activated carbon pellets are prepared for ease of use in the cellar.

Dosage

Bench trials recommended for wine

	Juice	
100-1000 ppm	10-100 g/hL	0.83-8.3 lb/1000 gal
	Wine	
100-300 ppm	10-30 g/hL	0.83-2.5 lb/1000 gal
		·

Usage

Add Granucol FA directly to juice or wine. The pellets immediately dissolve after addition. Stir vigorously for several minutes to ensure even distribution. The activated carbon deposit should be racked as soon as possible.

Storage

Dated expiration. Store in a dry, odor-free and well-ventilated environment below 25°C (77°F). Reseal opened packaging immediately.

Stage of Winemaking: Juice, Wine	Contact Time: 24 hours	Impact: Removes color
--	---------------------------	-----------------------------

GRANUCOL GE Deodorizing carbon White, Red, Rosé #15332 1 kg \$21.00

Granucol GE is a deodorizing carbon for the absorption of offtastes and off-aromas. These activated carbon pellets are prepared for ease of use in the cellar.

Dosage

Bench trials recommended for wine

100-1000 ppm	10-100 g/hL	0.83-8.3 lb/1000 gal

Usage

Add Granucol GE directly to juice or wine. The pellets immediately dissolve after addition. Stir vigorously for several minutes to ensure even distribution. The activated carbon deposit should be racked as soon as possible.

Storage

Dated expiration. Store in a dry, odor-free and well-ventilated environment below 25°C (77°F). Reseal opened packaging immediately.

Stage of Winemaking: Juice, Wine	Contact Time: 24 hour	Impact: Removes off- odors and flavors
--	--------------------------	---

BENTONITE

Bentonite is aluminum silicate clay which is mined in several areas around the world. The wine industry uses two types of bentonite, sodium (Na) and calcium (Ca), to remove heat unstable protein from white and rosé wines. Sodium-based bentonites are better at protein removal. Its lattice structure readily separates in water, exposing negative charges that adsorb and trap positively charged proteins. Calcium bentonite is gentler. Its structure does not separate as easily in water, it flocculates faster, and forms a more compact sediment.

The stronger the positive charge of the protein, the more reactive it is with bentonite. At lower pH, protein has a stronger charge. At higher pH, the protein charge is weaker so the more potent sodium-based bentonite is recommended.

In addition to protein removal, bentonite can also be used as a counter-fining and clarifying agent in conjunction with positively charged fining agents (e.g. gelatin, isinglass, etc.). Bentonite is also used in sparkling winemaking as an adjuvant to help riddling.

The quality of bentonite determines its effectiviness. The most refined bentonites are lighter in color with no or very low levels of sand and grit. We're happy to offer Erbslöh bentonites, considered to be some of the highest quality bentonite in the world.

Note for successful bentonite preparation: Hard water or acidic water makes swelling less effective as it inhibits cation exchange. Pay close attention to swelling times. If bentonite is not swelled as recommended its efficacy will be reduced. The longer the swelling time, the greater the adsorption area. Ensure that bentonite has not picked up any off-odors prior to use.



Blancobent UF is a highly purified and particularly effective powdered sodium-calcium bentonite formulated for use in conjunction with crossflow filtration. Due to the preparation of the bentonite and the absence of particles >100 μ m, Blancobent UF does not cause excessive abrasion to crossflow membranes. Owing to its defined particle size distribution, it is compatible with direct dosing into hollow fiber membrane crossflow systems. In this way, filtration and stabilization happen in one step!



Blancobent UF has fine particles and is free of crossflow-damaging grit and sand.

Competitor Bentonite

Dosage

Bench trials recommended for wine

Wine

200-2000 ppm	20-200 g/hL	1.6-16.8 lb/1000 gal
	<u> </u>	, ,

Usaae

Add Blancobent UF slowly to approximately 10 times its weight of warm water under constant stirring. Allow a rest period of 30-60 minutes, then stir again thoroughly. Let the mixture swell for 6–12 hours. Dispose of supernatant and add remaining bentonite slurry to the wine while thoroughly mixing.

Storage

Dated expiration. Store in a dry, odor-free and well-ventilated environment below 25°C (77°F). Reseal opened packaging immediately.

Stage of Winemaking: Pre-crossflow filtration (wine)	Contact Time: 1 hour	Impact: Removes proteins
---	-------------------------	--------------------------------



FermoBent® PORE-TEC is a pure granular sodium-calcium based bentonite with low iron for the specific treatment of juice. Due to its low iron content, fermentation on this particular bentonite is not only possible but encouraged. Fermenting on bentonite improves the release of ${\rm CO_2}$ during fermentation and the constant contact between juice and bentonite may eliminate the need for protein stabilization before bottling. This also helps to preserve varital aromatics as protein fining takes place before volatile aromatics are produced.

Dosage

Bench trials recommended

Juice

1000-2000ppm	100-200 g/hL	8.4–16.8 lb/1000 gal

Usage

Add FermoBent PORE-TEC slowly to approximately 5-10 times its weight of water and allow to swell. Allow a rest period of 4-6 hours. Dispose of supernatant and add remaining bentonite slurry to the must while thoroughly mixing. After fermentation, rack off of bentonite and gross lees.

Storage

Dated expiration. Store in a dry, odor-free and well-ventilated environment below 25°C (77°F). Reseal opened packaging immediately.

Stage of	Contact Time:	Impact:
Winemaking:	During	Removes
Fermentation	fermentation	proteins
••••••		



Dissolve Freshprotect in approximately 10 times its weight of cool water. Mix well and allow to sit for 1 hour. Add the mixture into the tank slowly; making sure the solution is thor-

Storage

Dated expiration. Store in a dry, odor-free and well-ventilated environment below 25°C (77°F). Reseal opened packaging immediately.

Contact Time: 1-2 weeks	Impact: Softens wine and removes oxidized characters
	Time: 1-2

CASÉINATE DE POTASSIUM

To help prevent oxidation and remove oxidized components White, Rosé, Fruit, Cider

#15808

\$207.00

Caséinate de Potassium is used in both juice and wine for the treatment of oxidized phenolics and bitter compounds. It helps freshen wine and reveal muted aromas. Although the potassium helps with solubility, once added a thorough mixing is essential.

Dosage

Bench trials recommended for wine

Juice	

500-1000 ppm	50-100 g/hL	4.2-8.4 lb/1000 ga
	Wine	
200-1000 ppm	20-100 g/hL	1.7-8.4 lb/1000 ga

Usage

Dissolve Caséinate de Potassium in approximately 10 times its weight of cold water. Mix well and allow the solution to stand for 4 hours. Stir to remove lumps. For juice, add before settling or at the start of alcoholic fermentation. For wine, mix vigorously after adding as Caséinate de Potassium can float.

Once hydrated, Caséinate de Potassium should be used within 48 hours.

Storage

Dated expiration. Store in a dry, odor-free and well-ventilated environment below 25°C (77°F). Reseal opened packaging immediately.

	•••••	•••••
Stage of Winemaking: Pre-fermentation for juice, pre-bentonite add for wine	Contact Time: 1-2 weeks	Impact: Treats oxidation

GRANUBENT PORE-TEC

Bentonite for general protein stability White, Red, Rosé

#15325 20 kg

GranuBent PORE-TEC is a highly purified sodium-based bentonite for the removal of heat unstable proteins in juice and wine. Its refined, granular formation is produced using PORE-TECnology, making it almost dust-free and easy to use.



NEW



GranuBent PORE-TEC is cleaner and more uniform than other bentonite.

Competitor Bentonite

Dosage

Bench trials recommended for wine

J	uice	
•		

350-750 ppm	35-75 g/hL	2.9-6.3 lb/1000 gal
Wine		
200-1500 ppm	20-150 g/hL	1.7-12.6 lb/1000 gal

Usage

Add GranuBent PORE-TEC slowly to approximately 10 times its weight of warm water under constant stirring. Let the mixture swell for 4-8 hours. Dispose of supernatant and add remaining bentonite slurry to the wine while thoroughly mixing.

Storage

Dated expiration. Store in a dry, odor-free and well-ventilated environment below 25°C (77°F). Reseal opened packaging immediately.

Stage of Winemaking: Juice or wine	Contact Time: 1-7 days	Impact: Removes proteins
suice of whic	•	Proteins

STAFF PICK

NACALIT PORE-TEC

\$28.00

Impact:

Clarification

and protein

removal

50-150 g/hL | 4.2-12.6 lb/1000 gal

Sodium-calcium bentonite for clarification

White, Red, Rosé

NaCalit® PORE-TEC is a granulated sodium and calcium ben-

tonite that is specifically formulated for instances where su-

perior flocculation, adsorption and clarification are required.

Dosage

Bench trials recommended for wine

Usage

Add NaCalit PORE-TEC slowly to approximately 5-10 times its

weight of water under constant stirring. Allow to swell for a mini-

mum of 4-12 hours. Dispose of supernatant and add remaining

Storage

Dated expiration. Store in a dry, odor-free and well-venti-

lated environment below 25°C (77°F). Reseal opened pack-

Contact Time: :

1-7 davs

bentonite slurry to the wine while thoroughly mixing.

#15322

50-1500

aging immediately.

Stage of Winemaking:

protein stabilization

for wine

Cold settling for juice, :

I love Freshprotect because I've seen it remove bitterness and add back mouthfeel. I love it for Sauvignon blanc and Pinot gris/grigio that gets a long or hard press cut. It can make that portion of juice blendable back to the main blend. It can take old green bean Sauvignon blanc wine and turn it grassy! Also Freshprotect settles nicely.

-- Maggie McBride, Inside Technical Sales, based in Sonoma Co

For the preventative treatment of oxidation and removal of off-odors White, Rosé, Fruit

BENTOLACT S

CASEIN AND/OR PVPP BASED FINING AGENTS

oughly mixed.

#15788 \$130.00

Bentolact S is a proprietary IOC blend of soluble casein and bentonite. It is most effective when used early in the winemaking process to clean-up moldy fruit, remove bitter characters, assist with clarification and help remove volatile sulfur off-odors.

Dosage

Bench trials recommended for wine

Juice

	Juice		
	200-1000 ppm	20-100 g/hL	1.7–8.4 lb/1000 gal
Wine			
	1000-2000 ppm	100-200 g/hL	8.4-16.8 lb/1000 gal

Usage

Dissolve Bentolact S in approximately 10 times its weight in cold water and mix vigorously to remove lumps. Mix well and allow the mixture to stand for 3 hours. Add during a pump-over or a good mixing. Bentolact S additions may take up to 7 days to settle. Once hydrated, Bentolact S should not be stored for more than 24 hours.

Storage

Dated expiration. Store in a dry, odor-free and well-ventilated environment below 25°C (77°F). Reseal opened packaging immediately.

		_
Stage of		Impact: Cleans
Winemaking: Cold	Contact	up off odors and
settling for juice,	Time: 1-2	flavors. Preventative
pre-bentonite add	weeks	treatment for
for wine		oxidation

FRESHPROTECT 30 1000

For treatment of oxygen sensitive juice and wine White, Rosé, Fruit

#15791 \$149.00 5 kg

Freshprotect is a proprietary IOC blend of polyvinylpolypyrrolidone (PVPP), bentonite, cellulose and gum arabic. It is used to remove oxidized characters, bitterness and herbaceousness in both juice and wines. It is especially useful in the treatment of hard-press wine where it reduces aggressiveness and reveals fruit. Freshprotect must be removed from wine via filtration per TTB regulations due to the PVPP.

Dosage

Bench trials recommended for wine

200-1000 ppm	20-100 g/hL	1.7-8.3 lb/1000 gal
1.1	OI	1 0

POLYCACEL SEC

For treatment of oxidized must and wine or for the preventative treatment of browning and pinking

White, Rosé, Fruit

#15785	1 kg	\$89.00
#15706	5 kg	\$266.00

Polycacel is an IOC blend of polyvinylpolypyrrolidone (PVPP), micropulverized cellulose and casein for use on phenols associated with browning and pinking. It can reduce bitterness and reveal hidden aromas. Polycacel must be removed from wine via filtration per TTB regulations due to the PVPP.

Dosage

Bench trials recommended for wine

300-700 ppm	30-70 g/hL	2.5-5.8 lb/1000 gal
Wine		
150-300 ppm	15-30 g/hL	1.25-2.5 lb/1000 gal

Usage

Dissolve Polycacel in approximately 20 times its weight in cool water. Mix well and allow to sit for 2 hours. Add the mixture into the tank slowly; making sure the addition is thoroughly blended into the juice or wine being treated. This is important as the casein portion can float.

Storage

Dated expiration. Store in a dry, odor-free and well-ventilated environment below 25°C (77°F). Reseal opened packaging immediately.

Stage of Winemaking: Cold settling for juice, pre-bentonite addition for wine	Time:	Impact: Treatment of oxidation, unmasking of aromas
--	-------	---

POLYCEL **3000**

For treatment of pinking or browning, removal of bitter compounds White, Rosé

> 1 kg \$78.00

Polycel is a blend of polyvinylpolypyrrolidone (PVPP) and cellulose formulated to help prevent and/or treat compounds which cause pinking and browning. It can also be used to treat bitterness and herbaceousness. As Polycel can bind color molecules and catechins it is best to use in young wines. Polycel must be removed from wine via filtration per TTB regulations.

Dosage

Bench trials recommended for wine

 IIICe	

Juice		
400-800 ppm	40-80 g/hL	3.3-6.7 lb/1000 gal
Wine (Preventative)		
150-300 ppm	15-30 g/hL	1.25–2.5 lb/1000 gal
Wine (Curative)		
300-500 ppm	30-50 g/hL	2.5-4.2 lb/1000 gal

Usage

Dissolve Polycel in approximately 20 times its weight of cool water. Mix well and allow to sit for 1 hour. Add mixture to the tank slowly, making sure the addition is thoroughly blended into the juice or wine being treated. Depending upon the wine, Polycel may take up to a week to settle out. PVPP is intended as a processing aid.

Storage

Dated expiration. Store in a dry, odor-free and well-ventilated environment below 25°C (77°F). Reseal opened packaging immediately.

Stage of Winemaking: Cold settling for juice, young wines post early racking	Contact Time: 1-2 weeks	Impact: Oxidation control, removal of bitter compounds
---	-------------------------------	--

GELATINS

COLLE PERLE DE COLLE

Gelatin for treatment of astringent wines Red, White, Fruit

#15798	1 L	\$23.00
#15799	5 L	\$75.00
#15800	20 L	\$278.00

Colle Perle is a hydrolyzed gelatin solution which can be used for clarification as well as for the treatment of astringency in wines. Colle Perle flocculates and settles well. It is particularly useful for hard pressed wines.

Dosage

Bench trials recommended for wine

1		I.
800-1500 ppm	80-150 mL/hL	3.0-5.7 L/1000 ga

Usage Juice

Add at the beginning of cold settling and mix throughly to ensure even distribution. When used in juice Colle Perle should be used in conjunction with bentonite or Gelocolle to improve settling. Racking should be done after 1 week.

Wine

Add and mix vigorously into the wine to ensure thorough distribution. Racking should be done after 1 week. Filtration is possible 48-72 hours after fining with Colle Perle. This is when filtration is most productive. For wines intended for aging, a second racking 1 week after the first racking will produce the best results.

It is not recommended to leave gelatins in wine for more than 30 days.

Storage

Dated expiration. Store in a dry, odor-free and well-ventilated environment below 25°C (77°F). Reseal opened packaging immediately.

• • • • • • • • • • • • • • • • • • • •	• • • • • • • • • • • • • • • • • •	• • • • • • • • • • • • • • • • • • • •
Stage of		Impact:
Winemaking: Cold	Contact	Clarification,
settling for juice, pre-	Time: 1	removal of
bentonite addition	week	astringent
for wine		compounds

INOCOLLE DE CONTROL DE



Gelatin for the treatment of moldy must and to enhance the bouquet of finished wines White, Rosé, Red, Fruit, Cider

#15795	1 L	\$26.00
#15796	5 L	\$88.00

Inocolle is a partially hydrolyzed gelatin solution that softens wine while improving aromas and flavors. It can help clarify wine by removing both colloidal and unstable materials.

Dosage

Bench trials recommended for wine

White Wines, Rose, Ciders, or Light Colored Fruit Wines		
300-600 ppm	30-60 mL/hL	1.1-2.2 L/1000 gal
Red Wines		
500-1000 ppm	50-100 mL/hL	1.9-3.8 L/1000 gal
When used with Gelocolle		
250-500 ppm	25-50 mL/hL	0.95-1.9 L/1000 gal

Usage Juice

Dilute Inocolle 1:1 in water. Introduce into juice gradually while mixing vigorously to assure even treatment. Racking should be done after 1 week. Do not adjust juice acidity with either tartaric or citric acid prior to treatment with Inocolle.

Wine

Dilute Inocolle 1:1 in water. Introduce into wine in conjunction with Gelocolle (pg 102). For enhanced settling and gentler fining, introduce Inocolle into wine 1 hour before adding Gelocolle. Mix vigorously to assure even treatment. Racking should be done after 1 week. Filtration is possible 48-72 hours after treating with Inocolle. This is when filtration is most productive. For wines intended for aging, a second racking 1 week after the first racking will produce the best results.

It is not recommended to leave gelatin in wine for more than 30 days.

Storage

Dated expiration. Store in a dry, odor-free and well-ventilated environment below 25°C (77°F). Reseal opened packaging immediately.

Stage of Winemaking: Cold settling for juice, pre-bentonite addition for wine	Contact Time: 1 week	Impact: Clarification and aroma revelation
---	-------------------------	---

\$39.00

#15249

Pure-Lees Longevity +TM is a proprietary blend of inactivated yeast and bentonite used to scavenge dissolved oxygen during aging, cold (tartrate) stabilization and transportation. Pure-Lees Longevity + is the result of work done in collaboration with INRA with different inactivated yeast fractions to evaluate their impact on oxidation. The result is a product with high dissolved oxygen uptake capacity. Oxidation can be responsible for loss of fruit character, browning of wine and decreased shelf-life. Using Pure-Lees Longevity + helps protect color and aromas. Although research determined it was more efficient than SO₂ at preserving color and thiols during 5-month aging trials, it is not a substitute for SO, as it has no antimicrobial activity.

Dosage

Bench trials recommended for wine

200-400 ppm 20-40 g/hL 1.7-3.4 lb/1000 gal

Usage

Suspend Pure-Lees Longevity + in 10 times its weight of water, gently mix, then add to wine. Mix thoroughly. Contact time depends on aging time (1–9 months).

Storage

Dated expiration. Store in a dry, odor-free and well-ventilated environment below 25°C (77°F). Reseal opened packaging immediately.

Stage of	į	
Winemaking:	•	C
Post-	i	
fermentation	÷	

Contact Time: 1-9 months

Impact: Scavenges oxygen

STAFF PICK

Reduless is a very handy tool to keep in your back pocket (not literally, of course, or you might smell yeasty). Reduless attacks sulfides which are tricky little compounds that can come and go in the lifetime of a wine. Removing them is not always essential, as some winemakers love them, but when they mask aromas or even add harshness to the finish (especially in reds) sulfides need to be removed. Using Reduless can unveil fruit and soften the palate. Even small doses of 1-2g/hL can make big difference.

-Ashlie Helm, Sales Representative, based in Central Valley, CA

PURE-LEES LONGEVITY +: INACTIVATED YEAST TO SCAVENGE OXYGEN

Scavenging dissolved oxygen during aging and storage helps protect white and rosé wine quality from the end of fermentation through the bottling step. During aging or movement of finished wines, white and rosé wines can develop aroma defects due to oxidation reactions. These reactions are mainly due to oxidation of alcohols by a coupled oxidation mechanism involving oxygen and wine di- and tri-hydroxyphenols. These oxidized compounds are responsible for lowering wine quality due to browning and loss of aromas.

Yeast cells, even in a non-viable physiological state, can uptake oxygen. This potential for oxygen consumption by non-viable yeast cells is now used for the protection of wines against oxidation during storage and/or aging. After years of collaborative research and development with the INRA Montpellier in France, Pure-Lees Longevity + TM was developed as an innovative solution for protection of wines against oxidation during storage and aging, allowing lower sulfite additions.



\$149.00

Reduless™ is a unique fining product used to reduce sulfur off-odors such as H₂S and dimethyl sulfide. Its formulation includes bentonite together with other natural elements which are rich in copper. Reduless can naturally enhance roundness while treating sulfur problems. It has also been shown to reduce phenol-related defects.

#15115

Dosage

Bench trials recommended for wine

Usage

Mix Reduless in 10 times its weight of water. Add immediately to the tank. If prepared in advance, re-suspend the product prior to its addition to the tank. Gently mix and rack off or filter after 72 hours. The maximum potential copper transfer, when used according to the recommendation, is 0.02 ppm.

Storage

Dated expiration. Store in a dry, odor-free and well-ventilated environment below 25°C (77°F). Reseal opened packaging immediately.

•••••		••••••••••••••••••••••••••••••••••••••
Stage of		Impact:
Winemaking:	Contact Time: 1-3	Reduction
Post-	days	of sulfur
fermentation		off-odors

GELOCOLLE 🐉 🗠 Silica gel for improved settling

Red, White, Rosé, Fruit, Cider

#15783 5 L \$69.00

Gelocolle is an aqueous solution of suspended silica commonly used in conjunction with gelatins, isinglass and other organic (protein-based) fining agents. It initiates flocculation of fining agents and helps lees compaction. It also reduces the risk of leaving residual protein-based fining agent behind (overfining). Gelocolle can be used for hard-to-filter wines where it helps chelate proteins and other compounds.

Dosage

Bench trials recommended for wine

0.75-3.8 L/1000 gal 200-1000 ppm 20-100 mL/hL

Note: Use 1.0 mL of Gelocolle to 1.0 mL of gelatin.

Usage

Gelocolle should be added directly into wine 1 hour after addition of protein-based fining agents (gelatin, isinglass, etc.). Mix thoroughly.

Storage

Dated expiration. Store in a dry, odor-free and well-ventilated environment below 25°C (77°F). Reseal opened packaging immediately.

Do not refrigerate or freeze! Gelocolle solidifies at temperatures of less than 0°C(32°F). This process is irreversible.

***************************************	• • • • • • • • • • • • • • • • • • • •	
Stage of Winemaking: Wine fining	Contact Time: 1-2 weeks	Impact: Lees compaction

HOT MIX SPARKOLLOID •

For superior clarification of wine White, Red, Rosé, Fruit, Cider, Mead

#15035 \$182.60

Hot Mix Sparkolloid® is specially formulated to clarify wine without impacting aroma, body or flavor. It can be used after bentonite or carbon fining to help compact lees. Hot Mix Sparkolloid can be helpful in removing haze left by other fining agents and enhances filterability.

Dosage

Bench trials recommended for wine

Wine

125-500 ppm	12-50 g/hL	1.0-4.0 lb/1000 gal
F F	0,	

Usage

Heat water to boiling [1-2 gallons of water per pound Hot Mix Sparkolloid (8-15 L/kg)]. Slowly stir in the Hot Mix Sparkolloid. Maintain temperature above 82°C(180°F) while agitating the mixture constantly until all of the translucent globules of clarifier have been dissolved and the mixture is smooth and creamy (approximately 20-30 minutes). While still hot, slowly add the mixture to the wine. This is easily accomplished by adding to a tank being mixed by a tank agitator or by introducing the hot mixture into the line during a tank circulation. Let the wine settle 1 week or more, depending somewhat on the volume of wine involved. Then filter, preferably from the top of the tank.

Storage

Dated expiration. Store in a dry, odor-free and well-ventilated environment below 25°C (77°F). Reseal opened packaging immediately.

Stage of Winemaking: Wine clarification	Contact Time: 1-2 weeks	Impact: Lees compaction, filterability enhancement
---	-------------------------------	---

CRISTALLINE PLUS 🐉 🗠

Isinglass to assist with clarification and brightening White, Rosés, Light reds, Fruit

#15770	100 g	\$17.00
#15771	1 kg	\$144.00

Cristalline Plus is a blend of isinglass and citric acid stabilized with potassium metabisulfite. It has a strong positive charge and can improve clarity and filterability even in very difficult wines (such as wines made with botrytised grapes). It is favored by Pinot noir winemakers due to its gentle fining effect and brightening of aromas. Cristalline Plus is not sensitive to cold temperatures but may be slow to complete settling.

Recommended Dosage

Bench trials recommended for wine

Usage

Dissolve Cristalline Plus in 150-200 times its weight of tepid water (15-20°C(59-68°F)). Allow to swell for 3 hours. Add additional water if solution is too viscous. Add homogenized solution to wine, taking care to mix well. Rack once lees are well settled.

Storage

Dated expiration. Store in a dry, odor-free and well-ventilated environment below 25°C (77°F). Reseal opened packaging immediately.

Stage of Winemaking: Pre- bentonite addition (wine)	Contact Time: 2-4 weeks	Impact: Clarification, brightening and aroma revealing
--	----------------------------	--

MANNOPROTEINS AND GUM ARABICS FOR STABILITY





Natural liquid mannoprotein preparation for potassium tartrate stabilization

White, Rosé, Red

#17000	2.5 L	\$204.00
#17001	20 L	¢1.426.00

Claristar® is a specialty liquid mannoprotein product from Oenobrands to aid in the natural tartrate stabilization of wines. It is the result of a patented extraction and separation technique that isolates the fraction of mannoproteins from S. cerevisiae with the highest Tartrate Stability Index (TSI). When added to wine, Claristar inhibits the nucleation and growth of potassium tartrate crystals. In addition to improved stability, the sensory balance of red, white and rosé wines are enhanced. Users note improved aromatics as well as smoothness on the palate.

Claristar is packaged as a liquid and its highly purified mannoproteins are 100% soluble in wine. It can be added directly and homogenizes easily. Thanks to Claristar's enhanced potassium tartrate stabilization properties, wine can be treated immediately prior to bottling.

Dosage

Verification of efficacy prior to use

White and Rosé Wines

80–100 mL/hL (3–3.8 L/1000 gal)		
Red Wines		
70-90 mL/hL	(2.7-3.46 L/1000 gal)	

To ensure efficacy of a Claristar addition for stability of any particular wine, bench trials MUST be run with laboratory analysis and verification. The amount of Claristar required will be unique to each wine. Its effectiveness is dependent upon a

wine's individual characteristics (e.g. protective colloid levels, pH, alcohol, etc.) in addition to a user's chosen stability criteria. The wine submitted for bench trials MUST be the final blend. Claristar should be the final addition to any wine prior to filtration and bottling. Please contact Scott Laboratories, Inc. for more information regarding the bench trial requirement.

Note: Claristar is not appropriate for calcium tartrate stabilization problems.

Usage

Claristar can be considered for use in white, rosé and red wines that meet the below criteria:

- Are the final blend
- Have never been pH adjusted with calcium carbonate
- Are confirmed protein stable
- Are under 16% alcohol by volume

Claristar should never be added to a wine prior to cake/DE/ Earth/Velo filtration, or cellulose pads, however, it can be added prior to crossflow and sterile cartridge filtration.

Storage

Dated expiration. Store in a cool, dry environment at under 10°C(50°F). Once opened, use within 15 days. Can be frozen once.

Note: This product contains ingredient(s) currently listed by the TTB as acceptable in good commercial winemaking practices in 27 CFR 24.250.

For more information please visit www.TTB.gov.

Stage of Winemaking: Pre-bottling	Contact Time: Indefinitely	Impact: Inhibits potassium tartrate precipitation
---	-------------------------------	---

FLASHGUM R LIQUIDE



Gum arabic for colloidal protection Red, White, Rosé, Cider, Mead

#15772	1 L	\$24.00
#15773	5 L	\$ 78 . 00
#15769	20 L	\$264.00

Flashgum R Liquide is a gum arabic derived from Acacia seyal. This preparation offers colloidal protection and gives perception of sweet and soft characters on the palate. Gum arabic products can help reduce the risk of colloidal deposits in unfiltered bottled wine. Natural polysaccharides reduce astringency and increase feelings of volume and fullness in the mouth. Flashgum R Liquide can provide color protection in rosé and fruit wines.

Dosage

Bench trials recommended for wine

100 1200	40 120 1/11	15 451 1200 1
400–1200 ppm	40-120 mL/hL	1.5-4.5 L/1000 gal

Usage

Flashgum R Liquide should be the last commercial product added to the wine. It is best to do inline additions 24–72 hours prior to the final pre-membrane and membrane filtrations. Filterability trials prior to membrane filtration are recommended. If using on wine that is not going to be filtered, add Flashgum R Liquide just prior to bottling.

Storage

Dated expiration. Store in a dry, odor-free environment at or below 25°C(77°F).

Stage of Winemaking: 24-72 hours Pre-bottling	Contact Time: Indefinitely	Impact: Colloidal protection, sweetness
--	-------------------------------	---

ULTIMA SOFT 🐉 🗠

Mannoprotein/gum arabic with positive impact on stability and perceived softness and volume White, Red

	•			
	•	- 1	•	4-2-0
#17012	•	1 kg		\$136.0
1111012	•	1 118		p150.0

UltiMA Soft is a unique blend of mannoproteins and gum arabic. On white wines, UltiMA Soft can soften, enhance body, add length, and lower astringency. On red wines, it helps maintain fruity aromas while helping to round out the mid-palate. If the wine is not to be filtered, this fully soluble product can be added immediately prior to bottling. Bench trials are recommended. Gum arabic and mannoproteins both have some stabilizing effects on wine, though the addition of this product is not a replacement for good winemaking practice or thorough analysis.

Dosage

Bench trials recommended for wine

ı		1
150-300 ppm	15-30 g/hL	1.2-2.4 lb/1000 gal

Usage

Add UltiMA Soft by mixing with 10 times its weight of water. UltiMA Soft should be the last commercial product added to the wine. Ideally it should be added to the wine using a dosing pump. If the wine is to be filtered, it is recommended that the addition be done 24-72 hours before the membrane filtration and that filterability trials be conducted prior to filtration.

Storage

Dated expiration. Store in a dry, well-ventilated environment with temperatures less than $25^{\circ}C(77^{\circ}F)$.

Note: These products contain ingredient(s) currently listed by the TTB as acceptable in good commercial winemaking practices in 27 CFR 24.250. For more information please visit www.TTB.gov.

Stage of Winemaking: Contact Time: 24-72 hours Indefinitely pre-bottling	Impact: Balancing and softening
--	---------------------------------------

......

FREQUENTLY ASKED QUESTIONS: FINING & STABILITY

Do I need to run bench trials before I use a fining agent?

Yes. Bench trials are essential to determine proper dosing, efficiency, and outcome in the wine. Each fining product works by a different mechanism and will react to each wine differently. Bench trials and cellar additions should be prepared and used the same way (same temperature, same mixing style, etc.). If bench trials are not performed, the winemaker may risk under or over fining and could harm the wine.

What are the main factors that influence how well fining works?

Fining can be a delicate operation. Product preparation and addition, product concentration, temperature, product age, pH, metal content and previous fining treatments are all factors that can influence the effectiveness of fining. It is important to follow the manufacturer's instructions and maintain accuracy when using fining products.

Which fining agents react with lysozyme?

Carbon, silica sol, oak chips and tannin will bind and precipitate lysozyme with a resulting decrease in activity. Bentonite will bind with and inactivate lysozyme.

Which fining agents do not react with lysozyme?

Gelatin, potassium caseinate and pectinase do not affect lysozyme activity. In fact, pectinase treatment will help maintain lysozyme activity by breaking down phenolic compounds that can bind lysozyme.

What is the best way to add fining agents?

There are several ways to add fining agents. Add the fining agent to the tank while mixing with a Guth agitator, dosing into a recirculation pump setup with a stand-alone dosing machine or with a Mazzei injector (see scottlab.com for more information).



CLEANING

BENEFITS OF AIRD® PRODUCTS

- Specially formulated products for the Innovative BUILT FORMULA for wine industry
- Significant water savings no citric rinse is required
- Non-dusting product

- more effective cleaning
- Effective at low doses over wide tem- Safer and lower environmental imperature ranges
- Does not require hazardous shipping
- No chlorine, other halogens, phosphates, silicates or fillers
- pact than bulk chemical cleaners

WATER SAVINGS WITH AIRD PRODUCTS

AiRD PROCESS

CLASSIC METHOD VS

DUE TO ITS UNIQUE FORMULATION, AIRD PRODUCTS **CAN RESULT IN UP TO 50% WATER SAVINGS.***

AiRD Process	Water Used*	Classic Method	Water Used*
Rinse	100 gallons	Rinse	100 gallons
AiRD Product	200 gallons	Caustic	200 gallons
Short Rinse	100 gallons	Long Rinse	200 gallons
TOTAL	400 gallons	Citric	200 gallons
	•	Rinse	100 gallons
		TOTAL	800 gallons

The chart shows a common cleaning procedure for a 2,000 gallon tank cleaning. *Not including potential reuse of AiRD solutions. Actual water savings may be greater.

CHOOSING CLEANING PRODUCTS FOR SUCCESS

 ◆ Highly Recommended ◆ Recommended 	Cleaning Agents			
O Recommended	Cleanskin-K	Destainex-LF	Oak Restorer	Oak Restorer-HW
Page#	106	106	106	106
Dosage	1.0-4.0% w/v	0.5-1.5% w/v	1.0-2.0% w/v	0.5-2.0% w/v
Water temperature for use	68-140°F 20-60°C	104-140°F 40-60°C	68-86°F 20-30°C	104-140°F 40-60°C
pH (1% solution)	~11.3	~10.8	~10.65	~9.6
Removes tartrates	•	٥	٨	٠
Removes color	٥	•	٠	•
Microbial neutralizing		٥	٠	•
General purpose cleaning	٥	•		
Barrel cleaning			٠	•

CLEANING AGENTS

CLEANSKIN-K COAIRD

Multi-purpose cleaner and tartrate remover

Tanks and Equipment

#18500 \$43.00

Cleanskin-K is a 100% active, water soluble, multi-purpose potassium-based cleaning product for use in the winery. This carbonate formulation uses the power of oxygen to effectively clean stainless steel and associated materials. Cleanskin-K can be used in tanks, presses, destemmers, juice channels and more to remove tartrate crystals. Secondarily, it is effective at removing wine color, protein and organic soils. In addition to the potassium carbonate, Cleanskin-K contains proprietary percarbonates, chelation and sequestering aids, polysurfactants and a rinse aid, to leave your surfaces bright, clean, neutral and spot free.

Dosage

1.0-4.0% w/v 10-40 g/L 1.3-5.4 oz/gal

Storage

Store in a dry, odor-free environment between 10-20°C(50-68°F) away from sunlight.

DESTAINEX-LF (LOW FOAMING) OGAIRD

Multi-purpose oxidizing cleaner for organic soils and molds Bottling systems, winery surfaces, lines, equipment and difficult to rinse systems

> #18504 5 kg

Destainex-LF is a proprietary sodium percarbonate based cleaning agents with microbial neutralizing abilities. This highly effective formulation can be used at low levels to remove wine color, protein stains, mold, mildew, and biofilms from wine contact surfaces such as: stainless steel, galvanized metals, concrete, polyethylene (low and high density), polypropylene, plastics, flexible hoses, glass and powder-coated surfaces.

Destainex-LF can be used in both automated (CIP) and manual systems. The sodium percarbonate in Destainex-LF is complemented with proprietary surfactants and chelation agents, water conditioning materials and rinse aids for a bright, clean and spot free neutral surface.

Dosage

0.5-1.5% w/v 5-15 g/L0.7-2.0 oz/gal

Storage

Store in a dry, odor-free environment between 10-20°C(50-68°F) away from sunlight.

OAK RESTORER OOMIRD

Oak cleaner and refresher

Barrels, staves and oak chips

Oak Restorer

#18508	5 kg	•	\$38.00
(Dak Restorer-H	-IW	
#18510	5 kg	:	\$38.00

Oak Restorer products are proprietary cleaners formulated for use on oak surfaces. These products were developed on behalf of winery clients in Australia. These buffered carbonate blends also contain bicarbonates and surfactants to effectively remove tartrate build-up, color, tannin and protein residues, thereby extending the working life of barrels, puncheons, redwood tanks and staves. Oak Restorers are single process cleaning agents requiring only a water rinse. No subsequent neutralization is required. Oak Restorers leave your wooden surfaces refreshed, odorless and pH neutral.

Dosage

0.5-2.0% w/v	5-20 g/L	0.7–2.7 oz/gal
0.3-2.0% W/V	3-20 g/L	0.7-2.7 02/gai

Storage

Store in a dry, odor-free environment between 10-20°C(50-68°F) away from sunlight.

INSTRUCTIONS FOR CLEANING PRODUCTS

Consult the chart on page 105 for water temperature requirements of each product. Cleaning is most effective when soft or treated water is used.

Prepare appropriate volume of potable water (typically 10% of vessel volume you are cleaning), accurately measuring the correct weight of the cleaner. Slowly add the powder into the water, mixing until a consistent solution is obtained. Initially the prepared solution will appear milky, but will clarify. Once the solution has clarified it is ready for use. Products can be used manually or with automated CIP systems. Contact time is based on water temperature and quality, amount of product used and turbulence of contact.

Making wine from sources other than grapes can be quite different and can pose many challenges. Numerous tools used in grape fermentation can also be utilized in fruit or mead fermentation. These tools can help the winemaker create a better product and ultimately enhance product longevity. The following information has been compiled to highlight our recommendations.

CHOOSING PRODUCTS FOR FRUIT WINES AND MEAD

Highly Recommended

♦ Recommended

Yeast	Fruit	Mead	Page#
Lalvin 71B ™	•		17
CVW5™	•	٠	21
Lalvin DV10 ™	•	٠	22
Lalvin EC1118™	•	٠	22
Lalvin ICV D47™	•		24
Lalvin K1 (V1116)™	•	٠	27
Lalvin ICV OKAY™	•		25
Lalvin QA23™	•	٠	28
Lalvin R2™	•		29
Lalvin Sensy™	•		30
VIN 13	•	•	31

Go-Ferm Protect Evolution™	٥	٥	45
Fermaid K™	٨	٨	48
Fermaid O™	٨	٥	49

Malolactic Bacteria

Enoferm Alpha™	•	57
Lalvin MBR 31™	٠	58
PN4™	٠	59
Lalvin VP41™	•	59

Enzymes

Scottzyme® BG	83
Scottzyme®HC •	84
Scottzyme® KS	84
Scottzyme® KS Plus	85
Scottzyme® Pec5L ♦	85

Tannins	Fruit	Mead	Page#
Scott'Tan™ FT Blanc	•		69
Scott'Tan™FT Blanc Citrus	٨	٨	69
Scott'Tan™FT Blanc Soft	٨	٨	70
Scott′Tan™FT ColorMax	•		70
Scott'Tan™FT Rouge	٨		71
Scott'Tan™FT Rouge Berry	٨		71
Scott'Tan™FT Rouge Soft	٨		71
Scott'Tan™ Radiance	•		72

Fining Agents/Stability

٠		98
٠	**************************************	98
٠		100
٠	٠	103
٠	٥	98
٠		96
٠	٥	104
٠	٠	102
٠	٠	102
٠		100
٠		97
٠		99
•	٠	101
	• • • • • • • • • • • • • • • • • • •	

Yeast Derivative Nutrients

Glutastar™	٠	٨	51
ICV Noblesse™	٨	٠	52
Opti-MUM Red™	٠		52
Opti-RED™	٠		53
Opti-WHITE™	•	٨	53

SELECTING PRODUCTS FOR SUCCESS IN FRUIT WINES & MEAD

YEAST

Using a selected yeast strain can maximize the positive attributes that come with that strain (e.g., mouthfeel, complexity, aromas, fermentation kinetics), while avoiding unpleasant aromas and poor fermentation kinetics that may come with a "wild" strain. The key to yeast choice is matching it to the wine style, and more importantly, the fermentation conditions. Proper rehydration and acclimatization of the selected yeast strain is essential.

NUTRIENTS

Fruit wines and mead are notorious for having low nutrient content. Proper nutrition for both yeast and malolactic bacteria is essential to ensure good fermentation kinetics, with positive flavor and aroma profiles. Nutrients can also help to avoid stuck or prolonged fermentations and H₂S and VA problems.

YEAST DERIVATIVE NUTRIENTS

Glutastar and Opti-WHITE are used either pre-fermentation or early in the fermentation to increase mouthfeel, help avoid browning and protect freshness and aromas during aging. Opti-RED and Opti-MUM Red are high in polyphenol reactive polysaccharides. Add at the onset of fermentation to enhance mouthfeel and to help stabilize color. Noblesse can be used to improve the perception of fruit and roundness and softness in the finish. It may be added at the onset or near the end of fermentation.

MALOLACTIC BACTERIA

Malolactic fermentation can soften wines made from fruit high in malic acid. Many fruits have unbalanced acid profiles and the resulting wine may have a very low pH. Be sure to choose a bacteria strain that works under the conditions of the fruit. If the winemaker's goal is to reduce acid without adding flavor/ aroma characteristics, then a neutral strain should be used. Other strains can produce subtle changes in flavor and/ or texture.

TANNINS

Tannins help give wine its structure and contribute to its longevity. Honey and some types of fruit contain very little natural tannin.Enological tannins can be used to add structure and enhance flavor and aroma. They reduce the risk of oxidation and help stabilize wine color. FT Blanc Soft adds to the midpalate texture without darkening lighter colored fruit wines and meads. For darker meads and fruit wine, there is a whole array of complex tannins derived from oak, exotic wood, grape skins and seeds, and more. For color stabilization, there is FT ColorMax, which is most effective when used in conjunction with FT Rouge or FR Rouge Soft. Onyx, Radiance, and Royal are ideal tannins for a finishing touch, even just before bottling.

wine.

ENZYMES

All fresh fruit contains pec-Most fining of fruit wine and tin. For many fruits, excess mead is done for clarificapectin can be responsible for tion. The fining agents pull inadequate juice extraction, minute particles together. lack of clarity, slow sedimen-The heavier particles then settle faster and and form a tation and poor filterability. Pectinases break down more compact sediment. Hot Mix Sparkolloid is very effecpectin. When pectinases are used at pressing, they result tive at clarifying the finished in the release of more juice. wine, as is the combination At the juice stage, enzymes of Cristalline Plus (isinspeed settling of solids prior glass) counter-fined with the to racking and fermentation. negatively-charged Geloco-In finished wine, pectinases lle. Fining agents can also aid filterability and final claribe used to remove oxidized fication. For most fruit wines, phenolic compounds from a combination of Pec5L and young wines. Caséinate de HC will work for most situ-Potassium (casein) and Polyations. For certain difficult cel (PVPP) are effective at situations, such as fruit comremoving the bitterness and promised by rot, stronger browning caused by oxidaenzymes like KS or MMX may tion of young wines. Redube necessary. Both of these less is used to treat wines should only be used on juice suffering from reduced sulfur or wine according to direccompounds (e.g., H₂S). For tions. Some enzymes, such as fruit wines subject to protein BG and Revelation Aroma, reinstability, bentonite fining lease aromas that are bound is the only way to remove the to sugars, thereby increasing unstable proteins. the aromatic intensity of the

FINING AGENTS | MICROBIAL CONTROL

Sulfur dioxide (SO₂), Lysovin, Bactiless and No Brett Inside can all be used to protect wine quality against microbial spoilage. Although its primary use is microbial control, SO₂ also helps reduce the risk of oxidation. Inodose SO₂ Granules and Tablets are pre-measured, and no mixing is necessary once added to the wine. No Brett Inside specifically targets and kills Brettanomyces. Lysovin (lysozyme) attacks gram-positive bacteria, such as Lactobacillus, Pediococcus and Oenococcus. Bactiless kills a wider range of bacteria, from lactic acid bacteria to acetic acid bacteria. Both Bactiless and Lysovin can be used to delay or inhibit malolactic fermentation.

CALCULATIONS AND CONVERSIONS

VOLUME CONVERSIONS
mL = milliliter, fl oz = fluid ounce, gal = gallon,
L = liter, hL = hectoliter
1 mL = 0.035 fl oz
1 fl oz = 30 mL
1 L = 1000 mL
1 L = 0.2642 gal
1 gal = 3785 mL
1 gal = 3.785 L
1 hL = 100 L
1 hL = 26.4 gal

MASS CONVERSIONS
mg = milligram, g = gram, kg = kilogram, lb = pound
1 kg = 1000 g
1 kg = 2.205 lb
1 g = 1000 mg
1 lb = 453.6 g
1 lb = 0.4536 kg
1 metric ton = 1000 kg
1 metric ton = 2205 lb
1 US ton = 2000 lb
1 US ton = 907 kg

INTERNET CONVERSION PROGRAMS

www.oiiiiieconversioii.com	www.wiiieudus.com	<u>www.wiiiebusiiiess.com/toois</u>
TEMF	IONS	

F° = Degree Fahrenheit $C^{\circ} \rightarrow F^{\circ} = (C^{\circ} \times 9/5) + 32$	F°	0	32	40	50	60	70	80	90	100	110	120
C° = Degree Celsius $F^{\circ} \rightarrow C^{\circ} = (F^{\circ} - 32) \times (5/9)$	C°	-18	0	4	10	16	21	27	32	38	44	49

OTHER CONVERSIONS

1 lb/1000 gal = 454 g/1000 gal = 0.454 kg/1000 gal = 120 mg/L = 27.2 g/barrel* = 0.120 g/L
1 kg/hL = 1000 g/hL = 10,000 mg/L = 2.271 kg/barrel* = 10 g/L
1 ppm = 1 mg/L
*barrel = 60 gal = 227.1 L
1°Brix = 1% sugar (wt/vol)

BENCH TRIAL CALCULATOR

We recommend performing bench trials with many of our products including lysozyme, tannins, enzymes and fining agents. This calculator will help determine the amount of any given stock solution to achieve a range of concentrations in various-sized sample bottles.

FOR POWDE	ERED PRODUCT	S (LYSOVIN, TANNINS, FINING AGENTS, ETC.)
mLs of stock solution to add	_	(sample size in mLs) x (desired concentration in ppm) x (0.0001)
per sample bottle		% concentration (w/v) of stock solution

mLs of stock solution to add	(sample size in mLs) x (desired concentration in ppm) x (0.0001)
per sample bottle	% concentration (w/v) of stock solution
FOR	LIQUID PRODUCTS (SCOTTZYMES, GELATINS, ETC.)
mLs of stock solution to add	(sample size in mLs) x (desired concentration in mLs/1000 gal) x (0.000024)
per sample bottle	% concentration (v/v) of stock solution
For example: If you have a 10% in a 375 mL sample bottle you w	stock solution of Color Pro and wish to create a 150 mL/1000 gal dose yould calculate:
mLs of stock solution	$= \frac{(375) \times (150) \times (0.000024)}{10} = 0.135 \text{ mL}$
Therefore, you would need to ac a concentration of 150 mL/1000	dd 0.135 mL of a 10% Color Pro stock solution to a 375 mL bottle to represent 9 gal.

BENCH TRIAL PROTOCOLS AND PROCEDURES

A bench trial is a small-scale test that simulates the effect a tannin, fining agent or other additive will have on a large volume of wine. Bench trials are used to: evaluate the efficacy of treatments, determine proper dose rate, and gain familiarity with addition methods. By working in small volumes, large volume mistakes can be avoided.

Wine matrices differ for many reasons (vintage variations, winemaking practices, etc) and bench trials must be repeated for every lot of wine. An additive that worked last year or in a different lot, may not work again in the same way or at the same dose.

Bench trials also demonstrate how an additive will behave during preparation (rehydration) or mixing. Many fining products have unique and sometimes difficult solubility issues which can pose a challenge in the cellar. Bench trials alert the winemaker to potential issues and can help formulate a more efficient plan when additions are made in the cellar.

HOW TO DO A BENCH TRIAL

	тос	OLS:	
100 mL graduated cylinder or volumetric flask.	Scale that can weigh to a tenth of a gram.	1 mL pipette divided into 100th's.	5 mL pipette divided into 1/10 mL.

PROCEDURE

- 1. Make sure to keep a CONTROL. A control is an untreated portion of wine.
- 2. Decide which dosages to prepare (100 ppm, 200 ppm and 300 ppm for example). Consult product technical information for manufacturer's recommended dosages.
- 3. Prepare stock solutions. Make a 2.5%, 5% or 10% stock solution by adding 2.5, 5.0, or 10.0 grams of product to total volume of 100 mL, respectively. After weighing out the product, mix it with 80 mL of water until either dissolved or all lumps are gone. Put it into the graduated cylinder or volumetric flask and fill to the 100 mL mark. Additives that are liquids can also be prepared in this way by adding 2.5, 5.0, or 10 mL product to total volume of 100 mL.
- 4. Using either the Bench Trial Calculator (previous page) or the Cheat Sheet here, add the appropriate volume of stock solution to either 375 mL or 750 mL bottles, then fill to the proper level (evacuating the head space with gas, if possible).
- 5. After capping or corking, agitate gently to get a good mix. If the product is not completely soluble (e.g., Noblesse, fining agents), occasional agitation to stir up the product in the wine might be necessary to duplicate what would take place in the barrel or tank.
- 6. Taste and/or test after the appropriate waiting period. For fining agents, this might just be as long as it takes the agent to settle. For tannins, it should be at least several days, but it is even better if the trial can sit for at least two weeks.

Cheat Sheet:

Cileat Sileet:					
Desired Dosage	Stock Solution	mLs of solu- tion to add to 375 mL bottle	mLs solu- tion to add to 750 mL bottle		
	2.5%	1.5	3.0		
100 ppm	5.0%	0.75	1.5		
	10.0%	0.375	0.75		
	2.5%	3.0	6.0		
200 ppm	5.0%	1.5	3.0		
	10.0%	0.75	1.5		
	2.5%	4.5	9.0		
300 ppm	5.0%	2.25	4.5		
	10.0%	1.125	2.25		
	2.5%	6.0	12.0		
400 ppm	5.0%	3.0	6.0		
	10.0%	1.5	3.0		
	2.5%	7.5	15.0		
500 ppm	5.0%	3.75	7.5		
	10.0%	1.875	3.75		

FINISHING KIT FOR BENCH TRIALS O

#SLQDTAN	Finishing Kit for Bench Trials	\$94.00
#37101	20–200μL Micropipette	\$135.00
#37102	100–1000μL Micropipette	\$135.00
#37111	5–200μL Micropipette tips (96 tips)	\$11.00
#37112	100–1250μL Micropipette tips (96 tips)	\$13.00

Finishing agents are valuable tools for perfecting a wine. Our Finishing Kit for Bench Trials includes pre-dissolved tannins and stability agents for ease of running bench trials.

Bench trials are a very important step to determine the right fit of any of these products. Finding the correct product to work with the matrix of your wine, as well as the correct dosage, might take several trials.

Finishing aids have been found to help with:

- Masking pyrazines/greenness
- Maximizing fruit
- Boosting/increasing mid-palate
- Increasing aromatic intensity
- Increasing body
- Help minimize impact of Brettanomyces
- Brighten acid
- Impart oak character
- Increase perception of sweetness

This kit contains:

- Scott'Tan™ FT Blanc (pg 69)
- Scott'TanTM FT Blanc Soft (pg 70)
- Scott'Tan™ FT Blanc Citrus (pg 69)
- Scott'Tan™ FT Rouge Berry (pg 71)
- Scott'Tan™ Complex (see scottlab.com)
- Scott'TanTM Estate (pg 69)
- Scott'Tan™ Riche (pg 73)
- Scott'Tan™ Riche Extra (pg 73) • Scott'TanTM Onyx (pg 72)
- Scott'Tan™ Radiance (pg 72)
- Scott'Tan™ Royal (pg 73)
- RedulessTM (pg 101)
- UltiMA Soft (pg 104) • Flashgum R Liquide (pg 104)
- Oak Lab™ Thermic Oak Samples, Profiles 1-5 (pg 76)

Note: Tannin solutions have been prepared for ease of use in bench trials. All of our tannins are normally sold as powder or granulate.



Product Optimal Storage Temperature (unopened) Recommended Storage (once opened) Active Driad Yeast 20°C (68°F) Use immediately Bactiless Below 25°C (77°F) Tightly sealed, dry, odor-free environment Bentolact S 25°C (77°F) Tightly sealed, dry, odor-free environment Bentolact S 25°C (77°F) Tightly sealed, dry, odor-free environment Caséinate de Potassium 25°C (77°F) Use immediately Cliestiar 10°C (50°F) Use immediately Cleaning Products (AIRD) 10-20°C (50-68°F) Tightly sealed, dry, odor-free environment Clistaline Plus 25°C (77°F) Tightly sealed, dry, odor-free environment Enzymes- Lallayme 25°C (77°F) Pry: Tightly sealed, general storage Rectydraced: Use within a few hours Enzymes- Rapidase 4-8°C (39-65°F) Dry: Tightly sealed, general storage Rectydraced: Use within a few hours Enzymes- Scottzymes 1-2 years: Store liquid forms: (94°C (39°F) Belydraced: Use within a few hours Entitles Mosaic/Novello 5-15°C (41-59°F) Use immediately Freshprotect 25°C (77°F) Tightly sealed; dry Gelocolle 10°C (27°F) <	Product		B
Activated Carbon 25°C(77°F) Tightly sealed, dry, odor-free environment Bactiless Below 25°C(77°F) Tightly sealed, dry, odor-free environment Bentonites 25°C(77°F) Tightly sealed, dry, odor-free environment Bentonites 25°C(77°F) Tightly sealed, dry, odor-free environment Tightly sealed, dry, odor-free environment Claristar 10°C(50°F) Use immediately Tightly sealed, dry, odor-free environment Claristar 10°C(50°F) Use immediately Tightly sealed, dry, odor-free environment Claristar 10°C(50°F) Use immediately Tightly sealed, dry, odor-free environment Tightly sealed, general storage Rehydraced: Use within a few hours Tightly sealed, general storage Rehydraced: Use within a few hours Tightly sealed, general storage Rehydraced: Use within a few hours Tightly sealed, general storage Tightly sealed, growthin a few hours Tightly sealed, dry Tightly			
Bettolact S Below 25°C(77°F) Bentolact S B		, ,	,
Bentolact S 25°C(77°F) Bentonites 25°C(77°F) Tightly sealed, dry, odor-free environment Casélante de Potassium 25°C(77°F) Tightly sealed, dry, odor-free environment Claristar 10°C(50°F) Use immediately Tightly sealed, dry, odor-free environment Claristar 10°C(50°F) Use immediately Tightly sealed, dry, odor-free environment Dry: Tightly sealed, general storage Rehydraced: Use within a few hours Enzymes- Lallzyme 25°C(77°F) Enzymes- Rapidase 4-8°C(39-45°F) Enzymes- Scottzymes 1-2 years: Store liquid forms: @ 4°C(39°F) Store dry forms: @ 18-24°C(60-77°F) Exotics Mosaic/Novello 5-15°C(41-59°F) Use immediately Use immediately Use immediately 15ghtly sealed, general storage Rehydraced: Use within a few hours Rehydraced: Use w	Activated Carbon	, ,	
Bentonites 25°C(77°F) Tightly sealed, dry, odor-free environment Caséinate de Potassium 25°C(50°F) Use immediately Cleaning Products (AIRD) 10-20°C(50-68°F) Tightly sealed, dry, odor-free environment, protected from light Tightly sealed, general storage Rehydrated: Use within a few hours Pory. Tightly sealed, general storage Rehydrated: Use within a few hours Store dry forms: @ 18-24°C(30°F) Rehydrated: Use within a few hours Store dry forms: @ 18-24°C(60-77°F) Rehydrated: Use within a few hours Store dry forms: @ 18-24°C(60-77°F) Use immediately Store dry forms: @ 18-24°C(60-77°F) Use immediately Store dry forms: @ 18-26°C(77°F) Tightly sealed; dry Tightly sealed; dry Tightly sealed Ground Store Granules & Tablets 25°C(77°F) Tightly sealed; dry Use immediately Use i	Bactiless	Below 25°C(77°F)	Tightly sealed, dry, odor-free environment
Caseinate de Potassium 25°C(77°F) Tightly sealed, dry, odor-free environment Claristar 10°C(50°F) Use immediately Tightly sealed, dry, odor-free environment, protected from light Tightly sealed, dry, odor-free environment Dry: Tightly sealed, dry, odor-free environment Dry: Tightly sealed, dry, odor-free environment Dry: Tightly sealed, general storage Rehydrated: Use within a few hours Protected from light Dry: Tightly sealed, general storage Rehydrated: Use within a few hours Protected Use within a few hours Protected Use within a few hours Exotics Mosaic/Novello 5-15°C(41-59°F) Use immediately Use immediately Tightly sealed Use immediately Preshprotect 25°C(77°F) Tightly sealed Glocolle 10-20°C(50-68°F). Do not freeze. Use immediately Use immediately Use immediately Use immediately Use immediately Non-Saccharomyces yeast (Biodiva, Flavia, Gaia) Non-Saccharomyces yeast (Biodiva, Flavia, Gaia) Non-Saccharomyces yeast (Laktia) Polycael 25°C(77°F) Use immediately Non-Saccharomyces yeast (Laktia) Protected dry Tightly sealed; dry Use immediately Nutrients- Yeast, Bacteria and Yeast Derivative Nutrients Polycael 25°C(77°F) Tightly sealed; dry Tightly sealed; dry Tightly sealed; dry Polycael 25°C(77°F) Tightly sealed; dry Tightly sealed; dry Tightly sealed; dry Tightly sealed; dry Polycael Poly	Bentolact S	25°C(77°F)	Tightly sealed, dry, odor-free environment
Claristar Cleaning Products (AiRD) 10-20°C(50-68°F) Cristalline Plus 25°C(77°F) Enzymes- Lallzyme Enzymes- Rapidase Enzymes- Scottzymes Enzymes- Rapidase Enzymes- Lallzyme Enzymes- Lallzyme Enzymes- Lallzyme Enzymes- Lallzyme Enzymes- Rapidase Enzymes- Lallzyme Enzymes- Lallzyme Enzymes- Lallzyme Enzymes- Lallzyme Enzymes- Lallzyme Enzymes- Rapidase Enzymes- Lallzyme Enzymes- Rapidase Enzymes- Lallzyme Enzymes- Rapidase Enzymes- Lallzyme Enzymes- Rapidase Enzy	Bentonites	25°C(77°F)	Tightly sealed, dry, odor-free environment
Cleaning Products (AIRD) 10-20°C(50-68°F) Tightly sealed, dry, odor-free environment, protected from light Trightly sealed, dry, odor-free environment Enzymes- Lallzyme 25°C(77°F) Enzymes- Rapidase 4-8°C(39-45°F) Enzymes- Rapidase 1-2 years: Store liquid forms: @ 4°C(39°F) Store dry forms: @ 18-24°C(60-77°F) Lyse immediately Flashgum R Liquide 25°C(77°F) Flashgum R Liquide 25°C(77°F) Gelatins (Colle Perle & Inocolle) 25°C(77°F) Gelocolle 10-20°C(50-68°F). Do not freeze. Use immediately Use	Caséinate de Potassium	25°C(77°F)	Tightly sealed, dry, odor-free environment
	Claristar	10°C(50°F)	Use immediately
Enzymes- Lalzyme 25°C(77°F) 25°C(77°F) 25°C(39°45°F) Enzymes- Rapidase 4-8°C(39-45°F) Enzymes- Scottzymes 1-2 years: Store liquid forms: @ 4°C(39°F) Exotics Mosaic/Novello 5-15°C(41-59°F) Exotics Mosaic/Novello 5-15°C(41-59°F) Exotics Mosaic/Novello 5-15°C(41-59°F) Fightly sealed, use within a few hours Exotics Mosaic/Novello 5-15°C(41-59°F) Fightly sealed 10-20°C(50-68°F). Do not freeze. 10 yes immediately 10 yes immediat	Cleaning Products (AiRD)	10-20°C(50-68°F)	
Enzymes- Rapidase A=8°C(39-45°F) Enzymes- Rapidase A=8°C(39-45°F) Enzymes- Scottzymes I=2 years: Store liquid forms: @ 4°C(39°F) Store dry forms: @ 18-24°C(60-77°F) Exotics Mosaic/Novello S=15°C(41-59°F) Exotics Mosaic/Novello S=15°C(41-59°F) Flashgum R Liquide Z5°C(77°F) Frightly sealed Freshprotect Z5°C(77°F) Tightly sealed Freshprotect Gelatins (Colle Perle & Inocolle) Gelocolle 10-20°C(50-68°F). Do not freeze. Use immediately Inodose Granules & Tablets Ionyswr 4°C(39°F) Use immediately Use immediately Use immediately Use immediately Lysovin Dry: 5-10 years @ 18°C(65°F) Use immediately No Brett Inside Below 25°C(77°F) Tightly sealed; dry We immediately Use immediately Non-Saccharomyces yeast (Biodiva, Flavia, Gaia) 11°C(52°F) Use immediately Use immediately Use immediately Non-Saccharomyces yeast (Laktia) A°C(39°F) Use immediately Use immediately Use immediately Use immediately Tightly sealed; dry Duri immediately Use immediately Tightly sealed; dry	Cristalline Plus	25°C(77°F)	Tightly sealed, dry, odor-free environment
Enzymes Scottzymes 1-2 years: Store liquid forms: @ 4°C(3°F) Store dry forms: @ 18-24°C(60-77°F) Exotics Mosaic/Novello 5-15°C(41-59°F) Exotics Mosaic/Novello 5-15°C(41-59°F) Flashgum R Liquide 25°C(77°F) Freshprotect 6elatins (Colle Perle & Inocolle) Gelocolle 10-20°C(50-68°F). Do not freeze. Indoose Granules & Tablets 25°C(77°F) Lyse immediately Indoose Granules & Tablets 25°C(77°F) Lyse immediately Indoose Granules & Tablets 25°C(77°F) Indiffy sealed 4°C(39°F) Use immediately Lysevin Dry: 5-10 years @ 18°C(65°F) No Brett Inside Below 25°C(77°F) Non-Saccharomyces yeast (Biodiva, Flavia, Gaia) Non-Saccharomyces yeast (Laktia) Non-Saccharomyces yeast (Laktia) A°C(39°F) Use immediately Use immediately Use immediately Use immediately Use immediately Nutrients-Yeast, Bacteria and Yeast Derivative Nutrients Oak 25°C(77°F) Tightly sealed; dry Polycael 25°C(77°F) Tightly sealed; dry Tightly sealed; dry Polycael 25°C(77°F) Tightly sealed; dry Tightly sealed; dry Polycael 25°C(77°F) Tightly sealed; dry Tightly sealed; dry Potassum Metabisulfite 25°C(77°F) Tightly sealed; dry Potassum Metabisulfite 25°C(77°F) Tightly sealed; dry Tightly sealed; dry Potassum Metabisulfite 25°C(77°F) Tightly sealed; dry Tightly sealed; dr	Enzymes- Lallzyme	25°C(77°F)	Rehydrated: Use within a few hours
Exotics Mosaic/Novello Flashgum R Liquide Freshprotect Gelatins (Colle Perle & Inocolle) Floor (77°F) Gelatins (Colle Perle & Inocolle) Flashgum R Liquide Freshprotect Gelatins (Colle Perle & Inocolle) Gelocolle Inodose Granules & Tablets Inodose Granules & Tablets Inoy Ingeria (Colle Perle & Inocolle) Inodose Granules & Tablets Inoy Ingeria (Colle Perle & Inocolle) Inodose Granules & Tablets Inoy Ingeria (Colle Perle & Inocolle) Inodose Granules & Tablets Inoy Ingeria (Colle Perle & Inocolle) Inodose Granules & Tablets Inoy Ingeria (Colle Perle & Inocolle) Inodose Granules & Tablets Inoy Ingeria (Colle Perle & Inocolle) Inodose Granules & Tablets Inoy Ingeria (Colle Perle & Inocolle) Inodose Granules & Tablets Inoy Ingeria (Ingeria) Ingertia (Ingeria) Ingertia (Ingertia) Ingertia (Ingert	Enzymes- Rapidase	, ,	
Flashgum R Liquide 25°C (77°F) Tightly sealed Freshprotect 25°C (77°F) Tightly sealed; dry Gelatins (Colle Perle & Inocolle) 25°C (77°F) Tightly sealed; dry Gelocolle 10-20°C (50-68°F). Do not freeze. Use immediately Inodose Granules & Tablets 25°C (77°F) Use immediately Inoys _{wF} 4°C (39°F) Use immediately Lysovin Dry: 5-10 years @ 18°C (65°F) Use immediately Malolactic Bacteria Short term: @ 4°C (39°F) No Brett Inside Below 25°C (77°F) Use immediately Non-Saccharomyces yeast (Biodiva, Flavia, Gaia) Use immediately Non-Saccharomyces yeast (Laktia) 4°C (39°F) Use immediately Non-Saccharomyces yeast (Laktia) 4°C (39°F) Use immediately Nutrients- Yeast, Bacteria and Yeast 18°C (65°F) Tightly sealed; dry Polycacel 25°C (77°F) Tightly sealed; dry Polycacel 25°C (77°F) Tightly sealed; dry Potassium Metabisulfite 25°C (77°F) Tightly sealed; dry Potassium Metabisulfite 25°C (77°F) Tightly sealed; dry Hot Mix Sparkolloid 4 years @ 18°C (65°F) Tightly sealed; dry Tannins 18°C (65°F) Tightly sealed; dry Tannins 18°C (65°F) Tightly sealed; dry Tannins Tightly sealed; dry	Enzymes- Scottzymes	1-2 years: Store liquid forms: @ 4°C(39°F) Store dry forms: @ 18-24°C(60-77°F)	Rehydrated: Use within a few hours
Freshprotect 25°C(77°F) Tightly sealed; dry Tightly sealed; dry Tightly sealed Gelatins (Colle Perle & Inocolle) 25°C(77°F) Tightly sealed 10-20°C(50-68°F). Do not freeze. Use immediately Inodose Granules & Tablets 25°C(77°F) Use immediately Non-Saccharomyces yeast (Biodiva, Flavia, Gala) Non-Saccharomyces yeast (Laktia) 4°C(39°F) Use immediately Use immediately Use immediately Nutrients- Yeast, Bacteria and Yeast Derivative Nutrients 18°C(65°F) Tightly sealed; dry Tightly sealed; dry Polycacel 25°C(77°F) Tightly sealed; dry Polycacel 25°C(77°F) Tightly sealed; dry Polycel 25°C(77°F) Tightly sealed; dry Potassium Metabisulfite 25°C(77°F) Tightly sealed; dry Potassium Metabisulfite 25°C(77°F) Tightly sealed; dry Tannins 18°C(65°F) Tightly sealed; dry	Exotics Mosaic/Novello	5-15°C(41-59°F)	Use immediately
Gelatins (Colle Perle & Inocolle) 25°C(77°F) Tightly sealed 10-20°C(50-68°F). Do not freeze. Use immediately Inodose Granules & Tablets 25°C(77°F) Use immediately Nutrients- Yeast, Bacteria and Yeast Derivative Nutrients 18°C(65°F) Use immediately Tightly sealed; dry Tightly sealed; dry Polycacel 25°C(77°F) Tightly sealed; dry Polycacel 25°C(77°F) Tightly sealed; dry Polycacel 25°C(77°F) Tightly sealed; dry Potassium Metabisulfite 25°C(77°F) Use immediately Use immediately Use immediately Tightly sealed; dry Potassium Metabisulfite 25°C(77°F) Tightly sealed; dry Potassium Metabisulfite 25°C(77°F) Tightly sealed; dry Hot Mix Sparkolloid 4 years @ 18°C(65°F) Tightly sealed; dry	Flashgum R Liquide	25°C(77°F)	Tightly sealed
Gelocolle 10-20°C (50-68°F). Do not freeze. Use immediately Inodose Granules & Tablets 25°C (77°F) Use immediately Inon-Saccharomyces yeast (Laktia) Von-Saccharomyces yeast (Laktia) Von-Saccharomyces yeast (Laktia) Von-Saccharomyces yeast (Laktia) Von-Saccharomyces yeast (Laktia) Vose immediately Use immediately Inghtly sealed; dry Tightly sealed; dry Tightly sealed; dry Polycacel 25°C (77°F) Tightly sealed; dry Polycel 25°C (77°F) Tightly sealed; dry Potassium Metabisulfite 25°C (77°F) Tightly sealed; dry Hot Mix Sparkolloid 4 years @ 18°C (65°F) Tightly sealed; dry	Freshprotect	25°C(77°F)	Tightly sealed; dry
Inodose Granules & Tablets 25°C(77°F) Use immediately Tightly sealed; dry Use immediately Tightly sealed; dry Use immediately Use immediately Tightly sealed; dry	Gelatins (Colle Perle & Inocolle)	25°C(77°F)	Tightly sealed
Ionys _{WF} 4°C(39°F) Use immediately Lysovin Dry: 5-10 years @ 18°C(65°F) Use immediately Malolactic Bacteria Short term: @ 4°C(39°F) Long term: @ -18°C(0°F) Use immediately No Brett Inside Below 25°C(77°F) Tightly sealed; dry Non-Saccharomyces yeast (Biodiva, Flavia, Gaia) 11°C(52°F) Use immediately Non-Saccharomyces yeast (Laktia) 4°C(39°F) Use immediately Nutrients- Yeast, Bacteria and Yeast Derivative Nutrients 18°C(65°F) Tightly sealed; dry Oak 25°C(77°F) Tightly sealed; dry Polycacel 25°C(77°F) Tightly sealed; dry Polycel 25°C(77°F) Use immediately Potassium Metabisulfite 25°C(77°F) Use immediately Pure-Lees Longevity Plus Below 25°C(77°F) Use immediately Hot Mix Sparkolloid 4 years @ 18°C(65°F) Tightly sealed; dry Tannins 18°C(65°F) Tightly sealed; dry Tannins 18°C(65°F) Tightly sealed; dry	Gelocolle	10-20°C(50-68°F). Do not freeze.	Use immediately
Lysovin Dry: 5–10 years @ 18°C(65°F) Use immediately Malolactic Bacteria Short term: @ 4°C(39°F) Use immediately No Brett Inside Below 25°C(77°F) Tightly sealed; dry Non-Saccharomyces yeast (Biodiva, Flavia, Gaia) Use immediately Non-Saccharomyces yeast (Laktia) 4°C(39°F) Use immediately Nutrients- Yeast, Bacteria and Yeast Derivative Nutrients Oak 25°C(77°F) Tightly sealed; dry Polycacel 25°C(77°F) Tightly sealed; dry Polycacel 25°C(77°F) Tightly sealed; dry Potassium Metabisulfite 25°C(77°F) Use immediately Pure-Lees Longevity Plus Below 25°C(77°F) Tightly sealed; dry Hot Mix Sparkolloid 4 years @ 18°C(65°F) Tightly sealed; dry Tannins 18°C(65°F) Tightly sealed; dry	Inodose Granules & Tablets	25°C(77°F)	Use immediately
Malolactic Bacteria Short term: @ 4°C(39°F) Long term: @ -18°C(0°F) No Brett Inside Below 25°C(77°F) Tightly sealed; dry Non-Saccharomyces yeast (Biodiva, Flavia, Gaia) Non-Saccharomyces yeast (Laktia) Non-Saccharomyces yeast (Laktia) Non-Saccharomyces yeast (Laktia) Non-Saccharomyces yeast (Laktia) Nutrients- Yeast, Bacteria and Yeast Derivative Nutrients 18°C(65°F) Tightly sealed; dry Tightly sealed; dry Polycacel 25°C(77°F) Tightly sealed; dry Polycel 25°C(77°F) Tightly sealed; dry Potassium Metabisulfite 25°C(77°F) Use immediately Tightly sealed; dry Use immediately Tightly sealed; dry	lonys _{WF}	4°C(39°F)	Use immediately
No Brett Inside Below 25°C(77°F) Tightly sealed; dry Non-Saccharomyces yeast (Biodiva, Flavia, Gaia) Non-Saccharomyces yeast (Laktia) Non-Saccharomyces yeast (Laktia) Non-Saccharomyces yeast (Laktia) Non-Saccharomyces yeast (Laktia) Nutrients- Yeast, Bacteria and Yeast Derivative Nutrients Oak 25°C(77°F) Tightly sealed; dry Polycacel 25°C(77°F) Tightly sealed; dry Polycel 25°C(77°F) Tightly sealed; dry Potassium Metabisulfite 25°C(77°F) Use immediately Tightly sealed; dry Tightly sealed; dry Use immediately Tightly sealed; dry Tightly sealed; dry Tightly sealed; dry Tightly sealed; dry Potassium Metabisulfite 25°C(77°F) Tightly sealed; dry Hot Mix Sparkolloid 4 years @ 18°C(65°F) Tightly sealed; dry Tannins 18°C(65°F) Tightly sealed; dry	Lysovin	Dry: 5-10 years @ 18°C(65°F)	Use immediately
Non-Saccharomyces yeast (Biodiva, Flavia, Gaia) Non-Saccharomyces yeast (Laktia) Non-Saccharomyces yeast (Laktia) A°C(39°F) Use immediately Use immediately Use immediately Use immediately Tightly sealed; dry Tightly sealed; dry Polycacel 25°C(77°F) Tightly sealed; dry Polycel 25°C(77°F) Tightly sealed; dry Potassium Metabisulfite 25°C(77°F) Use immediately Pure-Lees Longevity Plus Below 25°C(77°F) Tightly sealed; dry	Malolactic Bacteria		Use immediately
Flavia, Gaia) Non-Saccharomyces yeast (Laktia) Nutrients- Yeast, Bacteria and Yeast Derivative Nutrients Oak 25°C(77°F) Tightly sealed; dry Polycacel Polycacel 25°C(77°F) Tightly sealed; dry Tightly sealed; dry Tightly sealed; dry Potassium Metabisulfite 25°C(77°F) Tightly sealed; dry Use immediately Use immediately Use immediately Tightly sealed; dry	No Brett Inside	Below 25°C(77°F)	Tightly sealed; dry
Nutrients- Yeast, Bacteria and Yeast Derivative Nutrients 18°C(65°F) Tightly sealed; dry Tightly sealed; dry Polycacel 25°C(77°F) Tightly sealed; dry Polycel Potassium Metabisulfite 25°C(77°F) Tightly sealed; dry Use immediately Pure-Lees Longevity Plus Below 25°C(77°F) Tightly sealed; dry		11°C(52°F)	Use immediately
Derivative Nutrients 18°C(65°F) Tightly sealed; dry	Non-Saccharomyces yeast (Laktia)	4°C(39°F)	Use immediately
Polycacel 25°C(77°F) Tightly sealed; dry Polycel 25°C(77°F) Tightly sealed; dry Potassium Metabisulfite 25°C(77°F) Use immediately Pure-Lees Longevity Plus Below 25°C(77°F) Tightly sealed; dry Hot Mix Sparkolloid 4 years @ 18°C(65°F) Tightly sealed; dry Tannins 18°C(65°F) Tightly sealed; dry Tartaric Acid 25°C(77°F) Tightly sealed; dry		18°C(65°F)	Tightly sealed; dry
Polycel 25°C(77°F) Tightly sealed; dry Potassium Metabisulfite 25°C(77°F) Use immediately Pure-Lees Longevity Plus Below 25°C(77°F) Tightly sealed; dry Hot Mix Sparkolloid 4 years @ 18°C(65°F) Tightly sealed; dry Tannins 18°C(65°F) Tightly sealed; dry Tartaric Acid 25°C(77°F) Tightly sealed; dry	Oak	25°C(77°F)	Tightly sealed; dry
Potassium Metabisulfite 25°C(77°F) Below 25°C(77°F) Tightly sealed; dry Hot Mix Sparkolloid 4 years @ 18°C(65°F) Tightly sealed; dry Tannins 18°C(65°F) Tightly sealed; dry	Polycacel	25°C(77°F)	Tightly sealed; dry
Pure-Lees Longevity Plus Below 25°C(77°F) Tightly sealed; dry Tannins 18°C(65°F) Tightly sealed; dry	Polycel	25°C(77°F)	Tightly sealed; dry
Hot Mix Sparkolloid 4 years @ 18°C(65°F) Tightly sealed; dry Tannins 18°C(65°F) Tightly sealed; dry Tartaric Acid 25°C(77°F) Tightly sealed; dry	Potassium Metabisulfite	25°C(77°F)	Use immediately
Tannins 18°C(65°F) Tightly sealed; dry Tartaric Acid 25°C(77°F) Tightly sealed; dry	Pure-Lees Longevity Plus	Below 25°C(77°F)	Tightly sealed; dry
Tartaric Acid 25°C (77°F) Tightly sealed; dry	Hot Mix Sparkolloid	4 years @ 18°C(65°F)	Tightly sealed; dry
	Tannins	18°C(65°F)	Tightly sealed; dry
UltiMA soft 25°C(77°F) Tightly sealed; dry	Tartaric Acid	25°C(77°F)	Tightly sealed; dry
	UltiMA soft	25°C(77°F)	Tightly sealed; dry

HOW TO ORDER

WWW.SCOTTLAB.COM

Our easy-to-use website makes planning and submitting your orders easier than ever. Try one, or all, of these convenient features:

QUICK-ORDER SHOPPING CART

Our website's shopping cart allows you to quickly enter orders without navigating to every item page. Simply open the site directly to scottlab.com/shop/basket and start entering search terms or item numbers.

PDF ORDER PLANNER

Use order Planner at scottlab.com/order-planner to easily plan and organize your winemaking products list in one place.

ORDER UPLOAD

Do you love spreadsheets as much as our web team? Assemble your order in a spreadsheet and you can load a CSV file directly as a shopping cart. Head to scottlab.com/upload-cart to learn more and download the CSV template.

REORDER

Head to the My Account section (scottlab.com/profile) of the site and you can search back through your past Invoices and Shipments. If you have an order that you want to recreate, click the handy "Reorder" button to load the items from that invoice or shipment into your shopping cart.

ORDER TEMPLATES

If you have groups of items that you order regularly or want to save for quick re-ordering, nothing beats our Order Templates feature. Just assemble a shopping cart by browsing the site or using any of the handy tools listed above, and from the Shopping Cart page choose "Save as Order Template." Next time you want to start an order from this list of items you can load it from either your "My Account" section of the site, or directly from the Shopping Cart page. Great for recurring purchases.

CIDER + SPARKLING BOOKS

Scott Laboratories is proud to be a trusted resource for all of your fermentation endeavors! For a copy of our Sparkling or Cider Handbook, please contact us.

Note: Most products have an expiration date on the package. Please check the product and store appropriately

Albariño 11, 12, 18, 21, 26, 28,

31, 32

2.

27 CFR 24.246

27 CIN 24.240	3., 32	,
approvals for enzymes 80	Alchemy I 11, 15, 18	BRG [™] , Levuline 11, 13, 20
approvals for yeast nutrients 42	Alchemy II 11, 18, 69	BRL97™, Lalvin 13, 20, 29
27 CFR 24.250	Alchemy III 13, 16, 18	Browning 51, 53, 67, 69, 71, 77,
approvals for enzymes 80 approvals for yeast nutrients 42	Alchemy IV 13, 16, 19	93, 95, 99, 101, 108
approvals for Bactiless and No	Alpha™, Enoferm 56–57, 107	C
Brett Inside 88 approvals for Claristar 103	American hybrid (see Hyrbid winemaking)	Cabernet Franc 7, 13–14, 19, 21, 25, 29–30
approvals for Ultima Soft 104	AMH (see Assmanshausen)	Cabernet Sauvignon 7, 10, 13–14,
3	Amino acids 41, 43, 46-49,	18-21, 24-28, 30, 47, 58, 63
3001™, Vitilevure 18	54-55, 60-61, 65	Carbon, activated 93-95, 102,
31™, Lalvin (MBR) 56, 58, 107–108	Antioxidant 5, 42, 50-51, 53, 67, 69-70, 74, 77-78, 90-91	104, 111 Casein 93–94, 98–99, 104, 108
3MH, 3MHA (see Thiols)	Aromatic Whites 11–12, 17–19, 21–23, 28–32, 34, 47, 51	Caséinate de Potassium 98, 107
4	Aromella 15	CEG, Uvaferm 11, 20
43™, Uvaferm 11, 13, 17	Assmanshausen™, Enoferm 11,	Chambourcin 16
compatibility with Biodiva 33	13, 19, 29	Chardonel 15
use in stuck fermentation 39 43 RESTART™, Uvaverm 11, 13,	В	Chardonnay 11-12, 18, 20-26, 28-29, 31-32, 42, 44, 46-47,
17, 37	BA11™ 11, 19	59, 63, 83
use in Recommended Method	Bacteria (see Malolactic bacteria)	Style Guide, 66
to Restart a Stuck Fermentation 38	Bactiless™ 37–38, 57, 87–90, 92, 108, 111	Chenin blanc 11–12, 18, 21, 23, 25, 27, 30–32
4MMP (see Thiols)	Barbera 13–14, 20–21, 29, 32	Chitin-Glucan 88-89, 92
5	Bayanus, strains of	Chitosan 88-90, 92
58W3™, Vitilevure 11, 15, 17	Saccharomyces 11–16	Cinn-Free, Scottzyme 80, 83
use with FT Blanc Citrus 69	BDX TM 13, 19, 33	Clarification 23, 77-85, 87, 91,
7	Be Fruits 12, 26	93–94, 97–98, 100, 102–103,
7 71B™, Lalvin 11, 13, 15–17 (see	Be Thiols 12, 26	108
also Fruit Wine)	Bench trials 109–110	Claristar 94, 103, 111
use with FT Blanc Citrus 69	Bentolact S 94, 98, 107–108, 111	Cleaning 85, 105-106, 111
use with FT Rouge Berry 71	Bentonite 4, 6, 79, 83, 86, 89,	Clear Extreme, Rapidase 80, 82
٨	93–104	CLOS™, Lalvin 13, 16, 21
A Acetic acid bacteria 87, 89–90	Beta™, Enoferm 56, 58, 63,	Co-Inoculation 55–57, 63, 65
Gaia inhibition of, 34	65–66	Cold soak 18, 33-34, 70, 81
Acidifying yeast (see lonysWF™,	Beta Co-Inoc™ 56–57, 65–66	Colle Perle 94, 100, 107-108, 111
Laktia™)	BG, Scottzyme 80, 82-83,	Colloidal stability 16, 94
Acti-ML™ 56, 60	107–108	Colombard 27, 47
Aging	Biodiva™ 33, 111	Color stability 16, 20, 27, 50,
microbial control during, 87,	Black Spanish 16	52–53, 67, 70–72, 74, 78, 81,
89, 91–92	Blanc du bois 15	84
potential, yeast for (see 3001, MT), enzyme for (see EX-V),	Blancobent UF 96	Color Pro, Scottzyme 80, 83–84,
gelatins for (see Colle Perle,	BM 4x4™, Lalvin 11, 13, 16, 20	86
Inocolle)	Botrytis 41, 67, 69, 77–79,	Conversions (see unit conver- sions)
lees, 50	81-82, 84, 86, 91, 94	Crimson Pearl 16
role of discolved awaren in 101		

Brettanomyces 57, 73, 87–90, 92, Cross Evolution™ 11, 21, 33, 66 110, 112 BRG™, Levuline 11, 13, 20 3RL97™, Lalvin 13, 20, 29 Browning 51, 53, 67, 69, 71, 77, 93, 95, 99, 101, 108 \mathbf{C} abernet Franc 7, 13-14, 19, 21, 25, 29-30 Cabernet Sauvignon 7, 10, 13-14, 18-21, 24-28, 30, 47, 58, 63 Carbon, activated 93-95, 102, 104, 111 Casein 93-94, 98-99, 104, 108 Caséinate de Potassium 98, 107 CEG, Uvaferm 11, 20 Chambourcin 16 Chardonel 15 Chardonnay 11-12, 18, 20-26, 28-29, 31-32, 42, 44, 46-47, 59, 63, 83 Style Guide, 66 Chenin blanc 11-12, 18, 21, 23, 25, 27, 30–32 Chitin-Glucan 88-89, 92 Chitosan 88-90, 92 Cinn-Free, Scottzyme 80, 83 Clarification 23, 77-85, 87, 91, 93-94, 97-98, 100, 102-103, 108 Claristar 94, 103, 111 Cleaning 85, 105-106, 111 Clear Extreme, Rapidase 80, 82 CLOS™, Lalvin 13, 16, 21 Co-Inoculation 55-57, 63, 65 Cold soak 18, 33-34, 70, 81 Colle Perle 94, 100, 107–108, 111 EX-VTM, Lallzyme 80–82, 86 Colloidal stability 16, 94 Colombard 27, 47 Color stability 16, 20, 27, 50, 52-53, 67, 70-72, 74, 78, 81,

Bourgoblanc (see CY3079™)

Bourgorouge (see RC212™)

Cristalline Plus 94, 103, 107-108,

CSMTM 13, 16, 21 Cuvée Blanc™, Lallzyme 80, 81 CVW5™ 11, 15, 21, 66, 107 CY3079™, Lalvin 11, 15, 22, 66 D D21TM (see ICV D21TM) D254[™] (see ICV D254[™]) D47TM (see ICV D47TM) D80TM (see ICV D47TM) Detoxification 37, 61 Diacetyl 56-60, 63, 65 Diammonium Phosphate (DAP) 42-43, 45, 48-49, 54, 66 Direct Inoculation 36, 56–57, 62 DV10™, Lalvin 11, 22, 66, 107 EC1118™, Lalvin 11, 21-22, 107 Effervescent bacteria (see Malotabs) Elios 1™, Lalvin 56, 58 Elixir™, Vitilevure 11, 15, 22, 33 Enzymes 79-82, 84, 86, 93, 107-109, 111 Estate, Scott'Tan™ 68-69, 77-78, 110, 112 Esters 11-23, 25-26, 28-31, 33, 42-44, 46-47, 49, 55 EX™, Lallzyme 80-82, 86 Exotics Mosaic 11, 13, 15–16, 23, 111 Exotics Novello 11, 13, 23, 66 Expression Aroma, Rapidase 80, 82 Feelwood! oak chips 75 Fermaid KTM 39, 42, 44, 48, 54, Fermaid O[™] 17, 38-39, 42-44, 48-49, 54, 66, 107 Fermivin Champion 11, 13, 24 Fermivin MT48 13, 24

FermoBent PORE-TEC 94, 96

Fining 69-72, 84, 86-87, 91,

93-96, 98, 100-104, 107-110

Finishing kit 110 110-112 Flavia™ 33-34, 111 French oak 6, 72–73, 75 107, 111 Frontenac blanc 15 Frontenac gris 15 Fruit forward 13-14, 17, 19, 23-25, 28, 31-32, 80, 86 Fruit wine 21, 108 77–78, 107–108, 110, 112 77–78, 107–108, 110, 112 77, 107-108 77–78, 107–108, 110, 112 70-72, 77-78, 107-108 \mathbf{G} Gaia™ 33-34, 111 Gelatin 95, 100, 102, 104 21-22, 26, 28-32, 47, 83 107-108 Glutathione 8, 50-51 Go-Ferm™ 46 30-31, 34-39, 42, 44-45, 48-49, 54, 66, 107 Granucol FA 94-95 Granucol GE 94-95 Grape skin tannins 74 GRE (see ICV GRE™)

Finishing 65, 67–70, 73–74, 110, 112 Flashgum R Liquide 94, 104, 107, Freshprotect 94, 97-98, 104, FT Blanc, Scott'Tan™ 68-70, FT Blanc Citrus, Scott'Tan™ 68-70, 77–78, 107–108, 110, 112 Ft Blanc Soft, Scott'Tan™ 68, 70, FT ColorMax, Scott'Tan™ 68, 70, Ft Rouge, Scott'Tan™ 68, 70–72, FT Rouge Berry, Scott'Tan™ 68, 71, 77–78, 107–108, 110, 112 FT Rouge Soft, Scott'Tan™ 68, Gewürztraminer 11-12, 17, 19, Glutastar[™] 5, 42, 51, 53–54, 66, Glycosidase 69, 71, 79, 81-83 Go-Ferm Protect Evolution™ 17,

GranuBent PORE-TEC 6, 94, 97 Grape seed tannins 74 Grenache 13-14, 17-18, 20-21, 23-25, 29, 47, 51

Gum arabic 103 Н HC, Scottzyme 80, 82, 84-85, 107-108 Hot Mix Sparkolloid 93-94, 102, 107-108, 111 Hybrid cultivars (see individual cultivars) Hybrid winemaking yeast strains for, 15-16 tannins for, 71 enzymes for, 80, 82 Hybrid yeast 21-23, 26, 28, 31-32 111 ICV D21™, Lalvin 11, 14, 24 ICV D254™, Lalvin 12, 14, 16, 25, 33 ICV D47™, Lalvin 12, 24, 33, 66, 103-104 ICV D80™, Lalvin 14, 25 ICV Okay™, Lalvin 12, 14, 25, 78, 86, 107 107-108 ICV GRE™, Lalvin 12, 14, 25, 33, 71 ICV Opale 2.0™, Lalvin 12, 15, 26 Inactivated yeast 7–8, 42, 48–50, 54, 60-61, 94, 101 Inocolle 94, 100, 107-108, 111 Inodose granules and tablets 88, 91-92, 108, 111 lonys_{wF}TM 14, 26, 111 Isinglass 93-95, 102-103, 108 108 Itasca 15 K K1 (V1116)™, Lalvin 12, 27, 37, 39, 107 KS, Scottzyme 80, 82, 84-86, 107-108 Mourvedre 31

KS Plus, Scottzyme 80, 82, 85, 107-108 L La Crescent 15 Laccase 67, 69, 71, 77-78 Lachancea thermotolerans 33, 35 Lactic acid bacteria 37, 55, 87-90, 92

Laktia™ 33, 35, 111

LalVigne® 7-8 No Brett Inside™ 87-88, 90, 92, 108, 111 Lallzyme enzymes 81 Noblesse™ 42, 52, 54, 107–108, Late harvest wines 11–12, 17, 22, 110 29, 33, 86 Noiret 16 Lysovin 2, 4, 37–39, 57, 87–89, 108-109, 111 Non-Saccharomyces yeast 33, 36, 87, 111 Lysozyme (see Lysovin) Non-vinifera wine (see Hybrid M winemaking) M83™, Lalvin 12, 27 Norton 16 Malbec 13-14, 18, 20-21, 25-26, NT 116 12, 14, 28 28, 30-31 NT 202 14, 16, 28 Malolactic bacteria 17, 21, 25, 28, Nutrients 30, 35, 55, 57, 59-65, 107-108, for bacteria 60-61 for yeast 41-54 Malolactic fermentation 55-65 approved under 27 CFR Malolactic nutrients 60-61 24.246 42 Malotabs™ 56, 60 Mannoproteins 50, 79, 93, 0 Maréchal Foch 16 Marquette 16 MBR process 56-58, 62, 64-65, MBR 31 (see 31™, Lalvin) 87, 90 Mead 56, 68-70, 80, 88, 94, 102, 104. 107-108 Merlot 7, 13-14, 19-21, 23-31, 33, 47, 58, 75 Metschnikowia fructicola 33, 34 Metschnikowia pulcherimma 33, 110, 112 Microbial control 87-88, 92-93,

Nutrient Vit End™ 42, 50, 54 Oak 28, 42, 52, 59, 67-68, 72-73, 75-78, 104-106, 110-112 Oak chips 67, 75, 78, 104, 106 Oak restorer 105-106 Oenococcus oeni 39, 57-61, 63, Okay (see ICV Okay™) O-MEGATM 56, 58, 65-66 OMRI-listed 42, 45-46, 49-50, 52-53, 56, 60-61, 101 Onyx, Scott'Tan™ 68, 72, 77-78, Opale 2.0 (see ICV Opale 2.0™, Lalvin) Opti'Malo Blanc™ 61 Micropipettes 110 Opti'Malo Plus™ 56, 61 Minerals 41–48, 54–55, 65 Opti-MUM Red™ 42, 52, 54, 107, ML Red Boost™ 55-56, 59-62, 108 Opti-REDTM 42, 53, 86, 107-108 MMX™, Lallzyme 80-82, 86 Opti-White™ 42, 53-54, 107-108 Ordering 112 MSB™, Lalvin 5, 12, 27 Organic nitrogen 41-43, 46-47, MT™, Vitilevure 8, 14, 27 49, 54-55 Muscadine 15 Oxidation 51, 67-71, 74, 77-78, Muscat 7, 11–12, 19, 21, 28, 31, 87-88, 91, 93-94, 98-99, 101, 80 Oxygen scavenging 101 N NaCalit PORE-TEC 94, 97

Nitrogen 9, 11, 13, 15, 17-32, 35, 41-50, 54-55, 61

114

role of dissolved oxygen in, 101

use of oak and tannins during,

67-69, 74, 76-78

P

Pec5L, Scottzyme 80, 82, 84–85, 107–108

Pectin 79, 82-83, 85, 108

Persy™, Lalvin 14, 16, 28, 33

Petit Verdot 13–14, 18–21, 24–27, 30–31

Petite Pearl 16

Petite Sirah 13–14, 19, 21, 25–26, 28–32

Pinot blanc 11–12, 19, 21–22, 28, 30, 47

Pinot gris 11–12, 17–18, 21–22, 28, 32, 47, 83, 97, 104

Pinot noir 13-14, 18-20, 28-29, 32, 59, 71, 89, 92, 103

PN4™ 56, 59, 107

Polycacel 94, 99, 107, 111

Polycel 94, 99, 111

Polysaccharide 21, 24, 27, 79, 82

Potassium metabisulfite 91–92, 103, 111

Product Storage (see Storage Guidelines)

Protein stability 92, 94, 97
Pure-Lees Longevity +™ 111

PVPP 93-94, 98-99

Q

QA23TM, Lalvin 12, 15, 28, 33, 66, 69, 107

QTL Process 10

Quebracho 77

R

R2™, Lalvin 12, 29, 107

Racking 69–74, 78, 87, 89–90, 93, 99–100

Radiance, Scott'Tan™ 68, 72, 77–78, 107–108, 110, 112

Rapidase enzymes 82-83

RC212™, Lalvin 14, 16, 29

Reduless™ 54, 94, 101, 107–108, 110, 112

Rehydration nutrients 45–46

Reskue™ 17, 37–39, 42, 49, 61–62

Restart Stuck Fermentation 11– 14, 17, 22, 24, 27, 31, 56 Revelation Aroma, Rapidase 80, 82–83, 108

Rhône 2226™, Lalvin 14, 29

Rhône 4600™, Lalvin 12, 29, 33, 69

R-HST™, Lalvin 12, 30

Riche, Scott'Tan™ 68, 73, 77–78, 110, 112

Riche Extra, Scott'Tan™ 68, 73, 77–78, 110, 112

Riesling 7, 10–12, 17–19, 21, 25–26, 29–32, 47, 83

Roundness 21–22, 29, 52–53, 72, 74, 77, 101, 108

Royal, Scott'Tan™ 68, 73, 77–78, 110, 112

RP15™, Enoferm 14, 30

S

Sangiovese 13–14, 17, 19–20, 24–26, 29, 31–32

Sauvignon blanc 5, 7–8, 11–12, 18–19, 21–23, 26–32, 42, 44, 47, 51, 66, 69, 83, 97, 104

Sauvy™ 5, 12, 15, 30

Scottzyme enzymes 82–86, 107–108

Sensy™, Lalvin 12, 30, 107

Sequential Inoculation 57, 59, 63, 66

Seyval blanc 15

Silica gel 102

Silka™, Lalvin 56, 59

Skin contact enzymes 79

SO₂ 9-10, 18-19, 21-23, 25-35, 38, 45, 51, 55-61, 65, 69, 78-79, 86-87, 89-92, 101, 108, (see also sulfur dioxide products)

Solo Select 56, 59

Sparkling base 11–12, 19, 21–22, 27

St. Croix 16

Sterols 17, 41, 44-46, 48, 54

Stimula Chardonnay™ 42, 44, 46–47. 66

Stimula Sauvignon blanc™ 27, 30, 42, 44, 47, 66

Storage Guidelines 111

Stuck alcoholic fermentations 37–40

Stuck malolactic fermentations 61–62

Sulfides 10, 101

Sulfur dioxide (SO₂) products 91

Syrah™, Enoferm 14, 31

Syrah 13–14, 17, 19, 21, 23–26, 28, 30–32, 47, 51

т

T73™, Lalvin 14, 31

Tango Malbec™, Lalvin 14, 31

Tannins 7–8, 21, 25–26, 32, 50, 52–53, 67–69, 71–72, 74, 76–79, 81–84, 86, 89, 92–94, 107–112

Tartaric acid 26, 86, 91, 111

Tartrate stability 103

Tempranillo 13–14, 18, 21, 23–24, 26, 28, 31–32

Terpenes 16–17, 19, 22, 28, 33–34, 43, 82–83

Thermic oak, Oak Lab™ 67–68, 76, 110

Thiols 3, 5, 12, 18, 22–23, 26–28, 30, 33–34, 42, 44, 47, 49, 51, 82–83, 101

Torulaspora delbrueckii 33

Traminette 15

Troubleshooting Guides 37, 61, 65

U

UltiMA Soft 94, 104, 110-112

Unit conversions 109

Uva'Tan, Scott'Tan™ 68, 74, 78

Uva'Tan Soft, Scott'Tan™ 68, 74, 78

V

Vanilla 19, 72-73, 76, 108

Vidal blanc 15

Vignoles 15, 83

VIN 13 12, 15, 31, 37, 39, 69, 107

VIN 2000 12, 15, 32, 66, 69

Vineyard 7-9, 29, 31, 66, 77

Viognier 11-12, 17, 19, 22-23,

25, 29–32, 83

Vitamins 41-48, 54-55, 60-61, 65

Volatile acidity 9–10, 21–28, 30, 33–34, 37, 55, 57–59, 87

VP41™, Lalvin 56, 59, 62, 63, 65, 107

VRB™, Uvaferm 14, 32–33

W

W15[™], Lalvin 12, 14, 20, 29, 32, 66

Y

YAN (yeast assimilable nitrogen) 3, 9, 18, 31, 34–35, 37, 41–54, 66

YAN equivalents 42, 44, 46-49

Yeast 2–24, 26–28, 30–39, 41–57, 60–61, 63, 65–66, 69–71, 79, 81, 86–92, 94, 101, 107–108, 111

Yeast autolysates 46

Yeast nutrients 42, 46, 54

Yeast rehydration 36–39, 41–42, 44–46, 54

Yeast strains for American and hybrid (non-*Vinifera*) cultivars 15–16

Yeast strains for red wine 13–14

Yeast strains for white & rosé wine 11–12

YSEO 10

\mathbf{Z}

Zinfandel 13–14, 17–21, 24–25, 29–32